

[Manuals.plus](#) /

> [Luxshiny](#) /

> Luxshiny Vacuum Cleaner Hose Replacement with Ergonomic Curved Handle (Model 2W35QXG1726O95U) - Instruction Manual

## Luxshiny 2W35QXG1726O95U

# Luxshiny Vacuum Cleaner Hose Replacement

Model: 2W35QXG1726O95U

Instruction Manual

## INTRODUCTION

---

Thank you for choosing the Luxshiny Vacuum Cleaner Hose Replacement with Ergonomic Curved Handle. This manual provides essential information for the proper installation, operation, and maintenance of your new vacuum accessory. Please read these instructions carefully before use to ensure optimal performance and longevity of the product.

## SAFETY INFORMATION

---

Always follow basic safety precautions when using electrical appliances and accessories. This product is designed for use with compatible vacuum cleaners. Improper use may result in damage to the product or vacuum cleaner.

- Ensure the vacuum cleaner is unplugged before attaching or detaching the hose.
- Do not use the hose if it appears damaged.
- Keep the hose away from water or other liquids.
- This product is not a toy. Keep out of reach of children.

## PRODUCT OVERVIEW

---

The Luxshiny Vacuum Cleaner Hose Replacement features an ergonomic curved handle designed for comfortable and efficient cleaning. It is constructed from durable plastic materials for long-term reliability.



**Figure 1:** Overview of the Luxshiny Vacuum Cleaner Hose Replacement, showing its ergonomic curved design and key dimensions. The hose measures approximately 12.18 inches (31.0 cm) in length, with an inlet diameter of 1.97 inches (5.0 cm) and an outlet diameter of 1.65 inches (4.2 cm).



**Figure 2:** Detailed view of the Luxshiny Vacuum Cleaner Hose Replacement, highlighting the curved handle, connection points, and internal structure. This image provides a closer look at the robust construction and design elements.

## SPECIFICATIONS

Feature	Detail
Model Number	2W35QXG1726O95U
Material	Plastic
Color	Black
Product Dimensions	12.2 x 1.97 x 0.1 inches (31.00 x 5.00 x 4.20 cm)
Smaller Hole Inner Diameter	32 mm
Larger Hole Compatibility	Threaded hose with 35mm Inner diameter and 42mm outer diameter
Included Components	1 x Vacuum Cleaner Tube

## SETUP AND INSTALLATION

This replacement hose is designed for quick and easy installation. Ensure your vacuum cleaner is turned off and

unplugged from the power outlet before proceeding.

1. **Identify Connection Points:** Locate the hose connection point on your vacuum cleaner and the attachment point for your desired cleaning tool (e.g., floor nozzle, brush).
2. **Attach to Vacuum:** Insert the larger end of the replacement hose into the vacuum cleaner's hose inlet. Twist or push firmly until it clicks securely into place, ensuring a tight seal. This end is compatible with threaded hoses having a 35mm inner diameter and 42mm outer diameter.
3. **Attach Cleaning Tool:** Connect your preferred cleaning tool (e.g., floor nozzle, brush) to the smaller end of the ergonomic curved handle. The smaller hole has an inner diameter of 32mm. Push firmly until it is securely attached.
4. **Verify Connections:** Gently pull on both ends to ensure all connections are secure before operating the vacuum cleaner.



**Figure 3:** Illustration of the hose being connected to a vacuum cleaner, demonstrating the ease of installation. The image shows the curved handle ready to be attached to a floor nozzle.



**Figure 4:** A close-up view of the hose's connection end, showing the internal structure designed for secure attachment to vacuum cleaner accessories. This end typically connects to the cleaning tool.

## OPERATING INSTRUCTIONS

---

Once the hose is securely installed, you can begin using your vacuum cleaner with enhanced maneuverability.

- Plug in your vacuum cleaner and turn it on.
- Grip the ergonomic curved handle for comfortable control. The curved design allows for easier maneuvering around furniture and obstacles.
- Guide the cleaning tool over the surfaces you wish to clean.
- When finished, turn off and unplug the vacuum cleaner before detaching the hose or accessories.



**Figure 5:** A person operating a vacuum cleaner on a carpeted floor, demonstrating the use of the ergonomic curved handle for improved reach and comfort during cleaning.



**Figure 6:** A person operating a vacuum cleaner on a hard floor, illustrating how the curved handle facilitates cleaning under furniture and in tight spaces.

## MAINTENANCE

---

Regular maintenance will help prolong the life of your replacement hose.

- **Cleaning:** Wipe the exterior of the hose with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically inspect the hose for any signs of wear, cracks, or blockages.
- **Storage:** Store the hose in a cool, dry place away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
---------	----------------	----------

Hose does not attach securely.	Incompatible vacuum model or accessory; improper alignment.	Verify compatibility with your vacuum cleaner and accessories. Ensure correct alignment and push firmly until secure.
Reduced suction.	Loose connection; blockage in hose or vacuum.	Check all connections for tightness. Inspect the hose and vacuum for any obstructions and clear them.
Hose appears damaged.	Physical stress or wear.	Discontinue use if the hose is cracked or broken. Replace with a new hose if necessary.

## CUSTOMER SUPPORT

---

For further assistance or inquiries, please contact Luxshiny customer support through your retailer or the official Luxshiny website.

