



[Manuals.plus](#) /

> [PLAXSOON](#) /

> [PLAXSOON Flower Bakery Coffee House Building Set \(Model 881103\) Instruction Manual](#)

## PLAXSOON 881103

# PLAXSOON Flower Bakery Coffee House Building Set (Model 881103) Instruction Manual

Brand: PLAXSOON | Model: 881103

[Introduction](#) [Safety Information](#) [Package](#)

[Contents](#) [Assembly](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

## 1. INTRODUCTION

This manual provides detailed instructions for assembling and operating your PLAXSOON Flower Bakery Coffee House Building Set. This 1289-piece modular construction kit allows you to build a detailed three-story cafe bakery model with integrated lighting. Please read these instructions carefully before beginning assembly to ensure a smooth and enjoyable building experience.



Figure 1: Fully assembled Flower Bakery Coffee House.

## 2. SAFETY INFORMATION

- **Choking Hazard - Small Parts:** This product contains small parts and is not suitable for children under 3 years of age. Adult supervision is recommended for all users, especially those under the manufacturer's recommended age of 6 years.
- **Battery Warning:** This product contains a button battery. If swallowed, a lithium button battery can cause severe or fatal injuries in as little as 2 hours. Keep batteries out of reach of children. Seek immediate medical attention if a battery is suspected to have been swallowed or placed inside any part of the body.
- Ensure all electrical components (lighting kit) are handled according to instructions to prevent damage or malfunction.

### 3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. The package should contain:

- 1289 x Building Blocks (various shapes and sizes)
- 1 x Integrated Lighting Kit
- 1 x Instruction Manual



Figure 2: Overview of package contents and product dimensions.

### 4. ASSEMBLY INSTRUCTIONS

Follow the step-by-step visual instructions provided in the included manual. Sort pieces by color and shape to facilitate the building process. The set is designed with a modular structure, allowing for assembly of individual sections before combining them.

## 4.1. First Floor Assembly (Dessert Shop)

Begin by constructing the base and the first floor, which features the dessert shop. Pay close attention to the placement of the counter, cakes, and sweets. The side windows are designed to open, allowing for display of items.



Figure 3: First floor details, including the dessert shop.

## 4.2. Second Floor Assembly (Baking Room)

Proceed to assemble the second floor, which houses the baking room. This section includes miniature baking tools such as a rolling pin, bowls, and an oven. Ensure all details are correctly placed as per the instructions.



*Second Floor: Upstairs, a sunny baking room hums with life—here, flaky breads and creamy desserts are turning from ingredients into little joys.*

Figure 4: Second floor details, featuring the baking room.

### 4.3. Top Floor Assembly (Attic with Clock)

Construct the top floor, which includes an attic and a decorative clock. This section completes the main structure of the building.



*Top Floor:* The top spot is a cute, lit-up corner, plus a playful clock that's ready to tick off the perfect time for your next baked delight.

Figure 5: Top floor details, including the attic and clock.

#### 4.4. Lighting Kit Integration

The lighting kit is integrated during the assembly process. Follow the specific steps in the manual for wiring and placement of the lights. The design allows for easy wiring to ensure a clean finish.

 1289 PCS

 12+ AGES



Figure 6: Assembly in progress, demonstrating the building process.

## 5. OPERATION

### 5.1. Activating the Lights

Once assembly is complete and the lighting kit is installed, locate the power switch for the integrated lights. Flip the switch to illuminate the model. The lights are designed to provide a warm, welcoming glow.



Figure 7: Lights off (top) and lights on (bottom) comparison.

## 6. MAINTENANCE

- **Cleaning:** Dust the model regularly with a soft, dry cloth or a soft brush to maintain its appearance. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the assembled model in a stable location away from direct sunlight and extreme temperatures to prevent discoloration or warping of the plastic components.
- **Battery Replacement:** If the lights dim or stop working, replace the button battery according to the instructions provided with the lighting kit. Ensure proper polarity.

## 7. TROUBLESHOOTING

Issue	Possible Cause	Solution
-------	----------------	----------

Issue	Possible Cause	Solution
Missing pieces	Packaging error or accidental loss during assembly.	Review the package contents list. Contact PLAXSOON customer support for replacement parts.
Pieces do not connect securely	Incorrect piece selection or misalignment.	Double-check the instruction manual for the correct pieces and orientation. Apply firm, even pressure.
Lights not working	Battery issue, loose connection, or switch off.	Ensure the power switch is on. Check battery installation and replace if necessary. Verify all wiring connections are secure.

## 8. SPECIFICATIONS

---

**Product Name:** Flower Bakery Coffee House Building Set

**Brand:** PLAXSOON

**Model Number:** 881103

**Number of Pieces:** 1289

**Product Materials:** ABS Plastic

**Recommended Age:** 6 years and up (Adults, Teens, Girls 12+ for optimal experience)

**Assembled Product Dimensions:** Approximately 8.1 inches (W) x 6.2 inches (D) x 11.3 inches (H)

**Item Weight:** 3.72 pounds

**Manufacturer:** PLAXSOON

## 9. WARRANTY AND SUPPORT

---

PLAXSOON is committed to providing high-quality products. For any questions, concerns, or to report missing/damaged parts, please contact PLAXSOON customer support. Refer to the product packaging or the official PLAXSOON website for contact information.

Please retain your purchase receipt as proof of purchase for any warranty claims.

