

[Manuals.plus](#) /

› [PHILIPS](#) /

› Philips SFL2124 250 Lumen 5W LED Rechargeable Flashlight User Manual

PHILIPS SFL2124

Philips SFL2124 250 Lumen 5W LED Rechargeable Flashlight

Model: SFL2124

1. INTRODUCTION

Thank you for choosing the Philips SFL2124 LED Rechargeable Flashlight. This manual provides essential information for the safe and efficient use of your new flashlight. Please read these instructions carefully before use and retain them for future reference.

2. SAFETY INFORMATION

- Do not look directly into the LED light. The intense light can cause temporary vision impairment.
- Keep out of reach of children.
- Do not disassemble or modify the flashlight. This may cause damage and void the warranty.
- Use only the provided Type-C charging cable or a compatible certified cable.
- Avoid exposing the flashlight to extreme temperatures or direct sunlight for prolonged periods.
- Although water-resistant, do not submerge the flashlight in water.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- Philips SFL2124 LED Flashlight
- Type-C USB Charging Cable
- Wrist Lanyard
- User Manual (this document)
- Product Warranty Card



Image: Philips SFL2124 Flashlight, its retail box, Type-C charging cable, and documentation including the warranty card.

4. PRODUCT OVERVIEW

The Philips SFL2124 features a durable metal body, a rubber power switch, and a telescopic head for zoom functionality.

PHILIPS

SFL2124

EDC Teleskopik Yakınlaştırma

4 Işık Mod

Sonsuz Karartma

Type- C Şarj



Image: The Philips SFL2124 flashlight highlighting its telescopic zoom, four light modes, stepless dimming, and Type-C charging port.

5. SETUP

Initial Charging

Before first use, fully charge the flashlight. Connect the Type-C charging cable to the flashlight's charging port and plug the other end into a USB power source (e.g., wall adapter, computer USB port). The battery indicator will show red when below 30% charge and green when above 30% or fully charged. Charging typically takes approximately 3 hours.

6. OPERATING INSTRUCTIONS

Power On/Off and Mode Selection

The flashlight features a rubber switch for easy control.

- **First tap:** Activates Strong Light mode.

- **Second tap:** Switches to Soft Light mode.
- **Double tap quickly:** Activates or deactivates Flash-SOS mode.
- **Press and hold:** Turns the flashlight off from any mode.

Dört Mod Seçimi Geçiş yapmak için dokununuz

Birinci dokunuş güçlü ışık
ikinci dokunuş zayıf ışık

Flash-SOS'u açıp kapatmak için
iki kez seri dokununuz

Kauçuk Anahtar

Düzenlemenin tek elle
kontrolü



Güçlü
Işık



Düşük
Işık



Flaş



SOS

Image: Diagram illustrating the four mode selections (Strong Light, Low Light, Flash, SOS) and the rubber switch for single-hand control.


Telescopic Zoom

Adjust the beam focus by extending or retracting the flashlight head. Extend the head for a focused, long-range beam, and retract it for a wider floodlight illumination.

Stepless Dimming

While the flashlight is on in Strong or Soft Light mode, press and hold the power button to continuously adjust the brightness level from 15% to 100%. Release the button when the desired brightness is reached.

İhtiyaç Duyduğunuz Karartma Özelliği



Ayarlanabilir Parlaklık

15%~100%~

Image: Illustration of the adjustable brightness feature, showing a flashlight beam dimming from 100% to 15% output.

7. CHARGING

The Philips SFL2124 uses a 18650 Lithium Ion battery (1200 mAh) and charges via a Type-C port. The battery status indicator light provides a visual cue for the charge level:

- **Red light:** Battery charge is below 30%.
- **Green light:** Battery charge is 30% or above, or fully charged.

Ensure the flashlight is turned off during charging for optimal performance.

8. MAINTENANCE

Cleaning

Wipe the flashlight with a soft, damp cloth. Do not use abrasive cleaners or solvents. Keep the lens clean for optimal light

output.

Storage

Store the flashlight in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery every 3-6 months to maintain battery health.

9. TROUBLESHOOTING

Problem	Possible Cause	Solution
Flashlight does not turn on.	Low battery or depleted battery.	Charge the flashlight fully.
Light is dim or flickers.	Low battery. Dirty lens.	Charge the flashlight. Clean the lens with a soft cloth.
Flashlight does not charge.	Faulty charging cable or power source. Charging port obstruction.	Try a different Type-C cable and USB power source. Check the charging port for debris.
Zoom function is stiff.	Dirt or debris in the mechanism.	Gently clean the telescopic mechanism. Do not force it.

10. SPECIFICATIONS

The Philips SFL2124 is designed for reliable performance with the following specifications:

ÜRÜN ÖZELLİKLERİ



**Dört Kademeli
Karartma**



Süper Projektör



**Kademesiz
Karartma**



**Teleskopik
Yakınlaştırma**



**Alüminyum
Alaşımlı Malzeme**



Şık ve Kompakt

Image: Visual representation of key product features including stepless dimming, telescopic zoom, and aluminum alloy material.

Feature	Detail
Model Number	SFL2124
Light Output	≤ 250 Lumens (max.)
LED Power	5W
Lighting Modes	Strong light, Soft light, Flashing/SOS
Zoom Feature	Telescopic zoom (focused and wide illumination)
Dimming	Stepless Dimming (15%-100%)
Battery Type	18650 Lithium Ion Battery (1200 mAh)
Charging Time	~3 hours

Feature	Detail
Charging Input	Type-C
Battery Status Indicator	Present (red below 30%, green above 30%)
Drop Resistance	1 meter
Water Resistance Level	Water Resistant
Material	Metal (Aluminum Alloy)
Color	Black
Product Dimensions (L x W x H)	140 x 30 x 30 mm
Product Weight	0.16 Kilogram
Country of Origin	China

11. WARRANTY AND SUPPORT

Warranty Information

This Philips SFL2124 flashlight comes with a **2-Year Manufacturer Warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

Customer Support

For technical support, warranty claims, or any questions regarding your Philips SFL2124 flashlight, please contact Philips customer service. Refer to the contact information provided on your product warranty card or visit the official Philips website for your region.