

Bissell PowerClean FurGuard

Bissell PowerClean FurGuard 280W Self-Standing Cordless Vacuum

INSTRUCTION MANUAL

Product Overview

The Bissell PowerClean FurGuard 280W Self-Standing Cordless Vacuum is designed for efficient and convenient cleaning, especially for homes with pets. It features a powerful 280W motor, FurFinder Headlights to illuminate hidden debris, and a FurGuard Self-Cleaning Brushroll to prevent hair wrap. This model includes an extra battery for extended runtime, offering up to 50 minutes of cordless cleaning power. Its self-standing design allows for easy storage and convenient pauses during cleaning.



Figure 1: Bissell PowerClean FurGuard 280W Self-Standing Cordless Vacuum with included accessories and extra battery.

Setup and Assembly

1. **Unpack Components:** Carefully remove all components from the packaging. Ensure all parts listed in the user guide are present.
2. **Assemble the Vacuum:** Connect the main body to the cleaning head. Attach the extension wand if desired. Ensure all connections click securely into place.
3. **Charge the Battery:** Before first use, fully charge the 25.2V MAX Lithium-Ion Battery. Connect the charger to the battery and a power outlet. The indicator lights will show charging status.
4. **Attach Accessories:** The FurFinder Tool and other included components can be attached as needed for specific cleaning tasks.

Operating Instructions

The PowerClean FurGuard offers versatile cleaning modes for different surfaces and debris types.

- **Power On/Off:** Press the power button located on the handle to turn the vacuum on or off.
- **Select Power Mode:** The vacuum features 2 power levels. Use the mode selection button to switch between standard and max suction power.
- **FurFinder Headlights:** The integrated FurFinder Headlights automatically illuminate hidden pet hair and fine dust, ensuring thorough cleaning.
- **Self-Standing Feature:** The vacuum is designed to stand on its own, providing convenience for quick

pauses during cleaning or while charging.

- **Versatile Cleaning:** Easily transform the unit from a stick vacuum to a handheld or high-reach vacuum by detaching the main body and attaching desired tools.

Maintenance

Regular maintenance ensures optimal performance and longevity of your Bissell PowerClean FurGuard vacuum.

- **Emptying the Dirt Bin:** Regularly empty the dirt bin when debris reaches the 'MAX' line. Detach the bin and press the release button to empty contents into a trash receptacle.
- **Cleaning the FurGuard Self-Cleaning Brushroll:** The FurGuard brushroll is designed to minimize hair wrap. For cleaning, remove the brushroll cover and carefully pull out the brushroll. Remove any remaining tangled hair or debris. The brushroll can be rinsed with water if necessary, ensuring it is completely dry before reinstallation.
- **Filter Maintenance:** Periodically check and clean the vacuum's filters. Refer to the detailed instructions in the full user manual for filter removal and cleaning procedures. Ensure filters are completely dry before reinserting.

Troubleshooting

If you encounter issues with your PowerClean FurGuard vacuum, refer to the following common solutions:

- **No Power/Short Runtime:** Ensure the battery is fully charged. Check that the charger is properly connected. If using an extra battery, ensure it is also charged.
- **Reduced Suction:** Check if the dirt bin is full and needs emptying. Inspect the brushroll for any blockages or excessive hair tangles. Ensure all connections are secure and there are no obstructions in the air path. Clean or replace filters if they are clogged.
- **Brushroll Not Spinning:** Verify that the brushroll is properly installed and free from obstructions. Check for any error indicators on the vacuum.

For more complex issues or persistent problems, please contact Bissell Customer Support.

Specifications

Brand	Bissell
Model Name	PowerClean FurGuard
Motor Power	280W (0.375 horsepower)
Battery Type	25.2V MAX Lithium-Ion
Runtime	Up to 50 minutes
Included Components	FurFinder Headlights, FurGuard Self-Cleaning Brushroll, FurFinder Tool, Extra Battery
Cordless	Yes
Number of Power Levels	2

Indoor/Outdoor Usage	Indoor
-----------------------------	--------

Warranty and Support

Bissell products are manufactured to high standards and undergo rigorous testing. Your Bissell PowerClean FurGuard vacuum is covered by a limited warranty. Please refer to the warranty card included with your product for specific terms and conditions.

Note: Damage to or malfunction of your machine caused by non-BISSELL parts, such as a battery not supplied by Bissell, may not be covered under your warranty.

For product support, replacement parts, or to register your product, please visit the official Bissell website or contact their customer service. Every purchase proudly supports the BISSELL Pet Foundation and its mission to help save homeless pets.

Important Safety Information

Always read and follow all safety instructions provided in the complete user manual before operating your vacuum cleaner to reduce the risk of fire, electric shock, or injury.