

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

### Cuifati CUIFATIfwy96o0dsv-11

## Cuifati 4G Mobile WiFi Router User Manual

Model: CUIFATIfwy96o0dsv-11

### INTRODUCTION

Thank you for choosing the Cuifati 4G Mobile WiFi Router. This device provides a portable, high-speed wireless internet connection, ideal for travel, remote work, and various outdoor activities. It allows multiple devices to connect simultaneously, ensuring stable and efficient network access.

### SAFETY INFORMATION

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Use only the provided charging cable and a compatible power adapter.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- Keep the device away from water and other liquids.

### PACKAGE CONTENTS

Please check the package for the following items:

- 1 x Cuifati 4G 5G WiFi Hotspot
- 1 x User Manual
- 1 x Charging Cable



Image: The Cufati 4G Mobile WiFi Router shown alongside its included charging cable.

## PRODUCT OVERVIEW

Familiarize yourself with the device's components and indicators.



Image: Top view of the Cuifati 4G Mobile WiFi Router, highlighting the indicator lights for WiFi, signal strength, and battery.

### Indicator Lights:

- **WiFi Indicator:** Shows WiFi status.
- **Signal Strength Indicator:** Displays network signal strength.
- **Battery Indicator:** Indicates battery level.



Image: Front and back views of the Cufati 4G Mobile WiFi Router, showing its compact design.

## SETUP

Follow these steps for initial setup:

- 1. Insert SIM Card:** Locate the SIM card slot on the device. Gently insert your activated SIM card into the slot until it clicks into place. Ensure the SIM card is correctly oriented.
- 2. Insert Memory Card (Optional):** If desired, insert a memory card (up to 32GB, not included) into the designated slot.
- 3. Charge the Device:** Connect the provided charging cable to the device and a compatible USB power adapter. Charge the device fully before first use. The battery indicator will show charging status.
- 4. Power On:** Press and hold the power button (location may vary, refer to device diagram) until the indicator lights illuminate.

## OPERATING INSTRUCTIONS

### Connecting to the WiFi Hotspot:

1. Ensure the Cufati 4G Mobile WiFi Router is powered on.
2. On your device (smartphone, laptop, tablet), open the WiFi settings.
3. Search for available WiFi networks. The network name (SSID) and password are typically found on a sticker inside the battery compartment or on the device itself.
4. Select the Cufati hotspot's SSID and enter the password when prompted.
5. Once connected, you can access the internet.



Image: A mobile phone screen showing network speed test results, demonstrating the high-speed data capabilities of the hotspot.

### Key Features:

- **High-Speed Connectivity:** Enjoy download speeds up to 150Mbps and upload speeds up to 50Mbps, suitable for HD video streaming, remote work, and social media.
- **Multi-Device Support:** Connect up to 10 devices simultaneously, enabling high-speed network sharing for family or colleagues.
- **Long Battery Life:** The built-in 3000mAh Li battery provides up to 12 hours of continuous usage on a single charge.

- **Intelligent Signal Stability:** Equipped with intelligent chips for enhanced signal stability and data transfer efficiency.



Image: The Cufati 4G Mobile WiFi Router with graphical overlays highlighting its ability to connect up to 10 devices and its 3000mAh battery capacity.

# 3000mAh battery Long battery life

The Ideal Network of Life and Work



Image: The Cufati 4G Mobile WiFi Router with text emphasizing its 3000mAh battery and long battery life, ideal for extended use.

Say goodbye to interruptions and lags for seamless browsing, streaming and downloading.



Image: The Cufati 4G Mobile WiFi Router against a dynamic background, illustrating its capability for seamless browsing, streaming, and downloading.



Image: A collage depicting various usage scenarios for the mobile WiFi router, including business, travel, and outdoor activities, highlighting its versatility.

## MAINTENANCE

- Clean the device regularly with a soft, dry cloth. Do not use liquid cleaners.
- Store the device in a cool, dry place when not in use.
- Avoid overcharging the battery. Disconnect the charger once the battery is full.
- If the device will not be used for an extended period, charge it to about 50% before storing.

## TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---------|----------------|----------|
|---------|----------------|----------|

| Problem                        | Possible Cause  | Solution  |
|--------------------------------|---|---|
| No internet connection         | SIM card not inserted correctly or not activated; no network signal; data plan exhausted. | Ensure SIM card is properly inserted and activated. Check signal strength indicator. Verify data plan with your service provider. Try restarting the device.            |
| Cannot connect to WiFi hotspot | Incorrect WiFi password; device too far from hotspot; hotspot not powered on.             | Double-check the WiFi password. Move closer to the hotspot. Ensure the hotspot is powered on and its WiFi indicator is lit.   |
| Slow internet speed            | Weak signal; too many connected devices; network congestion.                              | Move to an area with better signal. Disconnect unnecessary devices. Try restarting the hotspot.   |
| Battery drains quickly         | Continuous heavy usage; old battery.  | Reduce continuous usage. Ensure background applications on connected devices are not consuming excessive data. If battery life significantly degrades, contact support. |

## SPECIFICATIONS

| Feature                         | Detail   |
|---------------------------------|--|
| Model Number                    | CUIFATIfwy96o0dsv-11                           |
| Battery                         | Built-in 3000mAh Li Battery                    |
| SIM Card Slot                   | Supports SIM Card (Not Included)               |
| Memory Card Slot                | Supports up to 32GB Memory Card (Not Included) |
| Download Speed                  | Up to 150Mbps                                  |
| Upload Speed                    | Up to 50Mbps                                   |
| Max Connected Devices           | 10   |
| Item Weight                     | 5.4 ounces                                     |
| Package Dimensions              | 5.51 x 3.54 x 1.18 inches                      |
| Wireless Communication Standard | 802.11ac                                       |

## WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official Cufati website. You may also contact the seller directly through the platform where the product was purchased.

**Seller:** Cufati3

**Amazon Store:** [Visit the Cufati Store on Amazon](#)



