

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VCHOO](#) /

› [VCHOO Keyless Entry Door Lock with Handle Set, Keypad Door Locks with Lever Handle, Auto-Lock&Anti-Peeping Password Smart Deadbolt Lock for Home Apartment Office Front Door Locks Oil Rubbed Bronze User Manual](#)

VCHOO SL01

VCHOO Keyless Entry Door Lock User Manual

Model: SL01

1. PRODUCT OVERVIEW

The VCHOO Keyless Entry Door Lock with Handle Set provides a secure and convenient access solution for homes, apartments, and offices. This smart deadbolt lock features multiple unlocking methods, robust construction, and advanced security functions to safeguard your property.

Key Features:

- **Smart Keyless Entry:** Supports up to 100 user codes (97 user, 3 admin), one-time codes, and mechanical key access.
- **Durable Construction:** ANSI Grade 3 smart door lock cylinder and high-quality zinc alloy deadbolt for long-lasting security.
- **Enhanced Security:** Features auto-lock within 10-30 seconds, one-touch lock, and anti-peeping password function.
- **Weather Resistant:** IP54 waterproof rating, designed to withstand extreme temperatures (-4 °F to 140 °F).
- **Low Battery Alert:** Notifies you when batteries are low, with an emergency TYPE-C charging port.



Image: The VCHOO Keyless Entry Door Lock with its keypad and handle set, installed on a modern white door.

2. PACKAGE CONTENTS

Please verify that all components are present and in good condition before beginning installation.

- Deadbolt Front Lock x 1
- Deadbolt Rear Lock x 1
- Door Handle Front Lock x 1
- Door Handle Rear Lock x 1
- Key x 2
- Lock Latch x 2
- Screw Accessories Package x 2
- Hole Opening Diagram x 1
- Installation Tutorial Card x 2

- Instructions x 1
- Screwdriver x 1




Image: A comprehensive layout of all parts included in the VCHOO Keyless Entry Door Lock package, including the deadbolt units, lever handles, keys, latches, and various screws.

3. SPECIFICATIONS

Feature	Description
Brand	VCHOO
Model Name	SL01
Lock Type	Keypad Deadbolt
Special Feature	Auto-Lock

Material	Zinc
Color	Oil Rubbed Bronze
Item Dimensions (L x W x H)	2.3 x 5.8 x 2.8 inches
Item Weight	3.36 Pounds
Power Source	4 AA Batteries (not included)
Door Thickness Range	1.31" - 2.16" (33mm - 55mm)
Backset	2-3/8in or 2-3/4in (60 or 70mm)
Waterproof Rating	IP54

4. SETUP AND INSTALLATION

The VCHOO Keyless Entry Door Lock is designed for easy installation and can replace most standard door locks with just a screwdriver. Ensure your door thickness and backset measurements are compatible before proceeding.

Check the Size Before Your Purchase

Suitable For US Left-Handle & Right-Handle Standard Doors




Image: Detailed diagram illustrating the required door measurements, including thickness, backset, and latch hole types, to ensure compatibility with the VCHOO lock.

Installation Steps:

- 1. Prepare the Door:** Ensure the door is properly drilled according to the provided hole opening diagram. The lock fits both left and right-hand doors.
- 2. Install the Latch:** Insert the lock latch into the door edge. Ensure the latch bolt faces the correct direction for your door swing.
- 3. Install the Exterior Assembly:** Place the exterior keypad assembly onto the door, aligning it with the latch.
- 4. Install the Interior Mounting Plate:** Secure the interior mounting plate to the exterior assembly using the provided screws.
- 5. Connect Cables and Install Interior Assembly:** Connect the cable from the exterior assembly to the interior assembly. Carefully tuck the cable into the designated channel. Attach the interior assembly to the mounting plate.
- 6. Install Batteries:** Insert 4 AA batteries (not included) into the battery compartment of the interior assembly.

7. **Install Handle Set:** Attach the lever handles to both sides of the door, ensuring they operate smoothly.
8. **Test the Lock:** After installation, test the lock with the mechanical key and default code (if any) to ensure proper function before closing the door.

Handle Reinstallation Video:

If the handle detaches or requires reinstallation, please refer to the following official video for detailed instructions:

Your browser does not support the video tag.

Video: This video demonstrates the process of reattaching the handle to the VCHOO SL01 lock, showing how to align the components and secure them properly.

5. OPERATING INSTRUCTIONS

The VCHOO Keyless Entry Door Lock offers multiple convenient ways to secure and access your property.

Multiple Ways to Unlock

100 User Codes
One-time Codes
2 Spare Keys

Kid Family
Parent Roommate
Courier Repairman

The advertisement features a large image of the VCHOO keyless entry door lock on a white door. The lock is black with gold accents and has a numeric keypad with 12 buttons (1-9, 0, and two lock icons) and the brand name 'VCHOO' below it. Below the keypad is a traditional keyhole. To the left of the lock, there is a list of six user categories, each with a circular icon: 'Kid' (two children), 'Family' (a family of four), 'Parent' (an elderly couple), 'Roommate' (three young adults), 'Courier' (a man with a clipboard), and 'Repairman' (a man with a hard hat and tools). Above the lock, the text 'Multiple Ways to Unlock' is written in a large, bold font. To the left of the lock, there are three icons representing different unlocking methods: a group of people for '100 User Codes', a binary code for 'One-time Codes', and a key for '2 Spare Keys'.

Image: Visual representation of the various unlocking methods available for the VCHOO lock, including user codes, one-time codes, and spare keys, suitable for different users like family, guests, or service personnel.

Setting User Codes:

Refer to the detailed programming instructions in the included Installation Tutorial Card for setting up admin and user passcodes. The lock supports up to 100 unique codes.

One-Time Codes:

Generate temporary one-time codes for visitors or service providers. These codes expire after a single use, providing enhanced security.



Image: A person receiving a one-time entry code via text message, demonstrating the convenience of temporary access for guests or deliveries.

Auto-Lock Function:

The lock can be configured to automatically lock after a set period (10-30 seconds) once the door is closed. This feature ensures your door is always secured.

One-Touch Lock:

Simply press and hold the '#' button on the keypad to instantly lock the door from the outside.

Keyless Entry, Make Life Easy

Auto Lock & One Touch Lock



Image: A visual representation of the auto-lock mechanism engaging and a hand demonstrating the one-touch lock feature, highlighting ease of use for daily security.

Anti-Peeping Password:

To prevent others from guessing your code, you can enter random numbers before or after your actual password. The lock will still recognize the correct sequence within the longer string of numbers.

6. MAINTENANCE

To ensure the longevity and optimal performance of your VCHOO Keyless Entry Door Lock, follow these maintenance guidelines:

- **Cleaning:** Wipe the keypad and handle surfaces with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Battery Replacement:** Replace all four AA batteries when the low battery alert is activated. Always use

new, high-quality alkaline batteries. Do not mix old and new batteries or different battery types.

- **Mechanical Key:** Keep the backup mechanical keys in a safe, accessible location outside of your home in case of battery failure or electronic malfunction.
- **Regular Checks:** Periodically check that all screws are tight and that the lock operates smoothly.

7. TROUBLESHOOTING

If you encounter issues with your VCHOO Keyless Entry Door Lock, please refer to the following common solutions:

- **Lock Not Responding:** Check if the batteries are depleted. Replace them if necessary. Ensure the battery compartment is clean and contacts are firm.
- **Keypad Not Working:** Verify that the cables between the exterior and interior assemblies are securely connected.
- **Code Not Accepted:** Double-check that you are entering the correct code. Ensure the lock is not in a 'locked out' state due to multiple incorrect attempts. Try using the mechanical key.
- **Handle Feels Loose or Detached:** Refer to the "Handle Reinstallation Video" in Section 4 for guidance on reattaching the handle securely.
- **Auto-Lock Not Functioning:** Ensure the auto-lock feature is enabled in your lock's settings (refer to your programming guide). Check for any obstructions preventing the door from closing fully.
- **Emergency Power:** If batteries are completely dead, use the TYPE-C charging port for temporary power to unlock the door.

If the problem persists after attempting these solutions, please contact VCHOO customer support.

8. WARRANTY AND SUPPORT

VCHOO provides a limited warranty for this product. For specific warranty terms and conditions, please refer to the warranty card included in your package or visit the official VCHOO website. Keep your purchase receipt as proof of purchase.

For technical support, troubleshooting assistance, or warranty claims, please contact VCHOO customer service through the following channels:

- **Email:** Refer to your product packaging or the VCHOO official website for contact email.
- **Website:** Visit the VCHOO store on Amazon or their official website for FAQs and support resources.