

[Manuals.plus](#) /

› [TISSCARE](#) /

› TISSCARE Electric Scalp Massager Instruction Manual (Model 755752387274)

## TISSCARE 755752387274

# TISSCARE Electric Scalp Massager Instruction Manual

MODEL: 755752387274

## Introduction

This manual provides essential information for the safe and effective operation of your TISSCARE Electric Scalp Massager. Please read thoroughly before first use and retain for future reference.




Image: TISSCARE Electric Scalp Massager with its various silicone massage heads.

## Product Features

- **Deep Scalp Relaxation:** Features 4 silicone massage claws with 96 massage nodes for a 360° simulated human finger kneading massage. Promotes blood circulation, stimulates hair growth, and relieves soreness. Soft silicone conical massage heads prevent hair tangling.
- **Waterproof & Versatile Use:** Designed for both wet and dry use. Suitable for use during showering or hair washing. Can be used on various body parts including shoulders, back, and legs to relieve muscle tension. Also suitable for pet massage.
- **One-Button Operation with 3 Speed Levels:** User-friendly single-button control. Short press to switch between High, Low, and Regular speed modes. Long press to power on/off.
- **Ergonomic & Portable Design:** Compact and ergonomic structure for comfortable handling. Lightweight, cordless design ideal for home, office, or travel. Includes a hanging loop for easy storage.
- **Rechargeable & Smart:** Powered by a rechargeable lithium-ion battery for cordless convenience. Includes a USB charging cable. Offers up to 10 days of daily use on a full charge. Features a 10-minute auto-off function to prevent overuse and conserve battery life.




Image: Overview of key features including massage nodes, red light therapy, and ergonomic design.



Image: Visual representation of the multiple benefits of using the massager.

## Setup

1. **Initial Charge:** Before first use, fully charge the massager using the provided USB charging cable. The device is powered by a rechargeable lithium-ion battery.
2. **Charging Process:** Connect the USB cable to the charging port on the massager and a compatible USB power source (e.g., power bank, laptop, phone adapter). The indicator light will show charging status.
3. **Attachment Selection:** The massager comes with different silicone massage heads. Choose the desired heads and ensure they are securely attached to the device.

## USB Charging



Image: USB charging options for the massager.

## Operating Instructions

---

1. **Power On/Off:** Press and hold the power button for a few seconds to turn the massager on or off.
2. **Select Speed Mode:** Briefly press the power button to cycle through the 3 available speed modes: High, Low, and Regular. Choose the intensity that best suits your preference.
3. **Application:** Gently place the massager on the desired area (scalp, neck, shoulders, etc.). Allow the rotating massage nodes to work. Move the device slowly across the area for comprehensive coverage.
4. **Auto-Off Feature:** The massager is equipped with a 10-minute auto-off function to prevent overuse and conserve battery life. The device will automatically power down after 10 minutes of continuous use.

# 3 Massage Modes One Control Button

 Mode 1 - High Speed

 Mode 2 - Low Speed

 Mode 3 - Regular Speed

 Long Press  
Power ON/OFF

 Short Press  
Mode Change



Image: One-button operation for power and speed selection.

Your browser does not support the video tag.

Video: Demonstration of the TISSCARE Electric Scalp Massager in use, highlighting its features and benefits for scalp massage.

## Maintenance

- **Cleaning:** The massager is waterproof. After wet use (e.g., in the shower), ensure to rinse off any shampoo or product residue. Dry the massager thoroughly with a soft cloth.
- **Detachable Heads:** The silicone massage heads are detachable for easy cleaning. Gently pull them off, clean them, and reattach them securely.
- **Storage:** Store the massager in a cool, dry place away from direct sunlight. Use the integrated hanging loop for convenient storage.

# Waterproof Design

Clean & Massage  
in the shower and bath



Image: The massager's waterproof design allows for easy cleaning and use in wet environments.

## Troubleshooting

- **Device Not Turning On:** Ensure the device is fully charged. Connect it to the USB charger and allow sufficient time for charging.
- **Weak Massage Intensity:** Check the battery level. A low battery can affect performance. Recharge the device if necessary.
- **Unusual Noise:** Ensure all massage heads are securely attached. If the noise persists, discontinue use and contact customer support.
- **Charging Issues:** Verify that the USB cable is properly connected to both the massager and the power source. Try a different USB port or adapter.

## Specifications

|                    |                                                   |
|--------------------|---------------------------------------------------|
| Product Dimensions | 3.94 x 3.35 x 3.15 inches                         |
| Item Model Number  | 755752387274                                      |
| Batteries          | 1 Lithium Ion batteries required                  |
| Item Weight        | 8 ounces (0.5 Pounds)                             |
| Power Source       | Battery Powered                                   |
| Material           | Acrylonitrile Butadiene Styrene, Silicone         |
| Manufacturer       | Wenzhou Lianhuang Electronic Technology Co., Ltd. |

## Warranty and Support

For any questions or support regarding your TISSCARE Electric Scalp Massager, please contact TISSCARE customer service. We are committed to providing continuous support and information to our customers. Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question