Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bellemave WL000053TFS2-T

Bellemave Twin Over Full Bunk Bed with Trundle - Instruction Manual

Model: WL000053TFS2-T

1. Introduction

Thank you for choosing the Bellemave Twin Over Full Bunk Bed with Trundle. This manual provides essential information for the safe assembly, operation, and maintenance of your new bunk bed. Please read all instructions carefully before assembly and retain this manual for future reference.

This heavy-duty metal bunk bed is designed to provide versatile sleeping space, accommodating three sleepers with its twin-over-full configuration and pull-out trundle. It features full-length guardrails and a stable ladder for safety.

2. Safety Information

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Always use the ladder to access the top bunk. Never jump on or off the top bunk.
- Ensure all connections are tight and secure before use. Periodically check and tighten all bolts and fasteners.
- Do not exceed the weight capacity:**Top Bunk: 250 lbs**, **Bottom Bunk: 350 lbs**, **Trundle: 250 lbs**.
- The top bunk is not suitable for children under 6 years of age.
- Ensure mattresses used are of the correct size and thickness to prevent entrapment. The maximum mattress thickness for the top bunk should not exceed 6 inches.
- Always use the full-length guardrails provided on the upper bunk.
- Prohibit more than one person on the top bunk.
- Prohibit horseplay on or under the bed.
- Use of a night light may provide added safety for a child using the upper bunk.
- Always use the recommended size mattress or mattress foundation, or both, to help prevent the likelihood of entrapment or falls.

3. Setup and Assembly

This bunk bed requires assembly. All necessary accessories and detailed, numbered assembly instructions are included. It ships in two boxes with labeled parts for a streamlined setup process.

3.1 Before You Begin

- Read through all steps before beginning assembly.
- Clear a spacious area for assembly.
- Verify all parts and hardware are present against the included parts list.
- Do not fully tighten bolts until instructed to do so.

3.2 Assembly Steps

Follow the step-by-step instructions provided in the packaging. Ensure proper alignment of all components. Two people are recommended for assembly.




Image: Detailed dimension diagram of the bunk bed, illustrating the length, width, and height of the twin top bunk, full bottom bunk, and the pull-out trundle. Key measurements like guardrail height and ladder step spacing are also shown.

The diagram above provides an overview of the bed's dimensions, which can be helpful during assembly to understand the scale and fit of components.

4. Operating Instructions (Usage)

4.1 Using the Bunk Beds

- The top bunk is designed for a twin-size mattress.
- The bottom bunk is designed for a full-size mattress.
- Always use the integrated ladder for safe access to the top bunk.

4.2 Using the Trundle Bed

The trundle bed is designed to glide smoothly from underneath the bottom bunk. It accommodates a twin-size mattress.

- To extend the trundle: Gently pull the trundle frame outwards from under the bottom bunk.
- To retract the trundle: Push the trundle frame back into its position under the bottom bunk until it is fully stored.



Image: A silver metal bunk bed with a twin bed on top and a full bed on the bottom. The trundle bed is pulled out from underneath the bottom bunk, ready for use.

5. Maintenance

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the powder-coated finish.
- **Fasteners:** Periodically check all bolts, screws, and fasteners to ensure they are tight. Re-tighten as necessary to maintain stability and safety.
- **Inspection:** Regularly inspect the bed frame for any signs of wear, damage, or loose components. Address any issues promptly.

6. Troubleshooting

- **Squeaking Noises:** If the bed makes squeaking noises, check and tighten all bolts and connections. Ensure the bed is on a level surface.
- **Difficulty with Trundle:** If the trundle is difficult to pull out or push in, check for any obstructions underneath the bed or ensure the wheels are clean and free of debris.
- **Missing Parts:** If you find any parts missing or damaged during assembly, please contact customer support immediately.

7. Specifications

Feature	Detail
Model Number	WL000053TFS2-T
Brand	Bellemave
Size	Twin Over Full with Trundle
Product Dimensions (L x W x H)	78.1" x 96.8" x 63"
Color	Silver
Material	Metal
Finish Type	Powder Coated
Assembly Required	Yes
Top Bunk Weight Capacity	250 lbs
Bottom Bunk Weight Capacity	350 lbs
Trundle Weight Capacity	250 lbs
Compatible Mattress Size	Twin (Top/Trundle), Full (Bottom)
Included Components	Guardrails, Headboard, Slats
Item Weight	108 pounds

8. Warranty and Support

For any issues, missing parts, or questions regarding your Bellemave Twin Over Full Bunk Bed with Trundle, please contact our customer support team.

Customer Support Email: service@bellemave.com

Please refer to your purchase documentation for specific warranty details. Generally, Bellemave products are covered by a manufacturer's warranty against defects in materials and workmanship.

© 2025 Bellemave. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FFGNVQDC

More documents and user manuals: **https://manuals.plus/**