



[Manuals.plus](#) /

> [WIE](#) /

> WIE Slushie Machine WS26M-B007-B-Ov-us User Manual

WIE WS26M-B007-B-Ov-us

WIE Slushie Machine User Manual

Model: WS26M-B007-B-Ov-us

INTRODUCTION

Thank you for choosing the WIE Slushie Machine. This manual provides essential information for the safe and efficient operation of your new appliance. Please read all instructions carefully before first use and retain this manual for future reference.



Image: The WIE Slushie Machine on a kitchen counter, surrounded by different frozen beverages.

IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons. This appliance is for residential indoor use only.

- Do not immerse the unit in water.
- Ensure the unit is kept upright for at least 2 hours before plugging in for the first use.
- All beverages must contain at least 5% sugar content for proper freezing.
- When using the wine/cocktail preset, premixed drinks should have 2.8%-16% alcohol content.
- Insufficient sugar will block proper freezing. Sugar-free recipes will not slush properly on their own; add recommended sugar substitutes.

PACKAGE CONTENTS

Verify that all items are included in the package:

- 1x WIE Slushie Machine
- 1x User Manual
- 1x Warranty Card
- 1x Drip Tray
- 1x Recipe Inspirations Booklet

PRODUCT OVERVIEW

The WIE Slushie Machine features a sleek design and advanced technology for creating various frozen beverages.

Key Features:

- **No-Ice-Needed Technology:** Revolutionary rapid-freezing eliminates the need for ice cubes.
- **88oz Capacity:** Large vessel with dual capacity indicators (68 fl oz recommended, 88 fl oz max fill) serves 7-9 people.
- **5 Preset Programs:** Includes Ice Cream, Slushy, Spiked Slush, Chilled Juice, Milkshake, Cocktail, and Margarita Frappé.
- **Self-Cleaning Function:** Easy maintenance with an auto-clean cycle.
- **Low Noise Operation:** Operates at approximately 40dB.
- **360° Spiral Blending:** Ensures efficient and consistent freezing.

88oz Vessel

360° Spiral Blending Technique



Image: Front view of the WIE Slushie Machine highlighting its 88oz vessel, 360° spiral blending, low noise, and smart touch control panel.

Control Panel:

The intuitive one-touch control panel allows for effortless operation.

- **Preset Menu/Cleaning Mode Button:** Press to cycle through presets; hold for 3 seconds to activate self-cleaning.
- **Start/Stop Button:** Initiates or pauses the selected program.
- **Thickness Setting:** Adjusts the consistency of your frozen drink.
- **Power ON/OFF Button:** Turns the appliance on or off.

Easy to Use 3 simple steps



Add
Drinks



Select a
program



Wait for
slushy



15mins Simply operation Design
Only 15 minutes

Image: A detailed view of the WIE Slushie Machine's one-touch control panel with buttons for presets, start/stop, thickness, and power.

SETUP

Before using your WIE Slushie Machine for the first time, please follow these steps:

1. **Unpack:** Carefully remove all packaging materials and inspect the unit for any damage.
2. **Positioning:** Place the unit on a stable, level surface. Ensure it remains upright for at least 2 hours before plugging it in.
3. **Clean Components:** Wash all removable components (vessel, lid, stirrer, drip tray) with warm, soapy water or place them in the dishwasher. Rinse thoroughly and dry.
4. **Assemble:** Reassemble the stirrer inside the vessel, then attach the vessel to the main unit. Ensure the drip tray is correctly positioned.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet. The unit will beep and

indicator lights will illuminate.

OPERATING INSTRUCTIONS

Making your favorite frozen drinks is simple with the WIE Slushie Machine:

1. **Add Liquid:** Pour your desired beverage into the vessel. Ensure the liquid level is between the MIN FILL (16oz) and MAX FILL (68oz) lines.
2. **Select Program:** Press the Preset Menu button to cycle through the 5 available programs (Slush, Frappe, Milkshake, Spiked Slush, Frozen Juice). The unit will start at the default optimal temperature for ideal texture.
3. **Adjust Thickness (Optional):** Use the Thickness Setting button to fine-tune the consistency of your drink.
4. **Start:** Press the Start/Stop button to begin the freezing and blending process.
5. **Dispense:** Once done, the unit will prompt with beeps. Pull the handle on the dispenser to serve.




Image: A woman pouring juice into the WIE Slushie Machine, illustrating the easy 3-step operation.

Important Usage Tips:

- All beverages/liquids added should have a sugar content of at least 5%.
- For wine/cocktail presets, ensure alcohol content is between 2.8% and 16%.
- Insufficient sugar will prevent proper freezing of slushie.
- Sugar-free recipes will not slush properly on their own. Add a recommended sugar substitute (refer to included guide) to ensure best results.
- Do not turn off the preset until all frozen drink has been dispensed.

Video: A demonstration of the WIE Slushie Machine in operation, showing the blending process and dispensing a frozen drink.

CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and hygiene.

Self-Cleaning Mode:

1. After each use, remove any remaining liquid from the vessel.
2. Add clean water to the vessel.
3. Press and hold the Preset Menu button for 3 seconds to activate the auto-clean function. All indicator lights will flash during the 5-minute cycle.
4. Once the cycle is complete, dispense the water and wipe the vessel dry.

Self Cleaning Mode



Image: A hand activating the self-cleaning mode on the WIE Slushie Machine, with water circulating inside the vessel.

Detachable Parts:

All removable components are dishwasher-safe for thorough cleaning.

- The vessel, lid, stirrer, and drip tray can be easily detached for cleaning.
- For manual cleaning, use warm, soapy water and a soft cloth.



DIY Slushies/Smoothies/Frozen Drinks

Image: The WIE Slushie Machine with its vessel and stirrer detached, demonstrating ease of cleaning and assembly.

SPECIFICATIONS

Feature	Detail
Brand	WIE
Model Name	slushy machine
Model Number	WS26M-B007-B-Ov-us
Color	Gray
Capacity	68 Fluid Ounces (recommended working capacity)
Product Dimensions	7.19"L x 16.81"W x 16.93"H

Item Weight	29.1 Pounds
Material	Plastic
Operation Mode	Automatic
Special Features	Automatic Clean, Automatic Shut-Off, Low Noise, Portable
Product Care Instructions	Dishwasher Safe (removable components)

WARRANTY AND SUPPORT

Your WIE Slushie Machine comes with a warranty card included in the package. Please refer to the warranty card for detailed terms and conditions. For product support or inquiries, please contact WIE customer service through the details provided on the warranty card or user manual.