



[Manuals.plus](#) /

› [Merax](#) /

› Merax Modern Wood TV Stand (Model HA2031) User Manual

Merax HA2031

Merax Modern Wood TV Stand User Manual

Model: HA2031 | Brand: Merax

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Merax Modern Wood TV Stand. Please read this manual thoroughly before assembly and use to ensure proper installation and safe operation. Keep this manual for future reference.

The Merax Modern Wood TV Stand is designed to accommodate TVs up to 85 inches, featuring a faux marble-patterned veneer top, a curved silhouette, and a golden base. It includes four storage drawers with fluted profiles for practical storage solutions.

2. SAFETY INFORMATION

- Always follow assembly instructions carefully. Incorrect assembly can lead to instability and potential injury.
- Do not exceed the maximum weight capacity of the TV stand. The tabletop supports up to 220 lbs (100 kg), and each drawer supports up to 11 lbs (5 kg).
- Place the TV stand on a flat, level, and stable surface to prevent tipping.
- Keep small parts and packaging materials away from children and pets to avoid choking hazards.
- Periodically check all connections and fasteners to ensure they remain tight.
- Do not stand or climb on the TV stand.

3. PACKAGE CONTENTS

Before beginning assembly, ensure all components are present and undamaged. If any parts are missing or damaged, contact customer support.

- TV stand components (MDF panels, base, drawer parts)
- Hardware kit (screws, pins, connectors, drawer slides)
- Assembly instructions manual

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this TV stand. Each screw and pin is coded and clearly labeled to assist with the process. It is recommended to assemble the unit with at least two people.

Step-by-Step Assembly Guide


- 1. Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface (e.g., a blanket or carpet) to prevent scratches. Identify each part using the provided labels and the parts list in the separate assembly guide.
- 2. Assemble the Main Frame:** Begin by connecting the side panels to the bottom and top panels using the designated hardware. Ensure all connections are secure.
- 3. Install the Golden Base:** Attach the golden base to the bottom of the main frame. This 2.2-inch base provides stability.
- 4. Prepare Drawer Components:** Assemble the drawer boxes according to the instructions. The drawers feature smooth-painted panels with unique fluted profiles.
- 5. Install Drawer Slides:** Attach the premium slide hardware to both the TV stand frame and the assembled drawers. Ensure they are aligned correctly for smooth operation.
- 6. Insert Drawers:** Carefully slide the assembled drawers into their respective compartments. The angled pull handles are integrated beneath the door panels for easy opening.
- 7. Final Checks:** Once assembled, gently move the TV stand to its desired location. Verify that all screws are tightened and the unit is stable.



Figure 4.1: Fully assembled Merax Modern Wood TV Stand.


Sturdy Structure

With a 2.2-inch base, this piece offers reliable stability.



1

Crafted primarily from MDF



2

TV stand is built to last, with a tabletop that supports up to **110 LBS**



3

Drawers feature premium slide hardware

Figure 4.2: Structural details and weight capacity of the TV stand.

5. OPERATING INSTRUCTIONS

The Merax Modern Wood TV Stand is designed for practical use in living rooms and bedrooms.

- **Placing Your Television:** Carefully place your television on the center of the tabletop. Ensure the TV's base is fully supported and does not overhang the edges. The tabletop can accommodate TVs up to 85 inches.
- **Using the Storage Drawers:** The four drawers provide ample storage for media accessories, remote controls, and other items. Pull the drawers open using the angled handles located beneath the door panels. Push firmly to close.
- **Cable Management:** While not explicitly designed with cable cutouts, cables can be routed behind the unit. Ensure cables are not pinched or strained.

Generous Storage Capacity

The drawers feature angled pull handles beneath the door panels, ensuring easy opening and closing—blending practicality with sleek design.



Figure 5.1: Drawers open, demonstrating generous storage capacity.

6. MAINTENANCE

Proper care will extend the life and maintain the appearance of your TV stand.

- **Cleaning:** Wipe the surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish. For the faux marble top, use a mild, non-abrasive cleaner if necessary.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the veneer.
- **Protection:** Use coasters or protective pads under hot or wet items placed on the tabletop. Avoid direct sunlight exposure for prolonged periods to prevent fading.
- **Drawer Maintenance:** The fluted doors are water-resistant. If drawers become stiff, check the slides for debris and clean as needed.

Well-Finished Fluted Doors

Featuring four panels crafted with smooth painting, the drawers showcase unique fluted profiles.



Durability



Water Resistance



Easy Maintenance



Figure 6.1: Detail of the well-finished fluted doors.

7. TROUBLESHOOTING

If you encounter issues with your TV stand, refer to the following common solutions:

- **Wobbly Stand:** Ensure the TV stand is on a level surface. Check all assembly screws and tighten any that are loose.
- **Drawers Not Closing Smoothly:** Verify that the drawer slides are correctly installed and free of obstructions. Ensure the drawer contents are not interfering with closure.
- **Scratches or Dents:** Minor scratches on the veneer can sometimes be touched up with a furniture repair marker matching the finish. For significant damage, contact customer support.

8. SPECIFICATIONS

Feature	Specification
---------	---------------

Feature	Specification
Product Type	TV Stand
Model Number	HA2031
Overall Dimensions (L x W x H)	78.7" x 15.7" x 13.9" (199.9 cm x 39.9 cm x 35.3 cm)
Drawer Dimensions (W x D x H)	15.9" x 11.2" x 6.5"
Material	Engineered Wood Veneer (MDF)
Top Material	MDF with Faux Marble Veneer
Base Material	MDF
Color	Black with Gold Base
Number of Drawers	4
Tabletop Weight Capacity	220 lbs (100 kg)
Drawer Weight Capacity (each)	11 lbs (5 kg)
Overall Weight Capacity	221 lbs (100.2 kg)
Item Weight	89 lbs (40.4 kg)
Assembly Required	Yes

SIZE:INCH

Note:Manual measurements have been used and there may be some reasonable errors.



Figure 8.1: Detailed dimensions of the TV stand.

9. WARRANTY AND SUPPORT

For warranty information or assistance with your Merax Modern Wood TV Stand, please refer to the warranty card included with your purchase or contact Merax customer support directly. Please have your model number (HA2031) and purchase details ready when contacting support.