

[Manuals.plus](#) /

› [Siindoo](#) /

› Siindoo JH-ANC930Plus Hybrid ANC Wireless Headphone User Manual

Siindoo JH-ANC930PLUS

Siindoo JH-ANC930Plus Hybrid ANC Wireless Headphone User Manual

Model: JH-ANC930PLUS

Brand: Siindoo

1. INTRODUCTION

The Siindoo JH-ANC930Plus Hybrid ANC Wireless Headphones are designed to provide a superior audio experience with advanced features. These headphones combine hybrid active noise cancellation, a multi-functional magnetic touch control LED screen, and built-in 1GB MP3 storage for versatile use. They offer both wireless Bluetooth 5.3 and wired 3.5mm AUX connectivity, ensuring compatibility with a wide range of devices.



Image 1.1: Siindoo JH-ANC930Plus Hybrid ANC Wireless Headphones, showcasing the overall design and the integrated LED touch screen.

2. WHAT'S IN THE BOX

Upon opening the package, ensure all the following components are present:

- Siindoo JH-ANC930PLUS Headphone with LCD screen
- 0.5m Type-C charging cable
- 1.2m AUX cable
- Protective Case
- User Manual

WHAT'S IN THE BOX?



Image 2.1: All items included in the Siindoo JH-ANC930Plus retail package, including the headphones, cables, protective case, and user manual.

3. PRODUCT OVERVIEW

Familiarize yourself with the various parts and controls of your Siindoo JH-ANC930Plus headphones.

EASY OPERATION BUTTON



Image 3.1: Detailed view of the headphone's physical controls and ports, including the Power/Play/Pause button, Volume Up/Next Song, Volume Down/Previous Song, Type-C Charging Port, Charging Indicator, Calling Microphone, 3.5mm AUX Jack Port, ANC Button, Communication Pin, and Power Button.

3.1. Controls and Ports

- **Power ON/OFF / Music Play/Pause Button:** Located on the right earcup, this button controls power and music playback.
- **Volume Up / Next Song Button:** Adjusts volume up and skips to the next track.
- **Volume Down / Previous Song Button:** Adjusts volume down and goes to the previous track.
- **ANC Button:** Toggles Active Noise Cancellation and Transparency modes.
- **Type-C Charging Port:** Used for charging the headphones.
- **3.5mm AUX Jack Port:** For wired audio connection.
- **Charging Indicator:** Shows charging status.
- **Calling Microphone:** For voice calls and voice assistant.
- **Multifunctional Magnetic Touch Control LED Screen:** Provides access to various settings and functions via touch.

4. SETUP

4.1. Charging the Headphones

Before first use, fully charge your headphones. Connect the supplied Type-C charging cable to the charging port on the headphones and the other end to a USB power source (e.g., computer USB port, wall adapter). The charging indicator will show the charging status. A full charge provides approximately 40 hours of playtime with ANC enabled. A quick 10-minute charge can provide up to 2 hours of playtime.



Image 4.1: The headphones connected for charging, highlighting the 40 hours of playtime with ANC on and the quick charge feature.

4.2. Power On/Off

- **To Power On:** Press and hold the Power ON/OFF button until the indicator light illuminates.
- **To Power Off:** Press and hold the Power ON/OFF button until the indicator light turns off.

4.3. Bluetooth Pairing

The headphones use Bluetooth 5.3 for a stable wireless connection.

1. Ensure the headphones are powered on and in pairing mode (usually indicated by a flashing light).
2. On your device (smartphone, tablet, laptop), enable Bluetooth.

3. Search for "ANC930" or "Siindoo JH-ANC930Plus" in the list of available devices.
4. Select the headphones to connect. Once connected, the indicator light will stop flashing.

Note: Bluetooth connection is required for Active Noise Cancellation (ANC) functionality. ANC is not available when using the 3.5mm audio cable.

4.4. Wired Connection (AUX Mode)

To use the headphones in wired mode, connect one end of the 1.2m AUX cable to the 3.5mm AUX Jack Port on the headphones and the other end to your audio device's 3.5mm audio output. The headphones will automatically switch to wired mode.

4.5. APP Download and Connection

Enhance your experience by downloading the official JoyAudio APP. The APP allows for additional control and customization of your headphones.

1. Scan the QR code displayed on the headphone screen or visit the official download link:
<https://download.joygem.net/joyaudio> to download the JoyAudio APP.
2. Install the APP on your mobile phone.
3. Open the APP and follow the on-screen instructions to connect to your headphones. The APP may prompt you to scan a QR code on the headphone screen or select the device from a list (e.g., "ANC930" with Bluetooth address 46:98:0a:47:f7:fe).

Download the APP and Connection the Screen

Use your mobile phone to scan and download the app, then install on mobile.
After downloading APP, then to connect APP to screen




Image 4.2: Visual guide for downloading the JoyAudio APP via QR code and connecting it to the headphones for enhanced control.

4.6. Using the Built-in 1GB MP3 Memory

The headphones feature 1GB of internal storage, allowing you to store and play music directly without a connected device. Refer to the on-screen interface or the JoyAudio APP for instructions on how to transfer music files to the headphone's internal memory.

5. OPERATION

5.1. Multifunctional Magnetic Touch Control LED Screen

The integrated LED touch screen provides intuitive control over various headphone functions. Navigate the screen by swiping and tapping.

LED full-color touch screen Multiple practical functions

LCD full-color touch screen, answering incoming calls ,
Music playback and many headphones features



Image 5.1: A comprehensive display of the LED touch screen's interface, illustrating icons for music playback, volume, ANC modes, EQ adjustment, alarm, brightness, language, lock screen, wallpaper, light, weather, date/time, photo taking, liking, virtual fish game, and QR codes for APP and connection.

Key Screen Functions:

- **Music Playback:** Control play, pause, next/previous track.
- **Volume Adjustment:** Precisely adjust audio volume.
- **ANC Mode:** Switch between Hybrid Active Noise Cancellation and Transparency modes.
- **EQ Adjustment:** Customize sound equalization settings.
- **Alarm:** Set alarms directly from the headphones.
- **Brightness of Screen:** Adjust screen brightness (10 levels available).
- **Language Switch:** Select from 18 supported languages.
- **Lock Screen / Wallpaper:** Customize lock screen and choose from 3 wallpapers.
- **Light:** Control any integrated lighting features.
- **Weather Details:** View current weather information (requires APP connection).
- **Date & Time Setting:** Set the current date and time.

- **Take Photos:** Remote control for taking photos on a connected device.
- **Give a Like:** Functionality for social interaction or content liking.
- **Virtual Fish Game:** An integrated mini-game.
- **Connection QR Code / Jjay Audio QR Code:** For quick APP download and device pairing.

5.2. Active Noise Cancellation (ANC) and Transparency Mode

The Siindoo JH-ANC930Plus headphones feature professional hybrid active noise cancellation, reducing up to 33dB of ambient noise. The Transparency Mode allows you to hear your surroundings while still enjoying your audio.

- **Switching Modes:** Use the dedicated ANC button on the earcup or the touch screen interface to toggle between ANC On, Transparency Mode, and ANC Off.




Image 5.2: Demonstrates the effectiveness of hybrid active noise cancellation in various environments, such as blocking airplane engine noise, providing hearing protection, and aiding focus.

5.3. Audio Quality and Calls

Equipped with 40mm drivers, these headphones deliver a full range of frequencies, providing deep, powerful, and immersive sound. The built-in high-definition microphone ensures clear voice capture for calls, video conferences, and voice assistants.

Beamforming microphones focus on your voice and suppress background noise for clear communication.

5.4. Comfort and Design

The headphones are designed for extended wear with ultra-soft noise isolation padding and slow-rebound memory foam earcups. The adjustable lightweight headband accommodates various head shapes. The earcups feature 90° inward rotation and 120° inward folding for maximum comfort and portability.



Image 5.3: Illustrates the comfort-enhancing features of the headphones, including 90° swirling earcups, foldable design for portability, and an adjustable headband for a customized fit.

5.5. Sound Modes

The Siindoo JH-ANC930Plus offers five distinct sound modes to optimize your listening experience for different genres and preferences:

- Normal Mode
- Rock Mode
- Pop Mode
- Classical Mode

- **Jazz Mode**

These modes can be selected via the touch screen interface or the JoyAudio APP.

6. MAINTENANCE

To ensure the longevity and optimal performance of your Siindoo JH-ANC930Plus headphones, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use abrasive cleaners, alcohol, or chemical solvents. For the earcups, gently wipe with a slightly damp cloth if necessary, and allow to air dry completely before use.
- **Storage:** When not in use, store the headphones in the provided protective case to prevent dust accumulation and physical damage. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Moisture:** Do not expose the headphones to water or excessive moisture. If they get wet, dry them thoroughly before storing or using.
- **Handle with Care:** Avoid dropping the headphones or subjecting them to strong impacts. Do not twist or bend the cables excessively.

7. TROUBLESHOOTING

If you encounter issues with your headphones, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully using the provided Type-C cable.
Cannot pair via Bluetooth.	Headphones not in pairing mode; Bluetooth disabled on device; interference.	Ensure headphones are powered on and in pairing mode. Enable Bluetooth on your device. Move closer to the device and away from other wireless devices. Try restarting both devices.
No sound in wireless mode.	Not connected; volume too low; incorrect audio output selected.	Ensure headphones are successfully paired. Increase volume on both headphones and connected device. Check your device's audio output settings.
ANC function not working.	ANC is off; headphones in wired mode.	Press the ANC button to activate ANC. Ensure headphones are connected via Bluetooth, as ANC does not work in wired mode.
Touch screen unresponsive.	Temporary software glitch; screen lock enabled.	Restart the headphones. Check if the screen lock function is enabled on the touch screen.
Poor call quality.	Microphone obstructed; weak Bluetooth connection; environmental noise.	Ensure the microphone is clear. Move closer to your connected device. Use ANC to reduce environmental noise.

8. SPECIFICATIONS

Feature	Detail
Model Name	JH-ANC930PLUS (siindoo-ANC5)
Brand	Siindoo

Feature	Detail
Noise Control	Hybrid Noise Cancellation (up to 33dB reduction)
Connectivity Technology	Wired (3.5mm Jack), Wireless (Bluetooth 5.3)
Frequency Response	20000 Hz
Sensitivity	108 dB
Impedance	32 Ohm
Control Type	Touch Control (Magnetic LED Screen)
Built-in Memory	1GB (for MP3)
Battery Life (ANC On)	Approx. 40 hours
Charging Time	Approx. 2.49 Hours
Material	ABS, Metal, Plastic, Silicone, Stainless Steel
Item Weight	1.37 Pounds (approx. 621 grams)
Package Dimensions	8.66 x 7.8 x 3.15 inches
Manufacturer	JIUHU
First Available Date	June 25, 2025

9. WARRANTY AND SUPPORT

Siindoo products are manufactured by JIUHU. For warranty information and technical support, please refer to the warranty card included in your product packaging or visit the official Siindoo website. Please retain your proof of purchase for warranty claims. For further assistance, you may also contact the seller directly through the platform where the product was purchased.

© 2025 Siindoo. All rights reserved.
This manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question