

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [iTouchless](#) /

› [iTouchless 13.2 Gallon SoftStep 2.0 Kitchen Trash Can \(Model PC13RSS-N1\) Instruction Manual](#)

## iTouchless PC13RSS-N1

# iTouchless 13.2 Gallon SoftStep 2.0 Kitchen Trash Can

Model: PC13RSS-N1

## INTRODUCTION

---

Thank you for choosing the iTouchless 13.2 Gallon SoftStep 2.0 Kitchen Trash Can. This manual provides essential information for the proper setup, operation, and maintenance of your new trash can. Please read these instructions thoroughly before use and retain them for future reference.



Image: The iTouchless 13.2 Gallon SoftStep 2.0 Kitchen Trash Can positioned next to a kitchen counter, demonstrating its sleek design and space-saving profile.

## SAFETY INFORMATION

---

- Do not immerse the product in water or other liquids.
- Keep the product away from direct heat sources.
- Ensure the trash can is placed on a stable, level surface to prevent tipping.
- Do not allow children to play with the trash can or its components.
- Use only the recommended AbsorbX odor filters for optimal performance.
- Avoid placing heavy objects on the lid.

## PACKAGE CONTENTS

---

Verify that all items are present in the package:

- 1 x Stainless Steel Trash Can Unit
- 1 x Removable Inner Bucket
- 1 x AbsorbX Odor Filter

## SETUP

1. **Unpack the Unit:** Carefully remove all components from the packaging.
2. **Insert Inner Bucket:** Place the removable inner bucket into the stainless steel outer shell. Ensure it sits securely at the bottom.
3. **Install AbsorbX Odor Filter:** Open the lid of the trash can. Locate the filter compartment on the underside of the lid. Insert the AbsorbX odor filter into the compartment. Close the compartment cover securely.



Image: A hand demonstrates the installation of the AbsorbX odor filter into its designated slot on the underside of the trash can lid, designed to eliminate odors.

4. **Insert Trash Bag:** Line the inner bucket with a standard 13-gallon trash bag. Utilize the bag retention system by tucking the excess bag material into the designated holes or slots on the inner bucket to secure it in place and prevent slippage.



Image: A visual representation of the Tuck & Hold Bag Retention System, illustrating how to secure a trash bag within the inner bucket to prevent it from falling.

## OPERATING INSTRUCTIONS

The iTouchless SoftStep 2.0 trash can is designed for ease of use and hygiene.

- **Using the Step Pedal:** Gently press the foot pedal to open the lid. The lid will open smoothly and silently. Release the pedal to allow the lid to close automatically.




Image: An overview of the trash can's features, including the built-in odor filter, removable inner bucket, stay-open lid function, and the durable foot pedal.

- **Soft Close Lid:** The lid features a quiet close mechanism, preventing slamming and extending the product's lifespan.



Image: A graphic detailing the Soft & Silent Close Lid, highlighting the renewable air damper system responsible for its quiet operation.

- **Stay-Open Lid:** For longer tasks, the lid can be manually lifted past a certain point to engage a stay-open function. To close, gently push the lid down.
- **Odor Control System:** The integrated AbsorbX odor filter helps neutralize unpleasant odors, maintaining a fresh environment. Replace the filter every 3 months for optimal performance.

### Product Overview Video

Your browser does not support the video tag.

Video: This video demonstrates the key features of the iTouchless SoftStep trash can, including how to use the foot pedal, install the AbsorbX odor filter, change the trash bag, and highlights the soft-close lid and easy portability.

### MAINTENANCE

- **Cleaning the Exterior:** Wipe the stainless steel exterior with a soft, damp cloth and a mild cleaner. Avoid abrasive cleaners or scouring pads, which can damage the finish. The stainless steel is smudge-resistant and dent-resistant.

# PREMIUM GRADE STAINLESS STEEL




Image: An exploded view illustrating the multi-layered construction of the premium grade stainless steel, highlighting its wear-resistant, anti-rust, and fingerprint-proof qualities for easy cleaning.

- **Cleaning the Inner Bucket:** The removable inner bucket can be easily lifted out for cleaning. Wash it with soap and water, then rinse thoroughly and dry before returning it to the trash can.
- **Replacing the AbsorbX Odor Filter:** The AbsorbX odor filter should be replaced approximately every 3 months, or sooner if odors persist. Follow the installation steps in the Setup section to replace the filter.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Lid does not close softly.	Mechanism obstruction or damage.	Check for any obstructions around the lid hinge. Ensure the trash can is on a level surface. If the issue persists, contact customer support.
Unpleasant odors persist.	Odor filter needs replacement or improper installation.	Replace the AbsorbX odor filter. Ensure the filter is correctly installed in its compartment. Clean the inner bucket thoroughly.
Foot pedal is stiff or not working.	Debris or mechanism issue.	Check for any debris obstructing the pedal mechanism. Ensure the trash can is not pressed against a wall or cabinet that could impede pedal movement.

Problem	Possible Cause	Solution
Inner bucket is difficult to remove/insert.	Improper alignment or debris.	Ensure the inner bucket is aligned correctly with the outer shell. Check for any debris or trash bag material caught between the bucket and the shell.

## SPECIFICATIONS

**Brand:** iTouchless

**Model Number:** PC13RSS-N1

**Capacity:** 13.2 Gallons (50 Liters)

**Color:** Silver

**Opening Mechanism:** Step-On

**Material:** Plastic, Stainless Steel

**Product Dimensions:** 16.9"L x 14.5"W x 26.4"H (42.9 cm L x 36.8 cm W x 67.1 cm H)




Image: A detailed diagram illustrating the length, width, and height dimensions of the iTouchless trash can for accurate placement and fit.

**Item Weight:** 17.36 pounds (7.89 Kilograms)

**Special Features:** Dent Resistant, Odor Seal, Removable Bucket, Smudge Resistant

**Indoor/Outdoor Usage:** Indoor

## **WARRANTY INFORMATION**

---

For detailed warranty information regarding your iTouchless SoftStep 2.0 Kitchen Trash Can, please refer to the official iTouchless website or contact their customer support directly. Warranty terms and conditions may vary.

## **CUSTOMER SUPPORT**

---

If you have any questions, require assistance, or need to order replacement parts, please visit the official iTouchless website or contact their customer service department. Contact information can typically be found on the manufacturer's website or on the product packaging.