

[Manuals.plus](#) /

> [Anbuy](#) /

> Anbuy 9-Drawer Scalloped Dresser Instruction Manual (Model: 13.8D x 63.1W x 29.1H)

Anbuy 13.8D x 63.1W x 29.1H (9 Drawers)

Anbuy 9-Drawer Scalloped Dresser Instruction Manual

Model: 13.8D x 63.1W x 29.1H (9 Drawers)

INTRODUCTION

Thank you for choosing the Anbuy 9-Drawer Scalloped Dresser. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

IMPORTANT SAFETY INFORMATION

- Always assemble the dresser on a soft, clean surface to prevent scratches.
- Ensure all parts are present and undamaged before assembly. Do not proceed with assembly if any parts are missing or damaged.
- Use the provided anti-tip kit to securely anchor the dresser to a wall. This is crucial to prevent serious injury from tipping furniture.
- Do not allow children to climb on or play with the dresser.
- Observe the weight limits: The top surface supports up to 120 lbs, and each drawer supports up to 36 lbs.
- Keep small parts and packaging materials away from children.

PACKAGE CONTENTS

Before assembly, verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer support.

- Dresser Frame Components
- 9 Drawer Boxes
- 9 Drawer Fronts with Scalloped Design
- 9 Drawer Knobs
- 6 Solid Wood Legs
- Hardware Pack (screws, dowels, cam locks, drawer glides)

- Anti-Tip Kit
- Assembly Instructions

SETUP AND ASSEMBLY

Assembly typically requires two adults. Please follow the numbered steps carefully. Tools required: Phillips head screwdriver, hammer (optional), and a drill with an extended bit (recommended for leg attachment).

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface. Refer to the parts list in your instruction booklet to identify each piece.
2. **Assemble the Main Frame:** Follow the diagrams in your instruction booklet to connect the side panels, back panel, and top panel using the provided hardware. Ensure all cam locks are tightened securely.
3. **Install Drawer Glides:** Attach the drawer glides to the inside of the dresser frame. Ensure they are level and aligned correctly for smooth drawer operation.



Image: Detail of a smooth-gliding drawer mechanism.

4. **Assemble Drawers:** Construct each of the nine drawer boxes. Attach the drawer fronts with the scalloped design to the assembled drawer boxes. Secure the drawer knobs to the center of each drawer front.
5. **Attach Legs:** Carefully attach the six solid wood legs to the bottom of the dresser frame. **Note:** Some users have reported difficulty with leg attachment. Using a drill with an extended bit may be necessary to ensure secure fastening. Ensure the legs are firmly attached and stable.




Image: Detail of the solid wood gourd-shaped leg.

6. **Insert Drawers:** Gently slide each assembled drawer into its designated slot in the dresser frame. Test each drawer for smooth operation.
7. **Install Anti-Tip Kit:** This is a critical safety step. Follow the instructions provided with the anti-tip kit to secure the dresser to a wall stud. This prevents the dresser from tipping over, which can cause serious injury.

For visual reference, here is an image of the fully assembled dresser:



Image: The Anbuy 9-Drawer Scalloped Dresser, fully assembled and decorated.



PRODUCT DIMENSIONS



Image: Product dimensions diagram for the Anbuy 9-Drawer Scalloped Dresser.

OPERATING INSTRUCTIONS

The Anbuy 9-Drawer Scalloped Dresser is designed for convenient storage in various rooms.

- **Drawer Use:** Gently pull and push the drawers to open and close them. The smooth-gliding mechanisms ensure easy access to your stored items. Avoid forcing drawers if they feel stuck.
- **Weight Distribution:** Distribute weight evenly across the drawers. Do not overload individual drawers beyond 36 lbs.
- **Top Surface:** The top surface can be used for displaying decorative items, lamps, or other personal belongings, up to a maximum weight of 120 lbs. Ensure items are placed stably to prevent them from falling.



Image: Detail of the unique scalloped drawer front design.

MAINTENANCE AND CARE

Proper care will help maintain the appearance and longevity of your dresser.

- **Cleaning:** Wipe the surface with a soft, slightly damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Humidity:** Maintain a stable humidity level in the room to prevent wood warping or cracking.
- **Regular Checks:** Periodically check all hardware connections and tighten them if necessary to ensure stability.



Image: Detail of the rounded top edge for enhanced safety and aesthetics.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Drawers do not slide smoothly or get stuck.	Misaligned drawer glides; overloaded drawer; debris in glides.	Check that drawer glides are correctly installed and aligned. Reduce drawer contents if overloaded. Clean glides of any obstructions.
Dresser feels unstable or wobbly.	Loose hardware; uneven floor; legs not securely attached.	Tighten all assembly hardware. Ensure the dresser is on a level surface. Re-check leg attachment and tighten screws, using a drill if necessary. Ensure anti-tip kit is installed.
Difficulty attaching legs during assembly.	Pilot holes not deep enough; incorrect screw type; insufficient tool.	Ensure you are using the correct screws. A drill with an extended bit is highly recommended for secure leg attachment. If pilot holes seem insufficient, carefully deepen them slightly.
Missing or damaged parts.	Packaging error; shipping damage.	Do not proceed with assembly. Contact Anbuy customer support immediately for replacement parts.

PRODUCT SPECIFICATIONS

- **Brand:** Anbuy
- **Model:** 13.8D x 63.1W x 29.1H (9 Drawers)
- **Product Dimensions:** 13.8"D x 63.1"W x 29.1"H
- **Color:** Green
- **Room Type:** Bedroom, Living Room

- **Assembly Required:** Yes
- **Top Weight Capacity:** 120 lbs
- **Drawer Weight Capacity:** 36 lbs per drawer
- **Material:** MDF, Solid Wood Legs

WARRANTY AND SUPPORT

Anbuy is committed to providing quality products. For any questions regarding assembly, missing parts, or product issues, please contact Anbuy customer support. Our team is available to provide professional assistance. Please refer to your purchase documentation for specific warranty details.