

Manuals.plus /

› PULITUO /

› PULITUO Cordless Leaf Blower Instruction Manual (Model B0FFMMRZVD)

PULITUO B0FFMMRZVD

PULITUO Cordless Leaf Blower Instruction Manual

Model: B0FFMMRZVD

1. INTRODUCTION

Thank you for choosing the PULITUO Cordless Leaf Blower. This manual provides essential information for the safe operation, assembly, maintenance, and troubleshooting of your new tool. Please read this manual thoroughly before first use and retain it for future reference.

2. SAFETY INSTRUCTIONS

Always follow basic safety precautions to reduce the risk of fire, electric shock, and personal injury when using power tools.

- **Read All Instructions:** Familiarize yourself with the controls and proper use of the appliance.
- **Wear Eye Protection:** Always wear safety glasses or goggles to protect your eyes from debris.
- **Wear Hearing Protection:** Prolonged exposure to noise can cause hearing damage.
- **Dress Properly:** Do not wear loose clothing or jewelry that could get caught in moving parts. Wear sturdy footwear.
- **Keep Area Clear:** Ensure children, bystanders, and pets are at a safe distance (at least 50 feet) from the operating area.
- **Inspect Before Use:** Check for loose parts, damaged components, or any condition that may affect safe operation.
- **Use in Dry Conditions:** Do not operate the blower in wet conditions or rain.
- **Remove Battery When Not in Use:** Always remove the battery pack when assembling, adjusting, cleaning, or storing the blower.
- **Avoid Accidental Starting:** Ensure the switch is in the off position before inserting the battery pack.
- **Use Only Approved Batteries and Chargers:** Use only PULITUO 4.0Ah batteries and the provided charger.

3. PACKAGE CONTENTS

Verify that all items are present upon opening the package:

- PULITUO Cordless Leaf Blower Unit
- 2 x 4.0Ah Lithium-Ion Batteries
- Battery Charger
- Concentrator Nozzle
- Extension Nozzle
- User Manual (this document)



Image: The PULITUO Cordless Leaf Blower, including the main unit, two 4.0Ah batteries, and the battery charger, as typically found in the package.

4. ASSEMBLY

The leaf blower requires minimal assembly before use.

1. **Attach the Blower Tube:** Align the blower tube with the outlet on the main unit. Push and twist until it locks securely into place.
2. **Attach the Nozzle (Optional):** For concentrated airflow, attach the concentrator nozzle to the end of the blower tube. For extended reach, attach the extension nozzle first, then the concentrator nozzle.
3. **Insert Battery:** Slide a fully charged 4.0Ah battery pack into the battery slot on the base of the blower until it clicks into place. Ensure it is firmly seated.



Image: The leaf blower shown in both its short configuration for general use and its long configuration with an extension tube for precise cleaning.

5. BATTERY CHARGING

The PULITUO Cordless Leaf Blower comes with two 4.0Ah Lithium-Ion batteries and a dedicated charger.

1. **Connect Charger:** Plug the charger into a standard electrical outlet. The indicator light on the charger may illuminate.
2. **Insert Battery:** Slide the battery pack into the charger. Ensure proper alignment.

3. **Monitor Charging:** The charger's indicator light will change to show the charging status (e.g., red for charging, green for fully charged).
4. **Remove Battery:** Once fully charged, remove the battery from the charger. Disconnect the charger from the power outlet when not in use.

Note: It is recommended to fully charge batteries before first use. Overheat protection is built into the battery for safety.

6. OPERATION

Operating your leaf blower is straightforward. Always ensure the battery is fully charged and securely installed.

1. **Starting the Blower:** Press the power button to turn on the blower.
2. **Adjusting Speed:** The blower features 3 variable speeds. Use the speed adjustment button to cycle through the levels:
 - **Level 1 (90 MPH):** Suitable for clearing light dust and debris.
 - **Level 2 (120 MPH):** Ideal for sweeping leaves and grass clippings.
 - **Level 3 (150 MPH):** For heavier tasks such as moving fluffy snow or dense piles of leaves.
3. **Using the Blower:** Direct the nozzle towards the material you wish to move. Use a sweeping motion to gather debris.
4. **Stopping the Blower:** Press the power button again to turn off the blower.

3 ADJUSTABLE SPEEDS

Easy-Start Power Button Allows
Continuously Working
Speed Button for 3-Level Airflow



Image: Close-up of the leaf blower's handle showing the power button and the 3-level speed adjustment controls.



Image: Examples of the leaf blower's versatility, demonstrating its use for lawn care, dust cleaning, assisting with barbecues, blowing snow, and drying vehicles.

7. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your leaf blower.

- **Cleaning:** After each use, remove the battery and clean the exterior of the blower with a damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure air vents are clear of debris.
- **Storage:** Store the blower in a dry, secure location away from children. Remove the battery pack before storing for extended periods.
- **Battery Care:** Store batteries in a cool, dry place. Do not store fully discharged batteries. Recharge them periodically if not used for a long time.
- **Inspection:** Periodically check all fasteners for tightness. Inspect the blower tube for cracks or damage.

8. TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Blower does not start	Battery not inserted correctly Battery discharged Power button not pressed	Ensure battery is fully seated Charge the battery Press the power button firmly
Reduced airflow	Blower tube or nozzle obstructed Battery low on charge	Clear any obstructions Recharge or replace battery
Short operating time	Battery not fully charged Operating at highest speed continuously Battery nearing end of life	Ensure battery is fully charged Use lower speeds when possible Consider replacing battery
Blower stops unexpectedly	Battery overheat protection activated Battery fully discharged	Allow battery to cool down Recharge or replace battery

9. SPECIFICATIONS

Feature	Detail
Brand	PULITUO
Model	B0FFMMRZVD
Power Source	Battery Powered
Voltage	20 Volts
Battery Type	Lithium Ion (2 x 4.0Ah included)
Maximum Air Speed	150 MPH
Maximum Air Volume	180 CFM
Motor Speed	17000 RPM
Operating Time	30-60 minutes (depending on speed)
Weight	3.4 LBS (blower unit only), 7.48 pounds (item weight with batteries)
Product Dimensions	38"L x 7"W x 7"H (with extension)
Special Features	Adjustable Speed, Adjustable Tube Length, Lightweight, Rechargeable, Turbo

10. WARRANTY AND CUSTOMER SUPPORT

The PULITUO Cordless Leaf Blower is backed by a 12-month warranty, ensuring durability and reliability. For any issues, questions, or support needs, please contact PULITUO customer service. Refer to the contact information provided with your purchase or visit the official PULITUO website for assistance.

