

[Manuals.plus](#) /

› [Tangkula](#) /

› Tangkula Farmhouse TV Stand User Manual

Tangkula tv stand-10745-HV

Tangkula Farmhouse TV Stand User Manual

Model: tv stand-10745-HV

1. INTRODUCTION AND PRODUCT OVERVIEW

The Tangkula Farmhouse TV Stand is designed to enhance your living space with both style and functionality. This entertainment center accommodates flat screen televisions up to 80 inches and provides extensive storage solutions for your media devices and accessories. Its farmhouse aesthetic, featuring transparent doors with diamond patterns, makes it a focal point in any room.



Image: The Tangkula Farmhouse TV Stand in antique white, supporting a large television, with decorative items and media devices in its compartments.

This stand features two pull-out drawers, two spacious cabinets, and an open compartment, ensuring all your entertainment essentials are neatly organized. Supported by seven raised metal legs, it offers enhanced stability and durability. A convenient cable management hole helps maintain a tidy appearance by concealing wires.

2. KEY FEATURES

- **Accommodates Large TVs:** Designed for flat screen TVs up to 80 inches, with a spacious 71" x 14" tabletop.
- **Ample Storage:** Includes 2 drawers, 2 cabinets, and an open compartment for media devices, books, and decorations.
- **Sturdy Construction:** Supported by 7 metal legs with non-slip foot pads for stability and floor protection.
- **Farmhouse Aesthetic:** Features transparent doors with intricate diamond patterns for a charming decorative touch.
- **Cable Management:** Equipped with a cable hole to keep wires organized and out of sight.
- **User-Friendly Design:** Includes magnetic catches for doors, smooth metal drawer slides, and convenient handles for ease of use.



Image: The TV stand positioned in a modern living room, demonstrating its suitability for various interior designs.

Ample Storage & Display Space



Image: An overhead view illustrating the various storage options: a wide tabletop, an open central compartment, two pull-out drawers, and two side cabinets.

Cable Management Hole

Keep messy wires hidden at the back




Image: A detailed view of the cable management hole located at the back of the TV stand, designed to keep wires tidy.



Transparent Doors with Diamond Patterns

Provide an aesthetic display of the contents inside

User-friendly Accessories



Magnetic Catch



Smooth Metal Drawer Slides



Convenient Handles

Image: Illustrations of the magnetic catch for secure door closure, smooth metal drawer slides for easy access, and ergonomic handles for effortless opening.

3. SPECIFICATIONS

Attribute	Value
Color	Antique White
Material	Engineered Wood, MDF, PC, Metal
Overall Dimensions (L x W x H)	71" x 14" x 18"
Dimensions of Compartment (L x W x H)	34.5" x 12.5" x 5"
Inner Size of Drawer (L x W x H)	15" x 11" x 4"
Inner Size of Cabinet (L x W x H)	17" x 13" x 11.5"

Attribute	Value
Raised Height (Legs)	5"
Net Weight	73 lbs
Weight Capacity of Tabletop	110 lbs
Weight Capacity of Compartment	22 lbs
Weight Capacity of Cabinet	33 lbs
Weight Capacity of Drawer	11 lbs
Number of Drawers	2
Number of Shelves	1 (open compartment)
Country of Origin	Malaysia

Dimensions



Weight Capacity
of Tabletop



Image: A comprehensive diagram illustrating all key dimensions of the TV stand and its internal storage areas, along with weight capacities.

7 Sturdy Metal Legs Enable a Firm Support



Non-slip Foot Pads



Reinforced Connection

Image: A visual representation emphasizing the seven robust metal legs, complete with non-slip foot pads and reinforced connection points for enhanced stability.

Suitable for Flat Screen TVs up to 80"



Image: A visual guide demonstrating the TV stand's capacity to hold flat screen TVs ranging from 60 to 80 inches, highlighting the 71" x 14" tabletop dimensions.

4. SETUP AND ASSEMBLY

The Tangkula Farmhouse TV Stand requires assembly. Please follow the instructions provided in the included assembly guide carefully. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

- 1. Unpack and Verify:** Carefully unpack all components and hardware. Compare the contents with the parts list in your assembly manual to ensure all pieces are present and undamaged.
- 2. Prepare Tools:** Gather any necessary tools as specified in the assembly guide (e.g., screwdriver, hammer).
- 3. Follow Step-by-Step Instructions:** Adhere strictly to the numbered steps in the assembly manual. Pay close attention to diagrams and illustrations.
- 4. Secure Connections:** Ensure all screws, bolts, and fasteners are tightened securely, but do not overtighten to avoid damaging the material.
- 5. Install Legs:** Attach the 7 metal legs to the base of the TV stand as instructed, ensuring they are firm and stable.

6. **Final Check:** Once assembled, gently test the stability of the TV stand before placing any items on it.

For detailed, step-by-step assembly instructions, please refer to the dedicated assembly manual included in your package.

5. OPERATING INSTRUCTIONS

The Tangkula Farmhouse TV Stand is designed for straightforward use. Once assembled, it serves as a stable and organized platform for your entertainment system.

- **Placing Your TV:** Carefully place your flat screen TV (up to 80 inches) on the center of the tabletop. Ensure the TV's base is fully supported and centered for optimal stability.
- **Organizing Media Devices:** Utilize the open compartment for media devices such as DVD players, gaming consoles, or soundbars.
- **Using Drawers and Cabinets:** Store remote controls, cables, DVDs, or other accessories in the two pull-out drawers. The two side cabinets with transparent doors are ideal for displaying decorative items or storing larger media components.
- **Cable Management:** Route all power cords and signal cables through the designated cable management hole at the back of the stand to maintain a clean and organized appearance.

6. MAINTENANCE AND CARE

Proper care and maintenance will help preserve the appearance and longevity of your Tangkula Farmhouse TV Stand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Immediately wipe up any spills with a dry cloth to prevent moisture damage.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the finish.
- **Heat and Moisture:** Keep the TV stand away from direct heat sources and areas of high humidity.
- **Regular Checks:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Moving the Stand:** When moving the TV stand, always lift it rather than dragging it to prevent damage to the legs and floor.

7. TROUBLESHOOTING

If you encounter any issues with your Tangkula Farmhouse TV Stand, please refer to the following common troubleshooting tips:

- **Instability/Wobbling:**
 - Ensure all assembly screws and bolts are securely tightened.
 - Verify that the TV stand is placed on a flat, level surface. Adjust non-slip foot pads if necessary to compensate for uneven flooring.
- **Drawers Sticking/Not Sliding Smoothly:**
 - Check that the drawer slides are correctly installed and aligned.
 - Ensure no foreign objects are obstructing the drawer slides.

- Lightly lubricate the metal drawer slides with a silicone-based lubricant if needed.

- **Doors Not Closing Properly:**

- Check the alignment of the door hinges and adjust if necessary.
- Ensure the magnetic catches are properly aligned with the door and frame.

- **Missing Parts:**

- Double-check the packaging and all corners for small parts.
- If parts are genuinely missing, contact customer support with your purchase details.

For issues not covered here, please contact Tangkula customer support.

8. WARRANTY AND CUSTOMER SUPPORT

Tangkula is committed to providing high-quality products. For any questions, concerns, or assistance with your TV stand, please reach out to our customer support team.

- **Protection Plans:** Extended protection plans are available for purchase separately to cover your product beyond the standard warranty. Options include 2-Year and 3-Year Protection Plans.
- **Returns:** This product is eligible for 30-day easy returns. Please refer to your purchase platform's return policy for details.
- **Contact Support:** For direct assistance, please visit the official Tangkula store or contact customer service through your point of purchase.

Visit the [Tangkula Store](#) for more information and product offerings.