

[Manuals.plus](#) /

› [YATINEY](#) /

› YATINEY Small TV Stand DS11DBB Instruction Manual

YATINEY DS11DBB

YATINEY Small TV Stand Instruction Manual

Model: DS11DBB

INTRODUCTION

Thank you for purchasing the YATINEY Small TV Stand. This manual provides essential information for the safe assembly, operation, and maintenance of your new TV stand. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image: The YATINEY Small TV Stand, showcasing its design and potential use in a living room environment.

SAFETY INFORMATION

To ensure safe use of this product, please observe the following:

- This TV stand includes an **anti-tip feature** designed to prevent accidental tipping. Ensure this feature is properly installed and secured to a wall stud or other appropriate anchor point as per the detailed assembly instructions.
- The stand is equipped with **adjustable feet** for stability on uneven surfaces. Adjust these feet to ensure the stand is level and stable before placing any items on it.
- Do not exceed the maximum weight capacity of **110 pounds (50 kg)**. Overloading can lead to instability and potential injury.
- Keep small parts and packaging materials away from children during assembly to prevent choking hazards.
- Always lift with assistance when moving the assembled stand to prevent injury.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- 1 x TV Stand (main frame and panels)
- 1 x Accessory Package (screws, bolts, tools, adjustable feet)
- 1 x Light Strip (if applicable to your model variant)
- 1 x User Manual (this document)

If any parts are missing or damaged, please contact customer support immediately.

SPECIFICATIONS




Image: A detailed diagram illustrating the dimensions of the YATINEY Small TV Stand, including height, width, and depth, as well as internal shelf and drawer measurements.

Brand	YATINEY
-------	---------

Model Number	DS11DBB
Color	Black
Material	Particleboard, Metal, Non-Woven Fabric
Product Dimensions (D x W x H)	11.8"D x 43.3"W x 15.7"H (30cm D x 110cm W x 40cm H)
Item Weight	8.1 kg
Maximum Weight Capacity	110 pounds (50 kg)
Number of Drawers	2 (Fabric)
Number of Shelves	3 (including top surface and bottom mesh shelf)
Mounting Type	Floor Mount
Additional Features	RGB LED Light Strip, Sturdy Metal Mesh Shelf, Adjustable Feet, Anti-tip Feature

ASSEMBLY INSTRUCTIONS

Detailed illustrated instructions are provided with the product. Please follow them carefully. General steps include:

- Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Verify all parts listed in the 'Package Contents' section are present.
- Assemble Frame:** Attach the metal frame components using the provided screws and tools. Ensure all connections are secure but do not overtighten until the entire frame is assembled.
- Install Panels and Shelves:** Secure the particleboard panels and mesh shelves to the assembled frame.
- Insert Drawers:** Assemble the fabric drawers and slide them into their designated compartments.
- Attach Adjustable Feet:** Screw the adjustable feet into the bottom of the stand.
- Install Anti-Tip Kit:** Secure the anti-tip device to the back of the TV stand and to a wall stud using the provided hardware. This step is crucial for safety.
- Install LED Light Strip:** If included, attach the LED light strip according to its specific instructions.
- Final Check:** Ensure all screws are tightened, the stand is stable, and the anti-tip device is properly installed.

Note: Two people are recommended for assembly to ensure stability and ease of handling.

OPERATING INSTRUCTIONS

Once assembled, your YATINEY Small TV Stand is ready for use:

- Placement:** Position the TV stand on a flat, level surface. Adjust the feet as necessary to eliminate any wobbling.
- Weight Distribution:** Place your television centrally on the top surface. Distribute other items evenly across the shelves and drawers to maintain balance. Do not exceed the maximum weight capacity of 110 pounds (50 kg).
- Cable Management:** Utilize the open design and mesh shelves to organize cables for your electronic devices, preventing tangles and ensuring proper ventilation.
- Drawer Use:** The fabric drawers are suitable for storing lightweight items such as remote controls, media accessories, or small personal belongings. Avoid placing heavy or sharp objects that could damage the fabric.
- LED Light (if applicable):** If your model includes an LED light strip, connect it to a power source and use the provided controller to adjust settings as desired.

MAINTENANCE

Regular maintenance will help prolong the life and appearance of your TV stand:

- **Cleaning:** Wipe the surfaces with **dry cloth**. For stubborn marks, a slightly damp cloth followed by a dry cloth can be used. Avoid harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Dusting:** Regularly dust all surfaces, including the metal frame and mesh shelves, to prevent buildup.
- **Check Connections:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary to maintain structural integrity.
- **Fabric Drawers:** The fabric drawers can be spot cleaned with a mild detergent and damp cloth. Allow to air dry completely.
- **Avoid Moisture:** Do not expose the stand to excessive moisture or direct sunlight, which can cause warping or fading.

TROUBLESHOOTING

If you encounter issues with your YATINEY Small TV Stand, consider the following:

- **Stand is Wobbly:**
 - Ensure the stand is on a flat, level surface.
 - Adjust the individual feet at the bottom of the stand until it is stable.
 - Check all assembly screws and bolts to ensure they are fully tightened.
- **Parts Do Not Fit:**
 - Review the assembly instructions carefully to ensure you are using the correct parts for each step.
 - Do not force parts together. If a part does not fit, re-examine the diagram and ensure proper orientation.
- **LED Light Not Working:**
 - Ensure the light strip is properly connected to its power source and controller.
 - Check if the power outlet is functional.
 - Refer to the separate instructions provided with the light strip for specific troubleshooting.
- **Missing Parts:**
 - Double-check all packaging materials.
 - Contact YATINEY customer support with your model number and a description of the missing part.

CUSTOMER SUPPORT

For further assistance, questions, or to report missing/damaged parts, please contact YATINEY customer support through the retailer's platform or the official YATINEY website. Please have your model number (DS11DBB) and purchase information ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question