Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YOZLNFO ST-718A

YOZLNFO ST-718A Portable 2-in-1 Garment Steamer and Iron User Manual

Model: ST-718A | Brand: YOZLNFO

1. Introduction

Thank you for choosing the YOZLNFO ST-718A Portable 2-in-1 Garment Steamer and Iron. This versatile appliance is designed for efficient wrinkle removal and garment care, offering both dry ironing and steaming functions. Its compact and lightweight design makes it ideal for home use and travel. Please read this manual thoroughly before operation to ensure safe and optimal performance.

2. Safety Instructions

- Always ensure the appliance is connected to a 110-120V power outlet. This product is designed for use in regions such as the US, Mexico, Taiwan, and Japan.
- Do not immerse the appliance in water or other liquids.
- Keep the appliance out of reach of children and pets.
- Exercise caution when handling the hot soleplate and steam. Avoid direct contact with skin.
- Always unplug the steamer from the power outlet before filling or emptying the water tank, and when not in use.
- Use only distilled or demineralized water to prevent mineral buildup and extend product life.
- Do not operate the appliance if the cord or plug is damaged.
- Place the steamer on the provided heat-insulated base when not actively ironing or steaming to prevent damage to surfaces.

3. Product Overview

The YOZLNFO ST-718A combines the functionality of a garment steamer and a dry iron in a compact form factor. Key features include a rotating steam head, 5 adjustable fabric settings, rapid heat-up, and an anti-drip design.



Figure 1: YOZLNFO ST-718A Portable 2-in-1 Garment Steamer and Iron.




Figure 2: The compact design of the steamer allows for easy packing in luggage, resembling a standard water bottle.



Figure 3: The non-stick anti-scalding safety soleplate ensures safe placement and prevents fabric damage.

4. Setup

4.1 Filling the Water Tank

1. Ensure the steamer is unplugged from the power outlet.
2. Rotate the steam head to the right to access the water tank opening.

3. Open the rubber tab covering the water reservoir.
4. Using the provided 110ml measuring cup, carefully pour distilled or demineralized water into the tank. Do not overfill.
5. Close the rubber tab securely and rotate the steam head back to the vertical position.



Figure 4: Illustration of filling the 110ml water tank with the measuring cup.

4.2 Powering On

- Plug the steamer into a compatible 110-120V power outlet.

- The LED display will illuminate, and the indicator light will flash, signifying that the appliance is heating up.
- Wait approximately 15 seconds for the steamer to reach the desired temperature. The indicator light will become steady when ready for use.

5. Operating Instructions

5.1 Selecting Fabric Settings

The steamer features 5 adjustable settings for various fabric types. Once the indicator light is steady, press the power button to cycle through the settings:

- Dry Ironing
- Silk
- Synthetic Fiber
- Cotton & Linen
- Woolen Fabric



Figure 5: The LED display indicates the selected fabric setting for optimal care.

5.2 Steaming Garments

- Hang the garment on a hanger or hold it taut.
- Select the appropriate fabric setting.
- Hold the steamer upright, ensuring the soleplate is not in direct contact with the fabric unless dry ironing.
- Press the steam trigger to release steam. Move the steamer slowly over the wrinkled areas.
- The steam volume ranges from 13g to 20g/min, effectively penetrating fabrics.



Figure 6: The steamer produces powerful steam for quick wrinkle removal.

5.3 Dry Ironing

- Place the garment on a flat, heat-resistant surface.
- Select the 'Dry Ironing' setting.
- Gently press the ceramic soleplate onto the fabric and move it across the wrinkled areas.
- The large 15.7-square-inch dry ironing panel ensures efficient crease removal.

5.4 Rotating Steam Head

The steam head can be rotated 90 degrees to switch between flat ironing and hanging steaming modes, providing flexibility for different garment types and preferences.



Figure 7: The rotating head allows for versatile flat and hanging ironing options.

6. Maintenance

6.1 Cleaning

- Ensure the steamer is unplugged and completely cooled down before cleaning.
- Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- For the ceramic soleplate, gently wipe with a damp cloth. Avoid scratching the surface.
- If mineral deposits accumulate in the water tank, fill it with a mixture of 50% water and 50% white vinegar, let it sit for 30 minutes, then empty and rinse thoroughly.

6.2 Storage

- Empty any remaining water from the tank after each use.
- Allow the appliance to cool completely before storing.
- Store the steamer in a cool, dry place, preferably in its original packaging or a protective bag.
- Ensure the power cord is neatly wrapped and not kinked.

7. Troubleshooting

Problem	Possible Cause	Solution
No steam output	Water tank is empty or low. Appliance not heated.	Refill water tank. Wait 15 seconds for heat-up.
Water leakage/dripping	Water tank overfilled. Rubber tab not closed properly. Steamer not fully heated.	Do not overfill. Ensure tab is sealed. Wait for indicator light to be steady.
Appliance not turning on	Not plugged in correctly. Power outlet issue.	Check power connection. Try a different outlet.
Wrinkles not removing effectively	Incorrect fabric setting. Not enough steam.	Select higher steam setting or use dry ironing. Ensure tank is full.

8. Specifications

Feature	Detail
Brand	YOZLNFO
Model Number	ST-718A
Power	1200 Watts
Voltage	110-120 Volts
Heat-up Time	15 Seconds
Steam Output	13g to 20g/min
Water Tank Capacity	110ml
Dry Ironing Panel Size	15.7 square inches
Product Dimensions	8.8"L x 2.83"W x 3.85"H

Feature	Detail
Item Weight	1.81 pounds

9. Warranty and Support

For warranty information and customer support, please refer to the contact details provided in your product packaging or visit the official YOZLNFO website. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FFMY7ZS8

More documents and user manuals: **https://manuals.plus/**