

Buqpow 500222684

Buqpow Ice Fishing Shelter Anchor User Manual

Model: 500222684

Brand: Buqpow

1. PRODUCT OVERVIEW

The Buqpow Ice Fishing Shelter Anchor is a durable and versatile accessory designed to secure outdoor shelters, tents, and other equipment in various ground conditions, including ice, sand, and snow. Made from high-quality alloy steel, these anchors provide strong holding power to prevent your shelter from being dislodged by wind or adverse weather.

Key Features:

- **High Bearing Capacity:** Designed to firmly secure shelters on various surfaces like ice and sand, ensuring stability against wind and rain.
- **Durable Material:** Constructed from alloy steel, these tent pegs are resistant to rust and breakage, ensuring long-term use even in harsh winter conditions.
- **User-Friendly Design:** Features a handle, deep thread, and pointed tip for easy insertion and removal. The design allows for stable placement in ground, sand, or snow.
- **Versatile Application:** Suitable for ice fishing tents, ground anchors, snow, and grassland applications, including securing trampolines and swings.

2. PACKAGE CONTENTS

Upon opening the package, please verify that all components are present and undamaged.

- 4 x Buqpow Ice Fishing Shelter Anchors (Silver, Alloy Steel)



Image 2.1: Four Buqpow Ice Fishing Shelter Anchors, showing their T-handle design and threaded shaft.

3. SETUP AND INSTALLATION

Follow these steps to properly install your Buqpow Ice Fishing Shelter Anchors:

1. **Identify Anchor Points:** Determine the optimal locations around your tent, shelter, or equipment where anchors are needed for maximum stability.
2. **Prepare the Surface:** Ensure the chosen surface (ice, snow, sand, or soil) is clear of large debris.
3. **Insert the Anchor:**
 - **Manual Method:** Hold the anchor by its T-handle. Place the pointed, threaded tip onto the desired spot. Apply downward pressure and rotate the handle clockwise to screw the anchor into the ground. Continue until the anchor is firmly seated.
 - **Drill Method (Recommended for Ice/Hard Ground):** For faster and easier installation, especially in ice or hard-packed snow, an appropriate drill adapter (not included) can be used with a power drill. Attach the anchor to the drill adapter and use the drill to screw the anchor into the surface.

WIDE APPICATION

Screw in ice fishing tent, ground anchors, snow and grassland.



Image 3.1: An anchor being screwed into a sheet of ice using a drill adapter, demonstrating its wide application.



Image 3.2: An anchor being screwed into a snowy surface with a power drill, showing the ease of installation.

4. **Secure Your Equipment:** Once the anchor is firmly in place, attach the ropes, straps, or guy lines from your tent, shelter, or trampoline to the T-handle of the anchor. Ensure a snug and secure connection.
5. **Check Stability:** Gently pull on your secured equipment to ensure the anchors are holding firmly and the setup is stable.

4. OPERATING INSTRUCTIONS / USAGE

The Bugpow Ice Fishing Shelter Anchors are designed for various outdoor applications:

- **Ice Fishing Shelters:** Use to anchor ice shanties and shelters securely to the ice, preventing them from shifting or blowing away in windy conditions.
- **Camping Tents:** Ideal for securing camping tents in soft ground, sand, or snow where traditional pegs may not hold.
- **Trampolines:** Can be used as ground anchors for trampolines to prevent them from moving or tipping over, especially in high winds.
- **Outdoor Swings and Play Equipment:** Provides additional stability for outdoor play structures.
- **General Outdoor Securing:** Useful for securing tarps, canopies, and other outdoor equipment.

EASILY SCREW IN TRAMPOLINE

Drill in Your Heavy Duty Spiral Ground Anchors in Seconds.



Image 4.1: An anchor securing a tent or trampoline, demonstrating its effectiveness in various outdoor settings.



Image 4.2: A collage illustrating the diverse applications of the anchors, including securing ice fishing tents, camping tents, swings, and trampolines.

Removal: To remove the anchor, rotate the T-handle counter-clockwise while applying slight upward pressure. For stubborn anchors, a wrench or drill (with adapter) can assist in unscrewing.

5. MAINTENANCE

Proper maintenance will extend the lifespan of your Buqpow Ice Fishing Shelter Anchors:

- **Cleaning:** After each use, especially in muddy, sandy, or salty conditions, clean the anchors thoroughly with water to remove any dirt or debris.
- **Drying:** Ensure the anchors are completely dry before storage to prevent rust, despite their alloy steel construction.
- **Storage:** Store the anchors in a dry place, away from direct sunlight and extreme temperatures. A storage bag (not included) can help keep them organized and prevent damage to other gear.
- **Inspection:** Periodically inspect the anchors for any signs of wear, bending, or damage. While designed to be durable, extreme forces can cause deformation.

6. TROUBLESHOOTING

If you encounter issues while using your anchors, consider the following:

- **Anchor is difficult to screw in:**
 - Ensure the tip is aligned correctly with the surface.
 - Apply firm, consistent downward pressure while rotating.
 - For very hard ground or thick ice, consider using a power drill with an appropriate adapter.
 - If the ground is extremely rocky, try a different spot.
- **Anchor does not hold firmly:**
 - Ensure the anchor is screwed in completely until the T-handle is close to the surface.
 - Verify that the surface material (e.g., very loose sand) is suitable for anchoring. You may need to use additional anchors or a different anchoring method in extremely loose conditions.
 - Check that the ropes/straps are securely attached to the anchor.

7. SPECIFICATIONS

Attribute	Detail
Brand	Buqpow
Model Number	500222684
Material Type	Alloy Steel
Color	Silver
Package Quantity	4 pieces

8. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Buqpow Ice Fishing Shelter Anchors, please contact the seller or manufacturer directly through the platform where the purchase was made. Please refer to your purchase receipt for specific warranty details, if applicable.

Keep your product model number (500222684) handy when contacting support for faster assistance.

© 2025 Buqpow. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question