

[Manuals.plus](#) /

› [ComfyCorner](#) /

› ComfyCorner 16 Gallon Dual Compartment Stainless Steel Trash Can Instruction Manual

ComfyCorner XC007

ComfyCorner 16 Gallon Dual Compartment Stainless Steel Trash Can

Model: XC007

INTRODUCTION

Thank you for choosing the ComfyCorner 16 Gallon Dual Compartment Stainless Steel Trash Can. This manual provides essential information for the proper setup, operation, and maintenance of your new trash can. Please read these instructions carefully before use and retain them for future reference.

This dual-compartment bin is designed for efficient waste sorting, featuring two 8-gallon inner buckets, soft-close lids, foot pedals for hands-free operation, and built-in odor control boxes. Its stainless steel construction offers durability and an anti-fingerprint finish.



Image: ComfyCorner 16 Gallon Dual Trash Can in Black Stainless Steel.

SAFETY INFORMATION

- Keep hands and fingers clear of the lid when closing to prevent pinching.
- Do not allow children to play with the foot pedals or lids.
- Ensure the trash can is placed on a stable, level surface to prevent tipping.
- Avoid placing excessively heavy items in the inner buckets to prevent damage.
- Do not use abrasive cleaners or harsh chemicals on the stainless steel surface.

PACKAGE CONTENTS

Verify that all components are present:

- 1 x ComfyCorner Dual Compartment Stainless Steel Outer Shell
- 2 x Removable Inner Buckets (8 Gallons each)
- 2 x Lids with Odor Control Boxes

PRODUCT OVERVIEW

The ComfyCorner Dual Compartment Trash Can is designed for convenience and hygiene. Key features include:

- **Dual Compartments:** Two separate 8-gallon bins for easy sorting of trash and recyclables.
- **Soft-Close Lids:** Lids close silently and gently, preventing noise and wear.
- **Odor Control Boxes:** Integrated compartments in each lid for air fresheners or charcoal filters (not included) to manage odors.
- **Foot Pedals:** Hands-free operation for hygienic waste disposal.
- **Removable Inner Buckets:** Easy to lift out, empty, and clean.
- **Side Handles:** Convenient handles for moving the unit.
- **Anti-Fingerprint Stainless Steel:** Durable and easy-to-clean exterior.

Product Dimensions



* 43



* 25




Image: Front view of the dual trash can, highlighting the two foot pedals.



Image: Top view illustrating the dual compartment design for waste separation.

SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove all components from the packaging.
2. **Position:** Place the outer stainless steel shell in your desired location. Ensure it is on a flat, stable surface.

3. **Insert Inner Buckets:** Place each of the two removable inner buckets into their respective compartments within the outer shell.
4. **Line with Bags:** Line each inner bucket with an appropriate size trash bag (8-gallon capacity recommended for each bucket). Ensure the bag edges are tucked neatly under the rim of the inner bucket.
5. **Odor Control (Optional):** If desired, insert an air freshener or charcoal filter into the designated odor control box located on the underside of each lid.



Image: Steps for handling and lining the removable inner buckets.

OPERATING INSTRUCTIONS

1. **Opening the Lid:** Gently press down on the corresponding foot pedal located at the base of the trash can. The lid will open smoothly.
2. **Disposing Waste:** Place your waste or recyclables into the open inner bucket.

3. **Closing the Lid:** Release the foot pedal. The soft-close mechanism will ensure the lid closes quietly and slowly without slamming.
4. **Stay-Open Feature:** For extended tasks, you can manually lift the lid to a 90-degree angle, and it will stay open. Push it down gently to close.

Dual Compartment Design

60L trash lid has two independently compartments for trash and recyclables, making it easy to sort waste.



Image: Visual representation of the soft-close lid in operation.

Official Product Video: Odor Control and Features


Your browser does not support the video tag.

Video: This video demonstrates the features of the ComfyCorner 60L Trash Can, including the built-in odor control compartment and the smooth operation of the lids and pedals.

MAINTENANCE AND CLEANING

Regular cleaning will help maintain the appearance and functionality of your trash can.

- **Exterior Cleaning:** Wipe the stainless steel exterior with a soft, damp cloth and a mild detergent. For best results and to maintain the anti-fingerprint finish, dry immediately with a clean, soft cloth. Avoid abrasive cleaners or steel wool.
- **Inner Buckets:** Remove the inner buckets and wash them with warm, soapy water. Rinse thoroughly and dry completely before returning them to the outer shell.
- **Odor Control Boxes:** Replace air fresheners or charcoal filters in the odor control boxes as needed to maintain freshness.



• Premium Stainless Steel

• Rust-Resistant Layer

• Antioxidant Layer



Fingerprint-resistant



Easy to Clean

Image: Illustration of the multi-layered stainless steel construction, highlighting its fingerprint-resistant and easy-to-clean properties.

TROUBLESHOOTING

- **Lid not closing softly:** Check for any obstructions around the hinge mechanism or on the rim of the inner bucket. Ensure the inner buckets are seated correctly.

- **Foot pedal stuck:** Inspect the pedal mechanism for debris or misalignment. Gently clear any obstructions.
- **Unpleasant odors:** Replace the trash bags regularly. Ensure the odor control boxes contain fresh air fresheners or charcoal filters. Clean the inner buckets thoroughly.
- **Unit unstable:** Ensure the trash can is placed on a flat, even surface.

SPECIFICATIONS

Feature	Detail
Brand	ComfyCorner
Model Number	XC007
Capacity	16 Gallons (2 x 8 Gallons)
Product Dimensions	20.1"L x 12.7"W x 26"H
Single Inner Bucket Size	9.1"L x 10.6"W x 24.2"H
Material	Stainless Steel (exterior), ABS Plastic (inner buckets)
Opening Mechanism	Step-On (Foot Pedal)
Special Features	Soft-Close Lid, Odor Control Box, Anti-fingerprint Finish, Side Handles
Color	Black



Image: Detailed product dimensions for the dual trash can and its inner buckets.

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the retailer's return policy or contact ComfyCorner customer service directly. Keep your purchase receipt as proof of purchase.

© 2025 ComfyCorner. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question