

ORRD 3 Drawer Fluted Dresser

ORRD 3 Drawer Fluted Dresser Instruction Manual

Model: 3 Drawer Fluted Dresser

1. INTRODUCTION

Thank you for choosing the ORRD 3 Drawer Fluted Dresser. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

2. SAFETY INFORMATION

To ensure safe use of this product, please observe the following guidelines:

- **Anti-Tip Device:** It is highly recommended to secure the dresser to a wall using an anti-tip device (if included) to prevent serious injury from tipping.
- **Weight Limits:** Do not exceed the maximum weight capacity for the top surface or individual drawers. Overloading can compromise stability and cause damage.
- **Assembly:** Assemble the dresser on a soft, clean surface to prevent scratches. Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten fasteners as needed.
- **Placement:** Place the dresser on a level surface to prevent wobbling and ensure proper drawer function.
- **Children Safety:** Keep small parts and packaging materials away from children during assembly. Do not allow children to climb on or play with the dresser.

3. PACKAGE CONTENTS

Before assembly, verify that all components listed in the packaging's parts list are present and undamaged. If any parts are missing or damaged, please contact customer support.

Note: A detailed parts list is provided within the product packaging.

4. ASSEMBLY INSTRUCTIONS (SETUP)

Assembly of the ORRD 3 Drawer Fluted Dresser requires careful attention to the provided step-by-step instructions. All necessary hardware and tools (if specific tools are required beyond standard household items) are included in the package.

1. Unpack all components and lay them out on a clean, soft surface to avoid scratches.

2. Identify each part by comparing it with the parts list in your product manual.
3. Follow the numerical sequence of steps provided in the enclosed assembly guide.
4. Ensure all connections are firm and secure. Do not overtighten screws.
5. Attach the anti-tip device to the dresser and wall as instructed to prevent tipping.

For visual reference, here are the overall dimensions and weight capacities:



Figure 1: Dresser Dimensions and Weight Capacities

Detailed installation instructions are provided within the product package to ensure a smooth assembly process.

5. OPERATING INSTRUCTIONS (USAGE)

The ORRD 3 Drawer Fluted Dresser is designed for versatile storage in various rooms.

- **Drawer Operation:** Gently pull and push the drawers using the knobs. The sturdy drawer slides ensure smooth operation. Avoid forcing drawers open or closed.
- **Storage:** Each drawer provides ample space for daily essentials. Distribute weight evenly within drawers to maintain balance and prevent strain on the slides.
- **Versatile Placement:** This dresser can function as a bedside table, an end table for a sofa, or a storage solution in a bedroom, living room, hallway, or closet.



Figure 2: Dresser with Drawers Open, showcasing storage capacity.

6. MAINTENANCE

Proper care will extend the life and appearance of your dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals, abrasive cleaners, or excessive moisture, which can damage the engineered wood finish.
- **Spills:** Clean spills immediately to prevent staining or damage to the finish.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Humidity:** Maintain a stable humidity level in the room to prevent warping or cracking of the wood material.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.

7. TROUBLESHOOTING

If you encounter any issues with your dresser, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Dresser wobbles or is unstable.	Uneven floor; loose fasteners.	Ensure the dresser is on a level surface. Check and tighten all assembly screws.
Drawers do not slide smoothly.	Misaligned drawer slides; obstruction in the track; overloaded drawer.	Check that drawer slides are correctly installed and aligned. Remove any obstructions. Reduce the weight in the drawer.
Gaps between drawers or frame.	Loose assembly; uneven floor.	Re-check all assembly steps and tighten fasteners. Ensure the dresser is on a level surface.

If the problem persists, please contact customer support for assistance.

8. SPECIFICATIONS

- **Brand:** ORRD
- **Model:** 3 Drawer Fluted Dresser
- **Color:** Green
- **Material:** Engineered Wood
- **Product Dimensions (Overall):** 15.66"D x 22.99"W x 27.55"H
- **Drawer Internal Dimensions:** Approximately 19.5" W x 11.8" D x 3.11" H
- **Number of Drawers:** 3
- **Assembly Required:** Yes
- **Maximum Top Surface Weight Capacity:** 50 lbs
- **Maximum Drawer Weight Capacity:** 20 lbs per drawer

9. WARRANTY AND SUPPORT

ORRD is committed to providing quality products and excellent customer service. While specific warranty details are provided with your purchase, generally, our products are covered against manufacturing defects.

For any questions, missing parts, or assistance with assembly or troubleshooting, please contact our customer support team. We are dedicated to ensuring your satisfaction and offer exceptional pre-sales and after-sales services.

Customer Support: Please refer to the contact information provided in your product packaging or visit the official ORRD website for support.

Online Resources: You may find additional support and product information on the [ORRD Store on Amazon](#).