



Manuals.plus /

- › FEICE /
- › FEICE FK036 Men's Analog-Digital Chronograph Sport Watch User Manual

FEICE FK036

FEICE FK036 Men's Analog-Digital Chronograph Sport Watch User Manual

Model: FK036

INTRODUCTION

Thank you for choosing the FEICE FK036 Analog-Digital Chronograph Sport Watch. This manual provides detailed instructions for setting up, operating, and maintaining your watch to ensure optimal performance and longevity. Please read this manual thoroughly before using your watch.

PRODUCT OVERVIEW

The FEICE FK036 watch features a sophisticated multi-layered stereo dial design with both analog and digital displays, powered by a precise Japanese quartz movement. It includes various functions such as chronograph, alarm, calendar, and a backlight for visibility in low light conditions. The watch is constructed with an alloy case, mineral-strengthened glass, and a genuine cowhide leather strap.



Figure 1: Front view of the FEICE FK036 watch, showcasing its analog and digital displays.



Figure 2: The watch displaying its luminous hands and markers for easy reading in the dark.

COMPONENTS AND CONTROLS

Familiarize yourself with the watch's buttons and crown:



Figure 3: Diagram illustrating the watch's components and control buttons.

- **Crown:** Used for setting the analog time.
- **A Key (LIGHT):** Activates the backlight for the digital display.
- **B Key (MODE):** Cycles through digital display modes (Time, Alarm, Chronograph, Date).
- **C Key (START):** Used to start/stop chronograph, increase values during setting, or view day.
- **D Key (RESET):** Used to reset chronograph, decrease values during setting, or view date.

SETUP INSTRUCTIONS

1. Setting Analog Time

1. Pull the crown out to the first position.
2. Rotate the crown to adjust the analog hour and minute hands to the desired time.
3. Push the crown back in to its normal position to start the analog timekeeping.

2. Setting Digital Time and Date

1. Press the **B Key (MODE)** repeatedly until the digital display shows the time setting mode (usually indicated by flashing digits).
2. Press the **C Key (START)** to increase the flashing value or the **D Key (RESET)** to decrease it.

3. Press the **B Key (MODE)** again to move to the next setting item (e.g., minutes, 12H/24H mode, month, day, year).
4. Repeat steps 2 and 3 until all desired settings are adjusted.
5. Once all settings are complete, press the **B Key (MODE)** to exit the setting mode. If no operation is performed for one minute, the watch will automatically exit the setting mode.

3. Switching 12H/24H Mode

While in digital time display mode, press the **C Key (START)** to toggle between 12-hour and 24-hour formats.

OPERATING INSTRUCTIONS

1. Chronograph Function

1. Press the **B Key (MODE)** until the digital display shows the chronograph mode.
2. Press the **C Key (START)** to begin timing.
3. Press the **C Key (START)** again to pause timing.
4. Press the **D Key (RESET)** to reset the chronograph to zero.

2. Alarm Function

1. Press the **B Key (MODE)** until the digital display shows the alarm setting mode.
2. Use the **C Key (START)** and **D Key (RESET)** to set the desired alarm time.
3. Press the **B Key (MODE)** to confirm and activate the alarm.

3. Backlight

Press the **A Key (LIGHT)** to illuminate the digital display for a few seconds.

4. Day and Date Display

In normal time mode, the day is displayed at the top of the dial and the date at the bottom digital display. You can also use the **C Key (START)** and **D Key (RESET)** to quickly view the day and date in certain digital modes.

MAINTENANCE

1. Water Resistance

This watch is water-resistant up to 3 ATM (30 meters), meaning it can withstand splashes, rain, and brief immersion in water. It is **not suitable** for bathing, swimming, diving, or any activities involving hot water or steam, as this can compromise the seals.



Figure 4: The watch demonstrating its water resistance against splashes.

2. Cleaning

Wipe the watch case and crystal with a soft, dry cloth. For the leather strap, avoid excessive moisture and harsh chemicals. Clean gently with a damp cloth if necessary and allow to air dry.

3. Battery

The watch uses a Japanese quartz movement, which is battery-powered. When the watch stops or the digital display fades, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and function.

4. Strap Care

The genuine cowhide leather strap is durable but can be affected by sweat, water, and direct sunlight. To prolong its life, avoid prolonged exposure to these elements. If the strap gets wet, dry it thoroughly before wearing.



Figure 5: The FEICE FK036 watch worn on a wrist, highlighting the leather strap.

TROUBLESHOOTING

- **Analog hands not moving:** Check if the crown is pushed in completely. If it is, the battery may need replacement.
- **Digital display is blank or dim:** The battery may be low. Replace the battery.
- **Digital time is incorrect:** Follow the "Setting Digital Time and Date" instructions to reset the time.
- **Chronograph not functioning correctly:** Reset the chronograph by pressing the D Key. If issues persist, re-check the digital time settings.
- **Water ingress:** If water enters the watch, stop using it immediately and take it to a professional watch repair service.

SPECIFICATIONS

| Feature | Detail |
|------------------|--|
| Model Number | FK036 |
| Movement | Japanese Quartz (Analog-Digital) |
| Case Diameter | 48 mm |
| Case Thickness | 16.7 mm |
| Watch Weight | 117 g |
| Strap Material | Genuine Cowhide Leather |
| Strap Width | 24 mm |
| Water Resistance | 3 ATM (30 meters) |
| Crystal Material | Mineral-strengthened glass |
| Functions | Chronograph, Alarm, Calendar, Backlight, Luminescent Hands |

OFFICIAL PRODUCT VIDEO

Video 1: An official product video demonstrating the features and water resistance of the FEICE Men's Waterproof Chronograph Quartz Watch.

WARRANTY AND SUPPORT

FEICE watches are manufactured to high-quality standards. For any questions, concerns, or warranty claims, please contact the FEICE customer support team. Refer to your purchase documentation for specific warranty terms and contact information. We are committed to providing a satisfactory solution within 24 hours.