

[Manuals.plus](#) /

› [MAXDONE](#) /

› MAXDONE A4 Laminator Machine User Manual

MAXDONE A4 Laminator Machine with Trimmer

MAXDONE A4 Laminator Machine User Manual

Model: A4 Laminator Machine with Trimmer

1. INTRODUCTION

This manual provides instructions for the safe and efficient operation of your MAXDONE A4 Laminator Machine. Please read all instructions carefully before use and retain this manual for future reference. This laminator supports both hot and cold lamination modes and is suitable for A4, A5, and A6 size documents.



Image: The MAXDONE A4 Laminator Machine, showcasing its compact design and the various accessories included in the kit.

2. SAFETY INSTRUCTIONS

- Always place the laminator on a stable, flat surface.
- Keep the laminator away from water or other liquids.
- Do not insert objects other than laminating pouches into the machine.
- Ensure proper ventilation around the machine during operation.
- Unplug the laminator when not in use or before cleaning.
- Keep out of reach of children.

3. PACKAGE CONTENTS

Your MAXDONE A4 Laminator Machine package includes:

- 1 x 9-inch Laminator Machine
- 20 x Thermal Laminating Sheets (2*A4, 3*A5, 15*A6)
- 1 x Paper Trimmer
- 1 x User Manual

Next-Gen Core Smarter Protection

Dual Rollers System



NTC Temperature Control



Mirror-finish Design



RoHS FC UK CA CE UL

- Smooth Laminating
- Overheating Protection
- Overvoltage Protection
- Short-Circuit Protection



Image: The laminator machine along with the included paper trimmer and various sizes of laminating sheets.

4. PRODUCT OVERVIEW

The MAXDONE A4 Laminator features a dual roller system and NTC temperature control for consistent lamination. It includes a simple control panel for mode selection and an ABS quick release button for jam resolution.

Jam Release in 3 Steps

2. keep pushing the "ABS" button.



Image: An internal view highlighting the dual roller system and NTC temperature control, along with safety certifications.

5. SETUP

1. Unpack the laminator and place it on a clean, stable, and heat-resistant surface.
2. Ensure there is enough space behind the machine for laminated items to exit freely.
3. Plug the power cord into a suitable electrical outlet.

6. OPERATING INSTRUCTIONS

6.1. Hot Lamination Mode

1. Turn on the laminator and select the "HOT" mode.
2. Wait approximately 90 seconds for the machine to warm up. The indicator light will turn green when ready.
3. Place your document inside a thermal laminating pouch, ensuring it is centered and there is a small margin around the edges.
4. Insert the sealed edge of the pouch into the laminator's input slot. The machine will automatically feed the pouch through.

5. Once the pouch exits the machine, allow it to cool on a flat surface.

Hot lamination is ideal for diplomas, menus, photos, certificates, documents, and invoices. Compatible with 80-100 micron pouches.

Cold & Thermal lamination



Cold Laminating:

- ✓ DIY Bookmark
- ✓ Old pictures
- ✓ Old documents

Note: The cold mode needs special sheets (not included).



Hot Laminating:

- ✓ Certificates
- ✓ Documents
- ✓ Invoices

Image: A visual guide demonstrating the four steps for easy hot lamination, from preheating to finishing.

6.2. Cold Lamination Mode

1. Turn on the laminator and select the "COLD" mode. No preheating is required for this mode.
2. Place your document inside a self-adhesive cold laminating pouch (not included).
3. Insert the sealed edge of the pouch into the laminator's input slot.
4. The machine will feed the pouch through, sealing it without heat.

Cold lamination is suitable for heat-sensitive items like thermal receipts or delicate documents. It requires self-adhesive pouches, which are sold separately.

Fast and Efficient

Improve Work Efficiency by **80%**

The image compares the Maxdone 9-inch Cold Thermal Laminator Machine (left) with a generic laminator (right). The Maxdone machine is shown with a large stack of documents and a certificate being laminated. It features a red 'MAXDONE' logo and a 'VS' graphic. The generic laminator is shown with a smaller stack of documents and a photo being laminated. A snail icon is used to represent the slower speed of the generic laminator.

Maxdone 9-inch Cold Thermal Laminator Machine	Generic Laminator
Lamination speed: 320mm/min	Lamination speed: 250mm/min
Preheating time: 90s	Preheating time: 3 min

The Maxdone machine is marked with a green checkmark, indicating it is the preferred option. The generic laminator is marked with a red 'X', indicating it is less efficient.

Image: An illustration comparing the applications and requirements for both cold and hot laminating modes.

6.3. Official Product Video: Maxdone 9 Inch Cold Thermal Laminator Machine

Video: A demonstration of the Maxdone 9-inch laminator machine in operation, showcasing its ease of use for both cold and thermal lamination.

7. MAINTENANCE

- **Cleaning:** To clean the rollers and remove any adhesive residue, run a blank piece of paper through the laminator periodically.
- **Cooling:** For optimal performance and longevity, allow the laminator to cool for at least 15 minutes after approximately 2 hours of continuous use.

8. TROUBLESHOOTING

8.1. Paper Jam

If a paper jam occurs:

1. Turn off the laminating machine.

2. Press and hold the "ABS" quick release button located on the side of the machine.
3. Gently pull the jammed paper or pouch out of the input slot.

The ABS button is designed to protect your documents from damage during a jam.



Image: A three-step guide illustrating how to resolve a paper jam using the ABS quick release button.

8.2. Overheating Protection

The MAXDONE laminator is equipped with an NTC temperature control system that prevents overheating, ensuring safer operation and extending the life of the device.

9. SPECIFICATIONS

Brand	MAXDONE
Model	A4 Laminator Machine with Trimmer
Product Dimensions	13.3"L x 5.11"W x 4.33"H
Laminating Width Maximum	9 Inches

Laminating Speed	320 mm/min
Warm-Up Time	90 Seconds
Number of Rollers	2



Image: The laminator's dimensions are highlighted, emphasizing its lightweight and portable design for various paper sizes.

10. WARRANTY AND SUPPORT

Your MAXDONE A4 Laminator Machine comes with a **2-Year Replacement Promise**. For any inquiries or support needs, MAXDONE offers **24-hour friendly customer service** and a **30-day exchange service**. Please refer to the warranty card included in your package for detailed terms and conditions or contact MAXDONE customer support directly.