

[Manuals.plus](#) /

› [VOWNER](#) /

› VOWNER 63" Folding Dining Table Set and 71" Tall Sideboard Cabinet User Manual

VOWNER RS-145+RS-143

VOWNER 63" Folding Dining Table Set and 71" Tall Sideboard Cabinet User Manual

Model: RS-145+RS-143

INTRODUCTION

Thank you for choosing the VOWNER 63" Folding Dining Table Set and 71" Tall Sideboard Cabinet. This versatile furniture piece is designed to maximize space in smaller living areas, offering a combination of dining, storage, and utility functions. Please read this manual carefully before assembly and use to ensure proper operation and longevity of your product.

IMPORTANT SAFETY INFORMATION

For your safety and to prevent damage to the product, please adhere to the following guidelines:

- Do not overload the table or shelves. Refer to the specifications for weight limits.
- Ensure the anti-tip design is properly engaged and secured to a wall to prevent the tall pantry from tipping, especially in households with children or pets.
- Always use the lockable wheels on the dining table to prevent accidental movement during use.
- Keep electrical cords from the power outlet clear of water and heat sources.
- Assemble the product on a soft, clean surface to avoid scratches.
- Periodically check all fasteners and re-tighten as necessary.

PACKAGE CONTENTS

Your VOWNER Folding Dining Table Set and Sideboard Cabinet comes in two packages. Please verify all parts are present before beginning assembly.

Package A: Sideboard Cabinet Components

Includes parts for the 71" tall sideboard cabinet, such as cabinet panels, shelves, drawer components, and hardware for assembly. This package also contains the power outlet unit.

Package B: Folding Dining Table and Stools Components

Includes parts for the 63" folding dining table, its support legs with lockable wheels, and the four accompanying stools.

Hardware for these components is also included.

**One
Person
Can
Easily
Unfold**

Only 4 steps
to fully expand



**1.Lift the tabletop
up wards**



**2.Pull out the legs to
the fixed position**




**3.Continue to pull out, open
the other half, and secure it**



**4.Take out the stools and
lock the wheels**

Image: Product dimensions for Package A, showing the sideboard cabinet with measurements for height (70.8"), width (31.5"), and depth (15.7"). It highlights the upper cabinet, microwave shelf, drawer, and lower storage area.

Product Size



Package B

Image: Product dimensions for Package B, illustrating the folding dining table in various configurations (folded, half-expanded, fully expanded) with measurements for length (63" fully expanded), width (29.5"), and height (29.5"). Also shows the dimensions of the stools.

SETUP AND ASSEMBLY

Assembly is required for both the sideboard cabinet and the folding dining table. It is recommended to have two people for assembly. Please follow the detailed instructions provided in the separate assembly guide included with your packages. Ensure all parts are accounted for before starting.

Key Assembly Steps:

1. Unpack all components from both packages and lay them out on a clean, soft surface to prevent scratches.
2. Assemble the main frame of the sideboard cabinet, ensuring all connections are secure.
3. Install the internal shelves and drawer slides for the sideboard.
4. Attach the power outlet unit to the designated area on the sideboard.
5. Assemble the folding dining table, including its support legs and lockable wheels.
6. Assemble the four individual stools.

7. Secure the anti-tip device for the sideboard cabinet to a wall as per the assembly guide.

Three Usage Modes

Suitable for various scenarios



◀ **All folded**

Expand half ▶



◀ **All expanded**



Image: The sideboard cabinet with its upper doors open revealing adjustable shelves, a microwave compartment, and a pull-out drawer for storage. The power outlet is visible on the side.

Ours-More Stable



8 × Lockable 360° wheels
Two metal support legs

Others-Easy to Shake



4 × wheels + 4 × Fragile feet
One wooden support leg

Image: A close-up comparison highlighting the stability of the VOWNER table's support structure, featuring 8 lockable 360° wheels and two metal support legs, contrasted with a less stable design from another product that uses fewer wheels and a wooden support leg.

OPERATING INSTRUCTIONS

Folding and Unfolding the Dining Table:

The dining table offers three usage modes to adapt to your space and needs:

1. **Full-Folded Mode:** The table is completely folded and stored within the sideboard cabinet, maximizing floor space.



Image: The VOWNER dining table set in its full-folded configuration, showing the table neatly tucked away into the sideboard cabinet, with the stools stored underneath.

2. **Half-Folded Mode:** One side of the table is extended, providing a compact workspace or dining area for 1-2 people.



Image: The VOWNER dining table set in its half-folded configuration, with one side of the table extended, suitable for smaller meals or as a compact desk.

3. **All-Expanded Mode:** Both sides of the table are extended, creating a spacious dining surface for 4-6 guests.



Image: The VOWNER dining table set fully expanded, showcasing its capacity to comfortably seat 4-6 people, with the stools positioned around it.

Steps to Unfold the Table (One Person Operation):

1. Lift the tabletop upwards from its stored position.
2. Pull out the support legs to their fixed position.
3. Continue to pull out and open the other half of the tabletop, securing it in place.
4. Take out the stools from their storage compartments and lock the wheels on the table for stability.

One Person Can Easily Unfold

Only 4 steps to fully expand



1. Lift the tabletop up wards



2. Pull out the legs to the fixed position



3. Continue to pull out, open the other half, and secure it



4. Take out the stools and lock the wheels

Image: A four-panel diagram illustrating the simple steps to unfold the dining table: 1. Lift the tabletop upwards. 2. Pull out the legs to the fixed position. 3. Continue to pull out the other half and secure it. 4. Take out the stools and lock the wheels.

Using the Power Outlet:

The sideboard cabinet includes a built-in power outlet for convenience. Plug in small kitchen appliances like microwaves, coffee makers, or bread machines directly into the integrated outlets. Ensure the total wattage does not exceed the specified limit (refer to specifications section).

Your browser does not support the video tag.

Video: A demonstration of the VOWNER Folding Dining Table Set and Tall Storage Cabinet, showcasing its various features including the storage capabilities, the folding mechanism of the table, and the integrated power outlet. This video highlights the product's versatility and space-saving design.

CARE AND MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.

- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Hardware:** Periodically check all screws, bolts, and fasteners to ensure they are tight. Re-tighten if necessary to maintain structural integrity.
- **Wheels:** Keep the lockable wheels clean and free of debris to ensure smooth operation.
- **Sunlight & Heat:** Avoid prolonged exposure to direct sunlight or extreme heat, which can cause fading or warping.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Table feels wobbly or unstable.	Loose fasteners; wheels not locked; uneven floor.	Check and tighten all assembly screws. Ensure all 8 lockable wheels are engaged. Move to a level surface or use shims if necessary.
Table difficult to fold/unfold.	Mechanism obstructed; lack of lubrication.	Check for any objects blocking the folding mechanism. Apply a small amount of silicone lubricant to moving parts if needed.
Drawer sticks or doesn't slide smoothly.	Misaligned slides; debris in tracks; overloaded drawer.	Ensure drawer slides are correctly aligned and free of debris. Do not overload the drawer.
Power outlet not working.	Not plugged into wall; circuit breaker tripped; overloaded.	Ensure the main power cord is securely plugged into a working wall outlet. Check your household circuit breaker. Do not exceed the maximum wattage for the outlet.

SPECIFICATIONS

Brand: VOWNER

Model Number: RS-145+RS-143

Material: Engineered Wood, Metal

Color: White+Oak

Sideboard Cabinet Dimensions (L x W x H): 31.5 x 15.7 x 70.8 inches

Folding Dining Table Dimensions (Expanded L x W x H): 63 x 29.5 x 29.5 inches

Item Weight: Approximately 153 pounds (total for both packages)

Number of Drawers: 1

Number of Shelves: 2 (adjustable within cabinet)

Table Seating Capacity: 4-6 persons

Table Weight Capacity: Up to 220 lbs (distributed evenly)

Special Features: Space-saving design, 71" tall kitchen pantry storage cabinet, integrated charging station (power outlet), 63" folding dining table with 4 stools, 8 lockable wheels on table, anti-tip design.

Country of Origin: China

WARRANTY INFORMATION

VOWNER products are manufactured with quality and durability in mind. This product comes with a standard manufacturer's warranty covering defects in materials and workmanship. Please refer to the warranty card included in your package for specific terms, conditions, and duration. Keep your purchase receipt as proof of purchase for warranty claims.

Protection plans are also available for extended coverage:

- 2-Year Protection Plan
- 3-Year Protection Plan
- Complete Protect (monthly plan covering eligible purchases)

For details on these plans, please visit the product page on Amazon or contact customer support.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact VOWNER customer support:

Online Support: Visit the [VOWNER Store on Amazon](#) for FAQs and contact options.

Seller Contact: For direct assistance, you may contact "KPRservice store" via Amazon's messaging system.

Please have your model number (RS-145+RS-143) and purchase date ready when contacting support.

© 2025 VOWNER. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FFSTM68G>

More documents and user manuals: <https://manuals.plus/>