Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

rollingsurfer MC03

Rollingsurfer 1.8m Pre-Lit Artificial Christmas Tree User Manual

Model: MC03 | Brand: rollingsurfer

Introduction

This manual provides comprehensive instructions for the assembly, operation, and care of your Rollingsurfer 1.8m Pre-Lit Artificial Christmas Tree. Please read these instructions carefully before setup to ensure safe and proper use.

Key Features:

- Height: 1.8 meters (6 feet)
- Pre-installed with 300 LED lights
- 11 lighting modes (Warm White & Multicolor)
- 1000 PVC branch tips for a full appearance
- Hinged segment design for easy assembly
- Sturdy metal stand included

1. Setup Instructions

1. **Unpack Components:** Carefully remove all tree sections, the metal stand, and the power adapter from the packaging.
2. **Assemble the Stand:** Open the metal stand and insert the three screws into the designated holes. Tighten them securely to form a stable base.
3. **Insert Bottom Section:** Place the largest tree section (Section A) into the assembled metal stand. Ensure it is firmly seated and the screws are tightened around the pole.
4. **Connect Tree Sections:** Insert the middle tree section (Section B) into Section A, aligning the poles. Then, insert the top tree section (Section C) into Section B. The hinged branches will fall into place automatically.
5. **Connect Lighting:** Locate the rotary interface connectors between each tree section. Connect them securely. Ensure all connections are tight to prevent light malfunctions.
6. **Fluff the Branches:** Starting from the bottom section, gently spread out each branch tip, bending them slightly upwards and outwards to create a full, natural appearance. This process may take 45 minutes to 1 hour for optimal results.
7. **Connect to Power:** Plug the power adapter into a standard electrical outlet.



Figure 1: Tree assembly and fluffing process. The image illustrates how to spread out the branches for a full appearance.



Figure 2: Tree dimensions and key assembly features, including the hinged segment design and rotary interface for lighting connections.

2. Operating Instructions

Your Christmas tree is equipped with pre-installed LED lights and a remote control for easy operation.

2.1 Lighting Modes

The tree features 300 LED lights with 11 selectable lighting modes, including both warm white and multicolor options.



Figure 3: Illustration of the warm white and multicolor lighting options available on the tree.

2.2 Using the Remote Control

Use the provided remote control to switch between the 11 lighting modes. Point the remote directly at the tree's receiver (usually located near the power connection) for optimal response.

- Press the "Mode" button to cycle through the different light patterns.
- Specific buttons may be available for brightness adjustment or timer functions, depending on the remote model. Refer to the remote's markings.

3. Maintenance

3.1 Cleaning

- To clean the tree, gently wipe the branches with a soft, dry cloth.
- Do not use harsh chemicals or abrasive cleaners, as these can damage the PVC branches or the LED lights.

- Ensure the tree is unplugged from the power source before cleaning.

3.2 Storage

- Before storing, ensure the tree is completely dry.
- Disassemble the tree by reversing the setup steps. Carefully disconnect the lighting interfaces.
- Gently compress the branches of each section.
- Store the tree sections and stand in their original packaging or a suitable storage bag in a cool, dry place, away from direct sunlight and extreme temperatures.

4. Troubleshooting

Problem	Possible Cause	Solution
Lights are not working.	• Power adapter not plugged in. • Loose connection between tree sections. • Faulty outlet.	• Ensure the power adapter is securely plugged into a working outlet. • Check all rotary interface connections between tree sections for tightness. • Test the outlet with another appliance.
Remote control is not responding.	• Remote battery is low or dead. • Obstruction between remote and receiver.	• Replace the remote control battery. • Ensure a clear line of sight between the remote and the tree's light receiver.
Tree appears sparse after assembly.	Insufficient branch fluffing.	Spend additional time spreading and shaping each individual branch tip to achieve a fuller appearance. Refer to "Fluff the Branches" in the Setup section.

5. Specifications

- **Model Number:** MC03
- **Brand:** rollingsurfer
- **Height:** 1.8 meters (6 feet)
- **Base Diameter:** 108 cm (3.54 feet)
- **Product Dimensions (L x W x H):** 108 x 108 x 180 cm
- **Weight:** 6.6 kg (14.52 lbs)
- **Tree Type:** Artificial Pine
- **Branch Tips:** Approximately 1000 PVC tips
- **Lighting:** 300 Pre-installed LED lights
- **Lighting Modes:** 11 (including Warm White and Multicolor options)
- **Base Type:** Metal Stand
- **Color:** Green (MC03 variant)



Figure 4: Overview of key product features and specifications.

6. Warranty Information

Specific warranty details for this product are not provided in the available information. Please refer to your purchase documentation or contact the retailer for warranty terms and conditions.

7. Customer Support

For further assistance, questions, or to report any issues with your Rollingsurfer Christmas tree, please contact your retailer or the manufacturer directly. Contact information may be available on the product packaging or the retailer's website.

© 2026 Rollingsurfer. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FFSX3VCM

More documents and user manuals: **https://manuals.plus/**