Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PACOVY ADJ-01

PACOVY Floor Lamp ADJ-01 Instruction Manual

Model: ADJ-01

1. Product Overview

The PACOVY Floor Lamp ADJ-01 is designed to provide versatile and efficient lighting for various environments such as living rooms, bedrooms, offices, and craft areas. It features 120 high-brightness LED beads, offering 18W 1800LM light output. Key features include adjustable height, a 360° flexible gooseneck, dimmable brightness (10%-100%), adjustable color temperature (2700K-6500K), and multiple preset lighting modes. Control options include a remote control and touch controls on the lamp pole. The lamp also includes a timer function and memory function for convenience.




Image: Overview of the PACOVY Floor Lamp's key features and dimensions, including the aluminum lamp head, 120 bright LEDs, flexible gooseneck, metal screw connection, and heavy-duty metal base.

2. What's in the Box

Please check the package contents upon arrival to ensure all components are present:

- Pink LED Floor Lamp
- Remote Control
- Adapter
- User Manual (this document)

3. Setup and Assembly

The PACOVY Floor Lamp is designed for quick and easy assembly without the need for additional tools. Follow these steps:

1. **Prepare All Parts:** Unpack all components and lay them out. Ensure you have the lamp head, lamp pole sections, base, remote control, and power adapter.
2. **Assemble the Lamp Pole:** Connect the lamp pole sections by screwing them together. Ensure the silver fastener is not unscrewed until installation is complete. Place the sections in the correct position and tighten to assemble securely.
3. **Connect the Base:** Attach the assembled lamp pole to the heavy-duty metal base. Screw it firmly into place.
4. **Connect the Power Cable:** Insert the power adapter cable into the lamp's power port, typically located near the base. Plug the adapter into a standard electrical outlet.



Image: Step-by-step visual guide for assembling the PACOVY Floor Lamp, showing preparation of parts, connecting pole sections, attaching the base, and connecting the power cable.

4. Operating Instructions

The PACOVY Floor Lamp offers multiple ways to control its settings for optimal lighting.

4.1. Touch Control on Lamp Pole

The lamp pole features integrated touch controls for quick adjustments:

- **Brightness +:** Increase light brightness.
- **Brightness -:** Decrease light brightness.
- **CCT (Color Temperature Adjustment):** Cycle through color temperature settings (Warm White to Cool White).
- **On/Off, 1 Hour Timer:** Press once to turn on/off. Long press to activate the 1-hour timer.




Image: Details of the touch control buttons on the lamp pole and the remote control, highlighting their functions.

4.2. Remote Control

The included remote control allows for convenient adjustment of light settings from up to 50 feet (15.24 meters). The remote is magnetic and can be attached to the metal lamp pole to prevent loss.

- **Power Button:** Turn the lamp on or off.
- **Brightness Adjustment:** Dedicated buttons to increase or decrease brightness (10%-100% stepless dimming).

- **Color Temperature Adjustment:** Buttons to adjust color temperature from 2700K (warm white) to 6500K (cool white).
- **Preset Modes:** Access 5 pre-programmed lighting modes: Work, Reading, Leisure, Care, and Night Light.
- **1-Hour Timer:** Activate a 1-hour automatic shut-off timer.

4.3. Light Adjustment Features

- **Stepless Brightness Adjustment:** Adjust light intensity from 10% to 100% to suit your needs.
- **Color Temperature Adjustment:** Change the light color from warm (2700K) to cool (6500K) to create different atmospheres.



Image: Visual representation of the lamp's color temperature adjustment from 2700K (Warm Light) to 6500K (Cool Light), and stepless brightness adjustment from 10% to 100% bright.

- **Preset Modes:** Quickly select from optimized lighting settings for specific activities.




Image: Examples of the lamp's preset modes in use: Work Mode, Night Light Mode, Care Mode, Leisure Mode, and Reading Mode.

- **1-Hour Timer:** Set the lamp to automatically turn off after one hour.



Image: Illustration of the 1-hour timer function, showing the lamp turning off automatically after a set period, ideal for bedtime reading.

- **Memory Function:** The lamp automatically restores the last used light settings when turned back on.

4.4. Flexible Gooseneck and Height Adjustment

The 360° flexible gooseneck allows you to direct the light precisely where needed. The extendable lamp pole enables easy adjustment of the overall height to suit your workspace or activity.

5. Maintenance

To ensure the longevity and optimal performance of your PACOVY Floor Lamp, follow these maintenance guidelines:

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the lamp head, pole, and base. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Bulb Replacement:** The lamp uses integrated LED beads with a lifespan of up to 50,000 hours. These are not user-replaceable. If the LEDs fail, please contact customer support.
- **Stability Check:** Periodically check that all connections, especially the pole sections and base, remain tight to

ensure stability.

- **Remote Control:** Replace the remote control battery (if applicable) when its range or responsiveness decreases. Refer to the remote's specific instructions for battery type and replacement.

6. Troubleshooting

If you encounter issues with your PACOVY Floor Lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	No power, loose connection, faulty adapter.	Ensure the power adapter is securely plugged into both the lamp and the wall outlet. Test the outlet with another device. If the issue persists, contact support.
Remote control not working.	Remote battery low/dead, remote not paired, obstruction.	Replace the remote battery. Ensure there are no obstructions between the remote and the lamp. If the remote is new or replaced, it might need to be paired (refer to specific remote instructions if provided).
Light flickers or is unstable.	Unstable power supply, internal component issue.	Try plugging the lamp into a different outlet. Ensure the power connection is stable. If flickering continues, contact customer support.
Cannot adjust brightness/color temperature.	Remote/touch control issue, lamp malfunction.	Try using both the remote and the touch controls on the lamp pole. Ensure the remote battery is good. If neither works, contact support.

If these solutions do not resolve the issue, please contact PACOVY customer support for further assistance.

7. Specifications

Feature	Detail
Model Number	ADJ-01
Light Source Type	LED
Number of LED Beads	120
Wattage	18 watts
Luminous Flux	1800 LM
Brightness Adjustment	10%-100% Stepless Dimmable
Color Temperature	2700K (Warm White) to 6500K (Cool White)
Control Method	Remote Control, Touch Control
Remote Range	Up to 50 feet (15.24 meters)
Additional Features	1 Hour Timer, Memory Function, Adjustable Height, Flexible Gooseneck, Eye-friendly, Flicker-free
Base Material	Heavy-Duty Solid Metal with Anti-slip Pads

Feature	Detail
Product Dimensions (D x W x H)	17.13"D x 6.69"W x 2.17"H
Base Diameter	8.66 Inches
Material Type	Aluminum, Copper, Metal, Plastic
Power Source	Corded Electric
Voltage	120 Volts (AC)
Lifespan	Up to 50,000 hours
Indoor/Outdoor Usage	Indoor

8. Warranty and Support

The PACOVY Floor Lamp ADJ-01 comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use.

For warranty claims, technical support, or any questions regarding your product, please contact PACOVY customer service. You can find more information and contact details by visiting the official PACOVY Store online: PACOVY Store.

Please retain your proof of purchase for warranty validation.

© 2026 PACOVY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FFSYY87Y

More documents and user manuals: **https://manuals.plus/**