Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MAHOMICO 1359

MAHOMICO Recliner Chair User Manual

Model: 1359

Introduction

Thank you for choosing the MAHOMICO Recliner Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new recliner. Please read it thoroughly before use and retain it for future reference.

Safety Information

No specific safety warnings are provided with this product. Always follow general furniture safety guidelines:

- Ensure all parts are securely fastened before use.
- Do not allow children to play on or around the recliner unsupervised.
- Avoid placing the recliner near heat sources or open flames.
- Do not stand on the recliner or use it as a step stool.
- Keep hands and feet clear of moving parts during reclining operation.
- Maximum weight capacity is 350 lbs. Do not exceed this limit.

Package Contents

Your MAHOMICO Recliner Chair is delivered in one box. Please verify that all components are present before beginning assembly.



Image: Diagram showing the dimensions of the recliner chair and indicating it is delivered in one box.



Image: Illustration of the recliner chair and a box, indicating it ships in one package.

Typically, the package includes:

- Recliner Base
- Backrest
- Armrests (Left and Right)
- Power Adapter (for massage/heat functions)
- Remote Control
- Lumbar Pillow
- Assembly Hardware and Tools (if required)
- Instruction Manual

Setup and Assembly

Assembly is required for this recliner. Please follow the steps below carefully. It is recommended to have two people for

assembly.

1. **Unpack Components:** Carefully remove all parts from the box and lay them out on a soft, clean surface to prevent damage. Verify all parts are present against the package contents list.
2. **Attach Armrests:** Align the metal grooves on the chair seat with the corresponding slots on the left and right armrests. Slide them down until they click securely into place.
3. **Install Backrest:** Slide the backrest onto the metal brackets on the chair base. Ensure it is fully seated and locked.
4. **Connect Wiring:** If your model includes massage and heat functions, connect the power cables from the backrest and seat to the main power adapter. Plug the adapter into a wall outlet.
5. **Final Check:** Gently rock and recline the chair to ensure all connections are secure and the chair operates smoothly.

Your browser does not support the video tag.

Video: This video demonstrates the assembly process for the single seat manual recliner chair, showing how to connect the armrests and backrest to the base.

Operating Instructions

Reclining Function

To recline the chair, locate the manual lever on the side of the chair (typically on the right). Pull the lever to release the footrest and lean back to your desired angle. The chair can recline up to 155 degrees, offering positions for reading (approx. 108°), watching TV (approx. 120°), and sleeping (approx. 155°). To return to the upright position, push the footrest down with your legs and lean forward.



Image: Diagram illustrating the different reclining angles for reading, watching TV, and sleeping.



Image: A person demonstrating the manual reclining function of the chair.

Massage and Heat Functions

If your recliner includes massage and heat features, use the provided remote control to operate them. The remote typically allows you to select from 5 massage modes, 2 vibration strengths, and activate lumbar heating across 8 vibrating points.



Image: Close-up of the remote control for massage and heat functions, showing buttons for modes, intensity, and heat activation.

Your browser does not support the video tag.

Video: This video showcases the massage functions of the recliner chair, demonstrating various settings and their effects.

Your browser does not support the video tag.

Video: A comprehensive showcase of the reclining sofa set, highlighting its features including massage and heat, and overall design.

Your browser does not support the video tag.

Video: This video provides a full showcase of the swivel rocker recliner with massage and heat functions, detailing its various capabilities.

Additional Features

- **Cup Holders:** Two cup holders are integrated into the armrests for convenience.
- **Side Pockets:** Storage pockets are located on the side of the chair for small items like remote controls or magazines.
- **Swivel and Rocking:** The chair features a 360° swivel and a gentle rocking motion for added comfort.



Image: Detailed view of the recliner's features including cup holders, padded headrest, foot support board, and side pockets.

Maintenance

To ensure the longevity and appearance of your MAHOMICO Recliner Chair, follow these maintenance guidelines:

- **Cleaning:** Wipe clean with a dry cloth or vacuum regularly to remove dust and debris. For spills, blot immediately with a clean, dry cloth. Avoid harsh chemicals or abrasive cleaners.
- **Fabric Care:** The chair is upholstered in breathable fabric. Refer to any specific fabric care tags if available.
- **Moving the Chair:** When moving the chair, lift it rather than dragging to prevent damage to the legs and frame.
- **Inspection:** Periodically check all bolts and screws to ensure they are tight. Retighten as necessary.

Troubleshooting

If you encounter any issues with your recliner, please refer to the following common solutions:

Problem	Possible Cause	Solution
Chair does not recline smoothly.	Mechanism obstruction or loose connections.	Check for any objects obstructing the reclining mechanism. Ensure all assembly connections are secure.
Massage/Heat functions not working.	Power connection issue or remote control battery.	Verify the power adapter is securely plugged into both the chair and the wall outlet. Check if the wall outlet is functional. Ensure remote control batteries are correctly inserted and charged (if applicable).
Chair feels unstable or wobbly.	Loose assembly bolts.	Inspect and tighten all assembly bolts and screws. Ensure the chair is on a flat, even surface.

If the issue persists, please contact customer support.

Specifications

Feature	Detail
Brand	MAHOMICO
Model Number	1359
Product Dimensions (D x W x H)	37.4"D x 38.6"W x 41.3"H
Reclined Length	62.2 inches
Seat Depth	21.7 inches
Seat Height	19.3 inches
Weight Limit	350 pounds
Seating Capacity	1
Item Weight	86.9 pounds
Color	Grey
Material Type	Fabric (Cotton fill)
Frame Material	Metal
Additional Features	Ergonomic, Swivel, Rocking, Massage & Waist heating, Reclining, Cup Holders, Side Pocket
Reclining Position Count	2 (multiple angles up to 155°)
Number of Cup Holders	2
Product Care Instructions	Wipe Clean with Dry Cloth or Vacuum Regularly

Warranty and Support

Warranty: This product comes with a Limited Warranty. Please refer to the warranty card included with your purchase for specific terms and conditions.
Returns: A 30-day easy return policy is typically offered by the seller. Please check your purchase details for exact return procedures.
Customer Support: For any questions, concerns, or assistance with your MAHOMICO Recliner Chair, please contact the seller or MAHOMICO customer service. Contact information can usually be found on the product packaging or the retailer's website.

© 2026 MAHOMICO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FFT6VC3B

More documents and user manuals: **https://manuals.plus/**