

NEC VersaPro VH-1 (VKT12)

NEC VersaPro VH-1 Laptop User Manual

Model: VersaPro VH-1 (VKT12)

1. INTRODUCTION

This user manual provides comprehensive instructions for the NEC VersaPro VH-1 laptop. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and user experience. Please read this manual thoroughly before using your device.

The NEC VersaPro VH-1 is a lightweight and high-performance 12.5-inch Full HD laptop, featuring a 7th Generation Intel Core i5-7Y54 processor. It is designed for efficient web browsing, business applications, and remote work. With pre-installed Windows 11 Pro and MS Office 2019, it is ready for immediate use upon arrival.

2. PRODUCT OVERVIEW

2.1 Key Features

- Lightweight & Thin Design:** Weighing approximately 921g, this 12.5-inch FHD laptop is highly portable, fitting easily into a backpack for commuting, business trips, or mobile work.
- 7th Gen Intel Core i5-7Y54 Processor:** Equipped with an efficient and power-saving Intel Core i5-7Y54 (up to 3.2GHz) processor, offering sufficient performance for browsing, online meetings, and Office applications. It also features quiet operation and low heat generation.
- High-Speed SSD Storage:** Features an SSD for fast boot-up and smooth operation, handling large files and multiple applications without lag.
- Rich Connectivity & Type-C Expansion:** Includes a Web camera, Wi-Fi, Bluetooth, HDMI, and a Type-C port for versatile connections to peripherals and external monitors. The Type-C port supports future expansion.
- Pre-installed Software:** Comes with Windows 11 Pro and MS Office 2019 pre-installed, allowing immediate document creation, report preparation, and web conferencing.

2.2 Component Identification

Familiarize yourself with the various parts of your NEC VersaPro VH-1 laptop.

NEC外観・デザイン



Image: Various views of the NEC VersaPro VH-1 laptop, showing the front, back, top, and keyboard layout.

豊富なインターフェースを搭載しており
さまざまなシーンでの活用が可能




Image: Side view of the laptop highlighting available ports including USB 3.0, LAN, Headphone Jack, HDMI, SD Card Slot, and Power Connector.

3. SETUP

3.1 Initial Power-On

- Connect Power:** Plug the AC adapter into the laptop's power port and then into a wall outlet.
- Power On:** Open the laptop lid and press the power button. The laptop will begin the initial boot process.
- Windows Setup:** Follow the on-screen instructions to complete the Windows 11 Pro setup, including language, region, network connection, and user account creation.

3.2 Software Activation

Your laptop comes with MS Office 2019 pre-installed. Follow the prompts to activate your Office suite using your Microsoft account or product key.

すぐに使える

面倒な初期設定不要、届いてすぐ使えます！



Image: The laptop displaying the Windows 11 interface, with logos indicating Windows 11 Pro and MS Office 2019 are installed and ready for use.

4. OPERATING INSTRUCTIONS

4.1 Basic Usage

- Keyboard:** The laptop features a Japanese layout keyboard designed for comfortable and accurate typing.
- Touchpad:** Use the integrated touchpad for navigation and gestures.
- Web Camera:** The built-in web camera and dual microphones are ideal for remote work, online meetings, and video calls.

Webカメラ搭載 デュアルマイク付

リモートワーク

Web会議

ビデオ通話

オンライン授業



Image: A user engaged in a video conference call on the NEC VersaPro VH-1 laptop, demonstrating its web camera and dual microphone capabilities for remote work and online learning.

- 快適で正確なタイピング体験
- 日本語キーボードを採用
- 日本語入力に特化したレイアウト
- ビジネスシーンや日常使用において
ストレスなくお使いいただけます



Image: Close-up of hands typing on the laptop's keyboard, illustrating the comfortable and precise typing experience provided by the Japanese layout keyboard.

4.2 Connectivity

- Wi-Fi:** Connect to wireless networks for internet access.
- Bluetooth:** Pair with Bluetooth-enabled devices such as headphones or mice.
- HDMI:** Connect to external displays or projectors.
- Type-C:** Use the Type-C port for data transfer, charging compatible devices, or connecting to a USB-C hub for additional ports.

5. MAINTENANCE

5.1 Cleaning

- Screen:** Use a soft, lint-free cloth slightly dampened with water or a screen cleaner. Do not spray liquid directly onto the screen.
- Keyboard & Chassis:** Use a soft cloth to wipe surfaces. For stubborn dirt, a slightly damp cloth can be used. Avoid harsh chemicals.

5.2 Battery Care

- To prolong battery life, avoid extreme temperatures.
- If storing the laptop for an extended period, ensure the battery is charged to about 50-70%.

6. TROUBLESHOOTING

6.1 Common Issues and Solutions

Issue	Possible Solution
Laptop does not power on.	Ensure the AC adapter is securely connected to both the laptop and a working power outlet. Check if the power button is functioning correctly.
Wi-Fi connection issues.	Verify Wi-Fi is enabled in Windows settings. Restart your router and the laptop. Check for updated network drivers.
External display not detected.	Ensure the HDMI cable is securely connected. Press Windows key + P to cycle through display modes. Check external display input settings.
Slow performance.	Close unnecessary applications. Check for background processes consuming resources. Ensure sufficient free space on the SSD. Run a system scan for malware.

If you encounter issues not listed here or require further assistance, please refer to the support section.

7. SPECIFICATIONS

Feature	Detail
Brand	NEC
Model Name	VasaPro VH-1
Product Model Number	VKT12
Screen Size	12.5 Inches
Resolution	1920x1080 Pixels (FHD)
CPU Brand	Intel
CPU Type	Core i5 7Y54
CPU Speed	1.2 GHz (Max 3.2 GHz)
Processor Count	2
RAM Memory Size	4 GB
Maximum Memory Supported	8 GB
Memory Type	DDR3 SDRAM

Feature	Detail
Hard Disk Size	1 TB
Hard Disk Type	SSD
Graphics Coprocessor	Intel HD Graphics 615
Graphics Card Description	Integrated
Operating System	Windows 11 Pro
Wireless Type	Bluetooth, Wi-Fi (802.11n)
USB 3.0 Ports	2
HDMI Ports	1
Optical Drive Type	None
Item Weight	1.5 Kilograms (Shipping Weight)
Battery	1 12V battery (included), 24 Watt-hours, 4 Lithium Ion cells

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or contact the retailer. Specific warranty terms may vary.