

[Manuals.plus](#) /

› [Teamson Home](#) /

› Teamson Home Outdoor 3-Piece Wicker Recliner Set Instruction Manual

## Teamson Home THF0124BR

# Teamson Home Outdoor 3-Piece Wicker Recliner Set

Model: THF0124BR

## INTRODUCTION

Thank you for choosing the Teamson Home Outdoor 3-Piece Wicker Recliner Set. This manual provides essential information for the safe assembly, operation, maintenance, and care of your new patio furniture. Please read all instructions carefully before assembly and use, and retain this manual for future reference.

## Safety Information

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the furniture on a soft, clean surface to prevent scratches.
- Always tighten all bolts and fasteners securely. Periodically check and re-tighten as necessary.
- Do not exceed the weight capacity of the chairs or table.
- Keep children and pets away from the assembly area.
- This furniture is designed for outdoor use. Protect it from extreme weather conditions to prolong its lifespan.

## SETUP AND ASSEMBLY

This 3-piece set requires assembly. It includes two reclining chairs and one round side table. Please follow the steps below for proper setup.

### Components Included:

- 2 x Recliner Chairs

- 1 x Side Table
- All necessary hardware and tools (usually included in packaging)

### Assembly Steps:

1. Unpack all components and lay them out on a protected surface. Verify all parts are present according to the parts list in your packaging.
2. Begin by assembling the chair frames. Attach the backrest to the seat frame, ensuring all bolts are finger-tightened initially.
3. Attach the armrests to the chair frames.
4. Secure the reclining mechanism components as per the diagrams.
5. Once the chair frames are assembled, place the cushions onto the chairs.
6. Assemble the side table by attaching the legs to the tabletop and securing the lower shelf.
7. Once all components are assembled, go back and fully tighten all bolts and fasteners using the provided tool. Do not overtighten.



Image: Front view of the assembled 3-piece set, showing two recliner chairs and a round side table.



Image: Detailed diagram showing the dimensions of the recliner chairs and side table.

## OPERATING INSTRUCTIONS

### Reclining Chairs:

The chairs feature an ergonomic reclining design for adjustable comfort. To recline, gently push back on the backrest while applying slight pressure with your feet on the footrest. The footrest will extend, and the backrest will lean back. To return to an upright position, lean forward and push the footrest back into its closed position.



Ergonomic Reclining Design



Extra-Wide & Thick Cushions



Eucalyptus Wood Inlays



Image: Side view of a recliner chair demonstrating the reclining mechanism.



Image: Close-up of the footrest in its extended position.



Image: A single recliner chair fully extended, showcasing its ergonomic design.

### Side Table:

The round side table is designed for convenient placement of beverages, books, or small decor items. It features a lower shelf for additional storage.

Your browser does not support the video tag.

Video: This video demonstrates the features of the Teamson Home 3-Piece Outdoor Reclining Wicker Chair Set, including the reclining function and overall design.

## CARE AND MAINTENANCE

---

Proper care will ensure the longevity and appearance of your Teamson Home furniture.

### Cleaning:

- **Wicker and Frame:** Clean with a dry or damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly with water. Avoid harsh chemicals or abrasive cleaners.
- **Cushions:** The cushions are made with 230gsm polyester covers and D20 foam, designed to be UV- and weather-resistant. Spot clean with a mild soap and water solution. Allow to air dry completely before storage or reuse.
- **Eucalyptus Wood Armrests/Tabletop:** Wipe clean with a damp cloth. To maintain the wood's natural warmth and protect it from weathering, periodic application of a suitable outdoor wood oil is recommended.

### Storage and Protection:

- During periods of non-use or inclement weather, it is recommended to cover the furniture with a protective cover or store it indoors to prevent damage and extend its lifespan.
- Ensure cushions are dry before storing to prevent mold and mildew.



Image: Close-up of the thick, weather-resistant cushion.



Image: Detailed view of the handwoven brown polyethylene rattan wicker finish.



Image: Close-up of the eucalyptus wood inlay on the armrest, highlighting the natural accent.

## TROUBLESHOOTING

---

This section addresses common issues you might encounter with your outdoor furniture set.

### Loose Connections:

- **Issue:** Furniture feels wobbly or unstable.
- **Solution:** Check all bolts and fasteners. Re-tighten any loose connections. Avoid overtightening to prevent stripping.

### Stains on Cushions:

- **Issue:** Spills or dirt on the fabric cushions.
- **Solution:** Promptly spot clean with a mild soap and water solution. For tougher stains, a fabric cleaner suitable for outdoor polyester may be used, following the product's instructions. Ensure cushions are completely dry before use or storage.

## Wicker Damage:

- **Issue:** Minor fraying or damage to the PE rattan wicker.
- **Solution:** For minor fraying, carefully trim with scissors. For more significant damage, contact customer support for advice on repair or replacement parts.

## SPECIFICATIONS

Feature	Detail
Brand	Teamson Home
Model Number	THF0124BR
Color	Brown (Wicker), Beige (Cushions)
Material Type	Polyethylene (PE) Rattan Wicker, Powder-Coated Steel Frame, Eucalyptus Wood, Polyester Fabric (Cushions), D20 Foam (Cushions)
Item Dimensions (Recliner Upright)	31.89"L x 36.61"W x 42.32"H (81 cm L x 93 cm W x 107.5 cm H)
Item Dimensions (Recliner Reclined)	56.3"L x 36.61"W x 36.61"H
Side Table Dimensions	19.69"L x 19.69"W x 20.28"H (50 cm L x 50 cm W x 51.5 cm H)
Item Weight	57.3 Pounds (Total for set)
Included Components	2 Recliner Chairs, 1 Side Table
Assembly Required	Yes
UPC	810136545999

## WARRANTY INFORMATION

This Teamson Home product is covered by a manufacturer's warranty for **30 days against manufacturer defects** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, abuse, improper assembly, accidents, or normal wear and tear. Please retain your proof of purchase for any warranty claims.

## CUSTOMER SUPPORT

If you have any questions regarding the assembly, operation, maintenance, or warranty of your Teamson Home Outdoor 3-Piece Wicker Recliner Set, please contact Teamson Home customer service. For assistance, please refer to the contact information provided with your product packaging or visit the official Teamson Home website for support options.

© 2024 Teamson Home. All rights reserved.