

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [DEWALT](#) /

> [DEWALT 18V XR Pole Pruner DCMPP569P1-QW Instruction Manual](#)

## DEWALT DCMPP569P1-QW

# DEWALT 18V XR Pole Pruner DCMPP569P1-QW Instruction Manual

Model: DCMPP569P1-QW

## INTRODUCTION

---

This manual provides essential instructions for the safe and efficient operation, setup, maintenance, and troubleshooting of your DEWALT 18V XR Pole Pruner, model DCMPP569P1-QW. Please read this manual thoroughly before using the tool to ensure proper handling and to maximize its performance and lifespan.

## GENERAL SAFETY INFORMATION

---

**WARNING:** Always observe general power tool safety warnings and instructions provided in the comprehensive safety manual that accompanies this product. Failure to follow all instructions may result in electric shock, fire, and/or serious injury. Keep all warnings and instructions for future reference.

- Always wear appropriate personal protective equipment, including eye protection, gloves, and sturdy footwear.
- Ensure the work area is clear of bystanders, especially children and pets.
- Do not operate the tool in wet conditions or near flammable liquids or gases.
- Disconnect the battery pack before making any adjustments, changing accessories, or storing the tool.
- Maintain a firm grip on the tool and be aware of your surroundings, especially overhead power lines.

## PRODUCT OVERVIEW

---

The DEWALT 18V XR Pole Pruner is a versatile tool designed for efficient pruning tasks. It features a segmented pole system for extended reach, anti-stick coated blades, and an articulated head for precision.



**Figure 1:** The DEWALT 18V XR Pole Pruner, fully assembled, showing the segmented pole, pruner head, and battery handle.



**Figure 2:** A detailed view of the pruner head, highlighting the cutting blade and the metal branch hook.



Figure 3: The main components of the pole pruner, including the handle with battery slot, pole segments, and the pruner head.

## SETUP

---

### 1. Battery Charging and Installation

1. **Charge the Battery:** Use the included 4A charger to fully charge the 18V XR 5Ah Lithium-ion battery pack before first use. Refer to the charger's instruction manual for specific charging procedures.
2. **Install the Battery:** Align the battery pack with the receptacle in the tool's handle. Slide the battery into place until it clicks securely. Ensure it is fully seated before operation.
3. **Remove the Battery:** Press the battery release button and slide the battery pack out of the tool.

### 2. Assembling the Pole Segments

The pole pruner features a segmented pole system, allowing for adjustable length up to 3 meters. To assemble:

1. Connect the desired number of pole segments by aligning the connectors and twisting them until they lock securely.
2. Attach the pruner head to one end of the assembled pole and the handle assembly to the other end, ensuring all connections are tight.
3. Verify all connections are secure before operating the tool.

## OPERATING INSTRUCTIONS

---

---

## 1. General Operation

- Ensure a stable footing and maintain balance while operating the pole pruner.
- Hold the tool firmly with both hands using the ergonomic grip.
- Position the pruner head around the branch to be cut. The tool is capable of cutting branches up to 38 mm in thickness.
- Engage the trigger to activate the cutting mechanism. Release the trigger to stop.
- Allow the blade to complete the cut without forcing the tool.

## 2. Using the Articulated Head

The 5-position articulated head provides flexibility and control for reaching difficult angles. To adjust the head:

- Ensure the tool is off and the battery is removed.
- Locate the articulation adjustment mechanism on the pruner head.
- Adjust the head to the desired angle, ensuring it locks securely into one of the five positions before use.

## 3. Utilizing the Metal Branch Hook

The integrated metal branch hook assists in removing cut branches that may become lodged in the tree. After making a cut:

- Use the hook to gently pull or dislodge the cut branch, clearing the work area safely.

---

# MAINTENANCE

## 1. Blade Care

- **Cleaning:** The blades are coated to prevent sap and debris buildup. After each use, clean the blades with a damp cloth to remove any residue.
- **Replacement:** The cutting blade is replaceable and secured with a simple hexagonal screw. When the blade becomes dull or damaged, replace it with a genuine DEWALT replacement blade to maintain cutting performance.
- **Lubrication:** Periodically apply a light oil to the blade pivot points to ensure smooth operation.

## 2. General Cleaning and Storage

- Keep the tool's ventilation openings clean and free of debris.
- Store the pole pruner in a dry, secure location, out of reach of children.
- Remove the battery pack from the tool before storage.

---

# TROUBLESHOOTING

If you encounter issues with your DEWALT Pole Pruner, consider the following common solutions:

- **Tool not starting:** Ensure the battery is fully charged and correctly installed. Check for any obstructions in the cutting mechanism.
- **Reduced cutting performance:** The blade may be dull or damaged. Refer to the blade care section for replacement instructions. Ensure the blades are clean and free of sap buildup.
- **Pole segments not locking:** Verify that the connectors are properly aligned and twisted until they click into place.

For persistent issues, contact DEWALT customer support or an authorized service center.

## SPECIFICATIONS

---

Feature	Specification
Model Number	DCMPP569P1-QW
Power Source	Battery Powered (18V XR Lithium-ion)
Battery Included	1 x 5Ah Battery
Charger Included	1 x 4A Charger
Cutting Capacity	38 mm
Maximum Pole Length	3 meters (segmented)
Articulated Head Positions	5 positions
Tool Weight	6.42 kg
Package Dimensions	103.2 x 40.9 x 16.8 cm

## WARRANTY AND SUPPORT

---

For detailed warranty information and customer support, please refer to the official DEWALT website or the warranty card included with your product. You can also contact your local DEWALT service center for assistance.