Hisense HLAW0825TW

Hisense HLAW0825TW Smart Inverter Window Air Conditioner User Manual

Model: HLAW0825TW

Important Safety Instructions

Read all instructions before using this air conditioner. Failure to follow these instructions may result in property damage, product damage, or personal injury.

- Always plug into a grounded 3-prong outlet.
- Do not remove ground prong.
- Do not use an adapter.
- Do not use an extension cord.
- Unplug the air conditioner before servicing.
- Use two or more people to move and install the air conditioner.

Product Overview

The Hisense HLAW0825TW is an 8,000 BTU Smart Inverter Window Air Conditioner designed for efficient cooling of spaces up to 350 sq ft. It features an ultra-slim profile, smart controls via the ConnectLife App, and a 4-way air direction system.



Figure 1: Front view of the Hisense HLAW0825TW air conditioner with the air outlet louvers open, showing the control panel and Hisense branding.




Figure 2: Front view of the Hisense HLAW0825TW air conditioner with the air outlet louvers closed, showcasing its ultra-slim profile.



Figure 3: Front view of the Hisense HLAW0825TW air conditioner with the front panel opened to reveal the washable air filter compartment.




Figure 4: Side view of the Hisense HLAW0825TW air conditioner, illustrating its compact design and L-shaped configuration for window installation.

Setup and Installation

The Hisense HLAW0825TW comes with an easy installation bracket for robust support. Ensure your window dimensions are compatible: 25” - 38.6” W x 15.2” H.

Unpacking

Carefully remove the air conditioner and all accessories from the packaging. Verify all included components are present:

- Hisense 8,000 BTU Smart Inverter Window Air Conditioner unit
- Remote control with batteries
- Mounting Bracket and Hardware kit
- User Guide (this document)

Window Preparation

Before installation, ensure the window frame is sturdy enough to support the unit's weight (approximately 51.8 lbs). Clear any obstructions from the window opening.

Bracket Installation

1. Assemble the easy installation bracket according to the diagrams provided in the separate installation guide.
2. Securely attach the bracket to the window sill and frame using the provided hardware. Ensure it is level and stable.

Unit Placement

1. With assistance, carefully lift the air conditioner unit and slide it into the installed bracket.
2. Ensure the unit is firmly seated and secured within the bracket.
3. Extend the side panels to seal the gap between the unit and the window frame.

Electrical Connection

Plug the air conditioner's power cord directly into a standard 115 Volt, grounded 3-prong electrical outlet. Do not use extension cords or adapters.

Operating Instructions

The Hisense HLAW0825TW offers multiple operating modes and smart control capabilities.

Control Panel and Remote

The unit can be controlled via the integrated control panel or the included remote control. The remote control provides full functionality for convenience.

Operating Modes

- **Cool Mode:** Provides cooling with adjustable temperature settings.
- **Fan Mode:** Circulates air without cooling. Choose from 3 fan speeds.
- **Dry Mode (Dehumidifier):** Reduces humidity in the room.
- **Eco Mode:** Optimizes energy consumption by cycling the compressor and fan.
- **Sleep Mode:** Adjusts temperature and fan speed for comfortable overnight operation and energy savings.

Air Direction Adjustment

The unit features 4-way air direction. Manually adjust the horizontal and vertical louvers to direct airflow as desired for balanced cooling.

Smart Control (ConnectLife App)

The air conditioner is Wi-Fi compatible and can be controlled remotely using the Hisense ConnectLife app. Follow the app's instructions to connect your device to your home Wi-Fi network.

- Download the ConnectLife app from your device's app store.
- Create an account and add your Hisense HLAW0825TW air conditioner.
- Control settings, schedule operations, and monitor status from your smartphone.

Maintenance

Regular maintenance ensures optimal performance and longevity of your air conditioner.

Cleaning the Washable Filter

The unit features an easy-access reusable filter with a clean-filter alert. Clean the filter regularly, typically every two weeks, or when the "Clean Filter" indicator illuminates.

1. Unplug the air conditioner from the power outlet.
2. Open the front panel to access the filter. (Refer to Figure 3 in Product Overview)
3. Carefully slide out the air filter.
4. Wash the filter with warm, soapy water. Rinse thoroughly.
5. Allow the filter to air dry completely before reinserting. Do not use hot water or dry with direct heat.
6. Slide the dry filter back into its compartment and close the front panel.

Cleaning the Unit Exterior

Wipe the exterior of the unit with a soft, damp cloth. Do not use harsh chemicals, abrasives, or solvents.

Seasonal Storage

If storing the unit for an extended period, clean the filter and ensure the unit is dry. Store in a cool, dry place, preferably in its original packaging.

Troubleshooting

Refer to the following table for common issues and their solutions.

Problem	Possible Cause	Solution
Unit does not turn on.	No power; power cord unplugged; circuit breaker tripped.	Ensure unit is plugged in; check circuit breaker; press reset button on plug if applicable.
Unit not cooling effectively.	Dirty air filter; blocked air intake/outlet; room too large; windows/doors open.	Clean air filter; ensure no obstructions; close windows/doors; verify room size is within 350 sq ft.
Noisy operation.	Unit not level; loose parts; foreign object inside.	Ensure unit is level; check for loose screws; contact service if noise persists.
Water dripping inside.	Unit not tilted slightly outwards; drain clogged.	Ensure proper tilt for drainage; check and clear drain if accessible.

If the problem persists after attempting these solutions, please contact Hisense customer support.

Specifications

Feature	Detail
Model Number	HLAW0825TW
Cooling Capacity	8,000 BTU (ASHRAE)
Coverage Area	Up to 350 Sq Ft
Power Consumption	700 Watts
Voltage	115 Volts
Fan Speeds	3
Air Direction	4-Way
Noise Level	41 dB
Dimensions (D x W x H)	20.3" x 20.5" x 14.6"
Item Weight	51.8 lbs
Compatible Window Size	25” - 38.6” W x 15.2” H
Special Features	Inverter Technology, Smart Controls (Wi-Fi enabled, ConnectLife App), Washable Filter, Easy Install Bracket

Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Hisense website. Keep your purchase receipt for warranty claims.

Hisense Customer Support:

- Online Support: www.hisense-usa.com/support
- Phone Support: Refer to your warranty documentation for regional contact numbers.

When contacting support, please have your model number (HLAW0825TW) and serial number ready.

© 2025 Hisense. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question