

## OVENTE CMDD2MB

# OVENTE Double Drip Coffee Maker CMDD2MB User Manual

Model: CMDD2MB

## IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using your OVENTE Double Drip Coffee Maker. Keep this manual for future reference.

- **Electrical Safety:** Ensure the voltage rating of the appliance matches your local power supply. Do not operate the appliance with a damaged cord or plug.
- **Hot Surfaces:** The coffee maker's heating plate and surrounding areas become hot during and after operation. Avoid contact with hot surfaces.
- **Hot Liquids:** Exercise caution when handling hot coffee and steam. Do not open the lid during the brewing cycle.
- **Water Tank:** Only fill the water tank with cold, fresh water. Do not exceed the maximum fill line.
- **Placement:** Place the coffee maker on a stable, level, heat-resistant surface, away from edges and out of reach of children.
- **Cleaning:** Always unplug the coffee maker from the power outlet and allow it to cool completely before cleaning.
- **Supervision:** Close supervision is necessary when any appliance is used by or near children.
- **Ground Coffee Only:** This appliance is designed for use with ground coffee only. Do not use coffee pods or capsules.

## PRODUCT OVERVIEW

The OVENTE Double Drip Coffee Maker CMDD2MB is designed for convenient brewing of two cups of coffee simultaneously. Its compact design makes it suitable for various environments.



Image: The OVENTE Double Drip Coffee Maker is shown in different environments, highlighting its versatility for use at home, in an office, during RV camping, or on a patio.

## Components:

- Coffee Maker Unit
- Reusable Nylon Filter
- Two Ceramic Mugs

## SETUP

---

### First Use and Preparation:

1. **Unpack:** Carefully remove all packaging materials and ensure all components are present.
2. **Clean:** Before first use, wash the reusable filter and ceramic mugs with warm, soapy water. Wipe the exterior of the coffee maker with a damp cloth.
3. **Placement:** Place the coffee maker on a dry, stable, and heat-resistant surface. Ensure it is near a power outlet and away from any water sources.
4. **Initial Rinse:** For the first use, run a brewing cycle with only water (no coffee) to clean the internal components. Discard this water.

## OPERATING INSTRUCTIONS

---

Follow these steps to brew coffee with your OVENTE Double Drip Coffee Maker:

1. **Fill Water Tank:** Open the lid of the coffee maker. Fill the water tank with cold, fresh water up to the desired level (0.25L capacity). Do not overfill.
2. **Add Ground Coffee:** Place the reusable nylon filter into its designated holder. Add your preferred amount of ground coffee into the filter. For optimal flavor, use medium-ground coffee.

## Built for Fresh Ground Coffee

No Pods Needed — Richer Flavor



Image: A hand is shown scooping ground coffee into the reusable filter basket of the coffee maker.

3. **Position Mugs:** Place one or two ceramic mugs (or other heat-resistant cups) directly under the coffee dispenser nozzles.
4. **Start Brewing:** Close the lid securely. Plug the coffee maker into a standard electrical outlet. Press the power button located on the side of the unit. The indicator light will illuminate, signaling that brewing has begun.

## One-Touch Brewing

Hot Coffee Ready in Minutes



Image: A finger is shown pressing the red power button on the side of the coffee maker, initiating the brewing process.

5. **Wait for Completion:** The coffee will brew directly into your mugs. Once the brewing cycle is complete, the coffee maker will automatically shut off after approximately 7 minutes.
6. **Enjoy:** Carefully remove the mugs and enjoy your fresh coffee.

## MAINTENANCE AND CLEANING

---

Regular cleaning ensures optimal performance and extends the life of your coffee maker.

### Daily Cleaning:

1. **Unplug and Cool:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Wash Filter and Mugs:** Remove the reusable nylon filter and wash it, along with the ceramic mugs, with warm, soapy water. Rinse thoroughly and allow to air dry.

## Eco-Friendly Reusable Filter

Easy to Clean & Paper-Compatible



Image: Hands are shown rinsing the reusable coffee filter under running tap water, demonstrating the cleaning process.

3. **Wipe Exterior:** Wipe the exterior of the coffee maker with a soft, damp cloth. Do not immerse the coffee maker in water or any other liquid.

### Descaling (Monthly or as Needed):

Mineral deposits from water can build up over time, affecting performance. Descale your coffee maker regularly.

1. **Prepare Solution:** Mix 1 part white vinegar with 2 parts water. Fill the water tank with this solution.
2. **Run Cycle:** Place empty mugs under the dispenser. Run a brewing cycle with the vinegar solution.
3. **Rinse:** After the cycle, discard the solution. Run 2-3 cycles with fresh, clean water to rinse out any remaining vinegar taste or smell.

### TROUBLESHOOTING

---

If you encounter issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Coffee maker does not turn on.	Not plugged in; power outlet not working; power button not pressed.	Ensure the unit is securely plugged in. Check the power outlet with another appliance. Press the power button firmly.
Coffee is not brewing.	No water in the tank; filter clogged; unit needs descaling.	Fill the water tank. Clean the reusable filter. Perform a descaling cycle.
Coffee tastes weak.	Not enough coffee grounds; coffee grounds too coarse; water tank overfilled.	Add more coffee grounds. Use finer ground coffee. Ensure water level is appropriate for desired strength.
Coffee maker is leaking.	Water tank overfilled; filter not seated correctly; unit damaged.	Do not overfill the water tank. Ensure the filter is properly in place. If damage is suspected, discontinue use and contact customer service.

## SPECIFICATIONS

Detailed specifications for the OVENTE Double Drip Coffee Maker CMDD2MB:

- **Model Number:** CMDD2MB
- **Brand:** OVENTE
- **Capacity:** 0.25 Liters
- **Wattage:** 450 watts
- **Dimensions (D x W x H):** 12" x 12" x 8" (approximate)
- **Color:** Black
- **Material:** Plastic
- **Coffee Input Type:** Ground Coffee Only
- **Filter Type:** Reusable Nylon Filter (Paper filter compatible)
- **Special Feature:** Auto Shut-Off (after 7 minutes)
- **Included Components:** Coffee Maker, Reusable Filter, 2 Ceramic Mugs, User Manual



Image: A diagram illustrating the approximate dimensions of the coffee maker: 5.5 inches wide, 7.75 inches high, and 6.25 inches deep.

## WARRANTY

The OVENTE Double Drip Coffee Maker CMDD2MB comes with a **1-year warranty** from the original purchase date.

- This warranty covers defects in material and workmanship under normal use and conditions.
- Proof of purchase is required for warranty claims.
- This warranty does not cover damage resulting from misuse, neglect, accident, alteration, or unauthorized repair.



Image: A badge indicating a 'Premium 1 Year OVENTE Warranty' is displayed next to the coffee maker.

## CUSTOMER SUPPORT

---

For any questions, concerns, or assistance with your OVENTE Double Drip Coffee Maker, please contact OVENTE customer service. Our US-based customer service team is available to help you.

Please refer to the contact information provided on the OVENTE official website or your product packaging for the most up-to-date support details.