

[manuals.plus](#) /

› [Etekcity](#) /

› [Etekcity Portable 6-Blade USB Rechargeable Juicer Blender User Manual \(Model BVX1\)](#)

Etekcity BVX1

Etekcity Portable 6-Blade USB Rechargeable Juicer Blender User Manual

Model: BVX1

1. PRODUCT OVERVIEW

The Etekcity Portable 6-Blade USB Rechargeable Juicer Blender is designed for convenient preparation of juices, smoothies, and shakes on the go. Its compact size and USB charging capability make it suitable for various environments, including school, office, parks, and camping.



Image 1.1: The Etekcity Portable Juicer Blender (Red) with ingredients.

Key Features:

- **Portable & Lightweight Design:** Easy to carry for various activities.
- **USB Rechargeable:** Built-in battery charges via any USB port (power bank, laptop, car, adapter).
- **6-Blade System:** Efficient blending for fruits, vegetables, and more.
- **Easy to Clean:** Detachable parts facilitate simple cleaning and maintenance.
- **Safety Lock Mechanism:** Prevents accidental operation for user safety.

2. SAFETY INSTRUCTIONS

Please read and understand all safety instructions before using the appliance to prevent injury or damage.

- Do not immerse the motor base in water or other liquids.
- Keep hands and utensils out of the blender jar while blending to prevent injury.
- Ensure the lid is securely fastened before operating the blender.
- Do not operate the blender if the blades are damaged or if the unit appears to be malfunctioning.
- Keep out of reach of children.
- Only use the provided charging cable or a certified USB cable for charging.
- Avoid overfilling the blender jar. Do not exceed 80% capacity.
- Do not attempt to blend hard items like whole nuts, coffee beans, or frozen solid fruits without sufficient liquid, as this may damage the blades or motor.
- Always ensure the blender is fully assembled and the safety lock is engaged before starting.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your Etekcity Portable Juicer Blender.



Image 3.1: Exploded view of the portable juicer blender components.

1. **Cap:** Top cover with a carrying strap.
2. **Strainer:** Integrated filter for smoother drinks.
3. **Jar (380ML):** Food-grade PC material container for ingredients.
4. **Six Blades 3D Blade:** Stainless steel blade assembly for efficient blending.
5. **IN/OFF Button:** Power button to operate the blender.
6. **LED Indicator:** Light indicating power and charging status.
7. **USB Port:** For charging the internal battery.

4. SETUP AND CHARGING

Initial Charge:

Before first use, fully charge the blender. The unit may arrive with a low battery. Connect the provided USB charging cable to the blender's USB port and a power source (e.g., USB wall adapter, power bank, laptop). Charging typically takes 3-5 hours.

USB RECHARGEABLE Portable for home, office, traveling, picnic ect.

2200mAh Battery

Charging about 3-5 hours



Power Bank



Charging Adapter



Car

Easy to carry
no water leakage



Laptop



Image 4.1: USB charging options for the portable blender.

Assembly:

Ensure all components are clean before assembly. Place the blade assembly onto the motor base, then screw the jar onto the blade assembly. Finally, secure the cap onto the jar.

5. OPERATING INSTRUCTIONS

Follow these steps to prepare your beverages:



Image 5.1: Step-by-step guide for operating the portable juicer blender.

- 1. Prepare Ingredients:** Cut fruits or other ingredients into small chunks (approximately 1-2 cm).
- 2. Load Ingredients:** Place the cut ingredients into the blender jar. Do not fill more than 80% of the jar's capacity.
- 3. Add Liquid:** Add a small amount of liquid such as water, milk, or yogurt. This aids in blending and prevents the motor from straining.
- 4. Secure Lid:** Ensure the cap is tightly secured onto the jar.
- 5. Start Blending:** Double-click the ON/OFF button to start the blending cycle.
- 6. Shake Gently:** During blending, gently shake the blender to ensure all ingredients are thoroughly mixed.

7. **Finish:** The blender will automatically stop after a cycle, or you can press the ON/OFF button once to stop it manually.
8. **Serve:** Open the cap and pour out your freshly blended juice or smoothie.

Recommended Uses:



Image 5.2: Versatile applications of the Etekcity Portable Juicer Blender.

- Fresh Fruit Juice
- Smoothies
- Baby Food
- Natural Face Masks
- Vegetable Juice
- Milk Shakes

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your blender.

- **Disassembly:** Separate the jar from the motor base. The cap and strainer can also be detached.

- **Washing:** Wash the jar, cap, and blade assembly with warm, soapy water. Use a brush if necessary to clean around the blades.
- **Motor Base:** Wipe the motor base with a damp cloth. Do not submerge it in water.
- **Drying:** Ensure all parts are thoroughly dried before reassembling or storing.
- **Storage:** Store the blender in a clean, dry place.



Image 6.1: Portable juicer blender with a cleaning brush.

7. TROUBLESHOOTING

If you encounter issues with your Etekcity Portable Juicer Blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not start.	Low battery, improper assembly, safety lock not engaged.	Charge the blender fully. Ensure the jar is securely attached to the motor base. Double-click the ON/OFF button to start.

Problem	Possible Cause	Solution
Blades stop during operation.	Overloaded, ingredients too large/hard, low battery.	Reduce ingredient quantity. Cut ingredients into smaller pieces. Add more liquid. Recharge the blender.
Leakage from the jar.	Lid not properly sealed, jar not tightened, damaged seal.	Ensure the cap is tightly screwed on. Verify the jar is securely fastened to the blade assembly and motor base. Check the silicone seal for damage and ensure it is correctly seated.
Poor blending results.	Insufficient liquid, ingredients too large, overfilling.	Add more liquid. Cut ingredients smaller. Do not overfill the jar. Shake gently during blending.

8. SPECIFICATIONS

Detailed technical specifications for the Etekcity Portable Juicer Blender.



Healthy nutrition



Image 8.1: Dimensions of the portable juicer blender.


- **Brand:** Etekcity
- **Model Number:** BVX1
- **Color:** REDQ1 (Red)
- **Product Dimensions:** 100D x 40W x 60H Millimeters (Approx. 3.94D x 1.57W x 2.36H inches)
- **Item Weight:** 249 g
- **Power Source:** Battery Powered (USB Rechargeable)
- **Included Components:** Charging Cable
- **Jar Capacity:** Approximately 380ml

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact Etekcity customer service. Keep your purchase receipt as proof of purchase.

For further assistance, please visit the official Etekcity website or refer to the contact information provided with your product packaging.

Related Documents - BVX1

	<p>Etekcity EB4074S Digital Body Weight Scale User Manual</p> <p>User manual for the Etekcity EB4074S Digital Body Weight Scale, providing comprehensive guidance on setup, operation, safety precautions, maintenance, specifications, troubleshooting, and warranty information. Contact Etekcity Corporation for support.</p>
	<p>Etekcity ESF-551</p> <p>Etekcity ESF-551</p>
	<p>Etekcity Luminary Küchenwaage EKS-L221-SEU: Bedienungsanleitung & Technische Daten</p> <p>Die Etekcity Luminary Küchenwaage (Modell EKS-L221-SEU) Bedienungsanleitung bietet detaillierte Informationen zu technischen Daten, Sicherheit, Bedienung, Fehlerbehebung und Garantie. Erfahren Sie, wie Sie Ihre Küchenwaage optimal nutzen.</p>
	<p>Etekcity EK9000 Digital Kitchen Scale Warranty Information</p> <p>Detailed warranty terms and conditions for the Etekcity EK9000 Digital Kitchen Scale, covering product details, warranty policy, exclusions, and customer support contact information.</p>

 <p>ETEKCITY</p> <p>User Manual</p> <p>Digital Kitchen Scale</p> <p>Model: EK7090</p> <p>Questions or Concerns? Email: customerservice@etekcity.com • 855-595-2535</p>	<p><u>Etekcity EK7090 Digital Kitchen Scale User Manual</u></p> <p>Comprehensive user manual for the Etekcity EK7090 Digital Kitchen Scale, detailing specifications, safety guidelines, operating instructions, unit conversion, tare function, troubleshooting, and warranty information.</p>
 <p>ETEKCITY</p> <p>Digital Kitchen Scale</p> <p>Model: EK5250</p> <p>Questions or Concerns? Email: customerservice@etekcity.com • 855-595-2535</p>	<p><u>Etekcity EK5250 Digital Kitchen Scale User Manual</u></p> <p>User manual for the Etekcity EK5250 Digital Kitchen Scale, providing detailed information on setup, operation, safety, maintenance, troubleshooting, and warranty.</p>