

GiveBest PT910EO

GiveBest PT910EO Portable Electric Space Heater User Manual

Model: PT910EO

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Use handles when moving this heater.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Always unplug heater when not in use.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Discard heater, or return to authorized service facility for examination and/or repair.
- Do not use outdoors.
- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable vapors or liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always plug into a grounded wall outlet.

SETUP

Unboxing and Initial Inspection

Carefully remove the GiveBest PT910EO Space Heater from its packaging. Inspect the unit for any signs of damage. Ensure all components, including the remote control, are present.

Remote Control Battery Installation

The remote control requires 2 AAA batteries (not included). Open the battery compartment on the back of the remote and insert the batteries, observing correct polarity. Close the compartment securely.

Power Connection

Place the heater on a firm, level surface. Uncoil the power cord and plug it directly into a standard 120V AC wall outlet. The unit will emit a beep sound upon successful connection, indicating it is in standby mode.

Heats Faster Runs Safer

2S
Fast Heating

75%
Air Heating Volume



**Horizontal
PTC Design**

Image: Internal view of the GiveBest PT910EO Space Heater, highlighting its PTC ceramic heating elements and fan for rapid heat distribution.

The GiveBest PT910EO Space Heater can be operated using the touch control panel on the top of the unit or via the included remote control.

Power On/Off

- **Touch Panel:** Press the power symbol button () on the top panel.
- **Remote Control:** Press the power button () on the remote.

When powering off, the heater will initiate a 30-second countdown, during which the fan will continue to run to cool down the heating elements before completely shutting off. This is a safety feature to prevent overheating.

Adjusting Temperature

The heater allows temperature adjustments in 1°F increments from 41°F to 95°F.

- **Touch Panel:** Use the '+' and '-' buttons to increase or decrease the desired temperature.
- **Remote Control:** Use the '+' and '-' buttons on the remote.

Operating Modes

Cycle through the available modes (Power, ECO, Fan) using the mode button () on the touch panel or remote.

- **Power Mode (P1, P2, P3):** Provides continuous heating at different power levels (P1: low, P2: medium, P3: high/1500W).
- **ECO Mode:** The heater will automatically adjust its heat output to maintain the set temperature, optimizing energy consumption. The display shows the current room temperature.
- **Fan Mode:** Circulates air without heating, functioning as a cooling fan.

ECO Mode Automatically Adjusts Heat Output



Image: The GiveBest PT910EO Space Heater operating in ECO Mode, displaying the set temperature and indicating its energy-efficient operation via a precise thermal sensor.

Oscillation Function

The 70° oscillation function distributes heat evenly across the room.

- **Touch Panel:** Press the oscillation button (🌀) to activate or deactivate oscillation.

- **Remote Control:** Press the oscillation button (🌀) on the remote.

Timer Setting

Set the heater to automatically turn off after a specified duration (1 to 12 hours).

- **Touch Panel:** Press the timer button (⏰) and then use '+' or '-' to set the desired hours.
- **Remote Control:** Press the timer button (⏰) and then use '+' or '-' on the remote.

Child Lock

Activate the child lock to prevent accidental changes to settings.

- **Touch Panel:** Press and hold the child lock button (🔒) for 3 seconds to activate/deactivate.
- **Remote Control:** Press the child lock button (🔒) on the remote.

Display Light Control

Turn off the display lights for undisturbed sleep or in low-light environments.

- **Touch Panel:** Press the display light button (💡) to toggle the display lights.
- **Remote Control:** Press the display light button (💡) on the remote.

Remote Control from Anywhere




Image: The GiveBest PT910EO Space Heater being controlled remotely, showing the physical remote and a smartphone app interface for convenient operation.

Cleaning

Always unplug the heater before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents. Ensure the heater is completely dry before plugging it back in.

Storage

When not in use, store the heater in a cool, dry place. It is recommended to store it in its original packaging to protect it from dust and damage.

TROUBLESHOOTING

Heater Does Not Turn On

- Ensure the power cord is securely plugged into a working outlet.
- Check if the master power switch (if applicable) is in the 'ON' position.
- Verify that the room temperature is below the set temperature in ECO mode.

Heater Shuts Off Unexpectedly

- The heater may have activated its **tip-over protection**. Ensure the heater is on a stable, flat surface. If it was tipped, place it upright, and it should resume operation.
- The **overheat protection** may have been triggered. Unplug the heater, allow it to cool down for 30 minutes, and then plug it back in. Ensure there are no obstructions blocking the air intake or exhaust vents.

Comprehensive Safety Protection



The GiveBest PT910EO Space Heater is shown in a cozy living room setting. The heater is white with a black control panel and a digital display showing 95°F. It is emitting a warm orange glow. A woman and a young boy are sitting on a rug in front of a large window, looking out at a snowy winter landscape. The heater's digital display shows 95°F.

 122°F Overheat Protection	 ETL Listed	 Enhanced Safety Plug	 Cool Touch Housing
 V-O Flame Retardant Material		 Child Lock	 Heavy Duty Mount

Image: The GiveBest PT910EO Space Heater showcasing its comprehensive safety features, including tilt-detection, V-0 flame retardant materials, ETL certification, overheat protection, and child lock.

SPECIFICATIONS

Brand	GiveBest
Model Number	PT910EO
Power	1500W
Heating Technology	PTC Ceramic
Heating Area	Up to 200 sq ft
Temperature Range	41°F - 95°F
Oscillation	70° Wide-Angle
Timer	1-12 Hours
Noise Level	Approx. 30dB
Safety Features	Tilt-Detection, Overheat Protection, V-0 Flame Retardant Materials, ETL Certified, Child Lock
Dimensions	10.44 x 6.89 x 6.85 inches
Item Weight	3.18 pounds

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your product or contact GiveBest customer service directly. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question