

manuals.plus /

- › [OLEVS](#) /
- › [OLEVS G3661 Men's Quartz Chronograph Watch Instruction Manual](#)

**OLEVS G3661**

# OLEVS G3661 Men's Quartz Chronograph Watch Instruction Manual

Model: G3661

## INTRODUCTION

---

Thank you for choosing the OLEVS G3661 Men's Quartz Chronograph Watch. This manual provides essential information for the proper setup, operation, and maintenance of your timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.



Image: The OLEVS G3661 watch, featuring a gold and black two-tone design, displayed on a wrist.

## SETUP

---

### 1. Setting Time, Date, and Moon Phase

- 1. Time Adjustment:** Pull the crown out to the furthest position. Rotate the crown to set the hour and minute hands to the correct time. Push the crown back in to secure the setting.
- 2. Date and Moon Phase Adjustment:** Pull the crown out to the first position. Rotate the crown to adjust the date and moon phase display. Ensure the date changes at midnight, not noon. Push the crown back in to secure the setting.



Image: A diagram illustrating the crown positions for adjusting the watch's time, date, and moon phase functions.

## 2. Bracelet Adjustment

The stainless steel bracelet can be adjusted to fit your wrist. The watch comes with adjustment tools for removing or adding links. If you are unsure, it is recommended to have a professional jeweler adjust the bracelet.

## OPERATING YOUR WATCH

---

### 1. Timekeeping

Your OLEVS G3661 watch is equipped with a precise analog quartz movement, ensuring accurate timekeeping.

### 2. Chronograph Function

The chronograph function allows for elapsed time measurement.

- **Start/Stop:** Press the upper pusher button to start the chronograph. Press it again to stop.
- **Reset:** Press the lower pusher button to reset the chronograph hands to zero. The chronograph hands will typically reset by moving backward.

### 3. Luminous Display

The watch features luminous hands and hour markers for improved visibility in low-light conditions. The luminous material absorbs light and emits a glow, allowing for easy time reading day and night.



Image: The watch face displaying its luminous hands and markers glowing in a dark environment.

## MAINTENANCE

### 1. Water Resistance

This watch is water-resistant up to 30 meters (3 ATM), suitable for daily use such as splashes, rain, or handwashing. It is **not** suitable for swimming, diving, or showering, as prolonged exposure to water or high-pressure water jets can compromise the seals.

<p><b>HIGH HARDNESS LENSES</b></p> <p>Clear vision, strong light transmission, wear-resistant, anti-scratch, waterproof</p>		<p><b>30 METERS WATERPROOF</b></p> <p>This watch is water-resistant to 30M, can withstand daily splash and short immersion in water</p>
	<p><b>LUMINOUS DISPLAY</b></p> <p>HD Luminous coating preferred material short absorption, strong luminescence</p>	

Image: The watch shown with water splashing, illustrating its 30-meter water resistance for daily splashes.

### 2. Cleaning and Care

- Wipe the watch regularly with a soft, dry cloth to remove dust and smudges.
- Avoid exposing the watch to extreme temperatures, direct sunlight for extended periods, or strong magnetic fields.
- The watch features a high-hardness coated glass mirror, which is wear-resistant and scratch-resistant. However, avoid impacts that could damage the crystal.



Image: A diagram highlighting the properties of the watch's coated mirror, emphasizing its clarity and resistance to scratches.

## TROUBLESHOOTING

Issue	Possible Cause	Solution
Watch stops or loses time	Depleted battery; internal movement issue.	Replace the battery (recommended by a professional). If issue persists, seek professional service.
Chronograph hands do not reset to zero	Chronograph hands require calibration.	Pull the crown out to the furthest position. Press the lower pusher button repeatedly until the chronograph hands align to the 12 o'clock position. Push the crown back in.
Date function is not working	Internal mechanism fault.	Contact customer support for assistance or professional repair.

## SPECIFICATIONS

- **Model Number:** C-YKS-S-G3661GH-JH
- **Movement:** Analog Quartz

- **Case Material:** Stainless Steel (Two-tone: Gold and Black)
- **Band Material:** Stainless Steel
- **Mirror Material:** High Hardness Coated Glass
- **Functions:** Time (Hour, Minute, Second), Chronograph, Moon Phase, Date
- **Water Resistance:** 30 Meters (3 ATM)
- **Product Dimensions:** 20 x 4.1 x 4.2 cm
- **Weight:** 190 g
- **Country of Origin:** China



Image: The reverse side of the OLEVS G3661 watch, displaying the stainless steel back with engraved brand logo and water resistance information.

## WARRANTY AND SUPPORT

---

For any queries regarding your OLEVS G3661 watch, including setup, features, or potential issues, please contact OLEVS customer support. Our team is available to provide assistance and ensure a satisfactory experience with your product.

Please refer to your purchase documentation for specific warranty terms and contact information.

