

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TESSAN](#) /

› [TESSAN WS-T188LP Wireless Portable Charger Qi2 Instruction Manual](#)

TESSAN WS-T188LP

TESSAN WS-T188LP Wireless Portable Charger Qi2 Instruction Manual

Model: WS-T188LP



INTRODUCTION

Thank you for choosing the TESSAN WS-T188LP Wireless Portable Charger Qi2. This device is designed to provide convenient and efficient power to your compatible electronic devices. Please read this manual thoroughly before use to ensure proper operation and to maximize the lifespan of your product.



Image: TESSAN WS-T188LP Wireless Portable Charger Qi2, showing its compact design and integrated USB-C cable.

PRODUCT FEATURES

- **Strong Magnetic Wireless Charging:** Securely attaches to compatible iPhones (17/16/15/14 series) and other Qi-enabled devices for stable, cord-free power. Features automatic coil alignment for uninterrupted charging.
- **Qi2 Certified 15W Fast Charging:** Delivers ultra-fast 15W wireless charging, twice the speed of standard wireless chargers. Supports simultaneous charging of two devices with 15W wireless and 35W USB-C wired output.
- **High-Capacity & Portable Design:** 10,000mAh capacity provides multiple full charges for most smartphones. Compact size and foldable kickstand enhance portability and hands-free viewing.
- **Built-in USB-C Cable:** An integrated USB-C cable is included for convenient wired charging and for recharging the power bank itself.
- **Built-in Foldable Stand:** Allows for hands-free viewing of your device while charging, supporting both horizontal and vertical orientations.
- **Wide Compatibility:** Compatible with MagSafe cases, AirPods, Samsung Galaxy devices, and all Qi-certified gadgets.

- **Flight-Safe:** Designed to meet airline carry-on regulations for safe travel.
- **Advanced Safety Protection:** Offers protection against overheating, short circuits, and over-discharge for safe charging.

SETUP

1. Charging the Power Bank

Before initial use, fully charge your TESSAN WS-T188LP power bank. Use the built-in USB-C cable or an external USB-C cable connected to a compatible power adapter (not included). The LED display will show the charging progress.

Safety Charging

The 10,000mAh Mag-Safe power bank has multi-protect safety, temp control, over-discharge, overcurrent, shorts, ensuring device security.



Image: The TESSAN power bank connected to a USB-C cable for recharging, with an arrow indicating 35W max input.

2. Checking Battery Level

Press the power button once to view the current battery percentage on the LED display. The display will show the remaining capacity.



Wide Compatible



Note: Please check what the maximum wireless charging power of the device is before use, the maximum supported wireless charging power is 15W

Image: The TESSAN power bank with a smartphone magnetically attached, showing the LED display with battery capacity percentage.

OPERATING INSTRUCTIONS

1. Wireless Charging (MagSafe Compatible)

1. Ensure your device is Qi-enabled and MagSafe compatible (for magnetic attachment).

2. Align your device with the magnetic charging area on the power bank. The magnets will securely attach the device.
3. The power bank will automatically begin 15W wireless charging.

Qi2 15W Wireless Charging

2X Faster



Note: Qi 2 Certified 15W wireless charging is 2X faster than 7.5W for iPhone models. Data based on TESSAN internal testing.

Image: An iPhone magnetically attached to the TESSAN power bank, displaying the charging animation, highlighting 15W wireless charging.

Note: For optimal magnetic attachment and charging efficiency, use a MagSafe compatible case or no case. Non-magnetic cases may hinder performance.

Compatible Magnetic Cases



Magnetic Cases 



Non-Magnetic 



Image: An illustration showing magnetic cases are compatible with the power bank, while non-magnetic cases are not recommended for magnetic attachment.

2. Wired Charging

1. Pull out the built-in USB-C cable from its storage slot.
2. Connect the USB-C cable to your device's charging port.
3. The power bank will automatically begin 35W wired charging.

Built in USB-C Cable



Image: A smartphone being charged by the TESSAN power bank using its integrated USB-C cable, indicating 35W fast charging.

3. Simultaneous Charging

The TESSAN WS-T188LP supports charging two devices simultaneously: one wirelessly via the magnetic pad and another via the built-in USB-C cable.



Image: The TESSAN power bank simultaneously charging an iPhone wirelessly and AirPods via the built-in USB-C cable, demonstrating multi-device charging capability.

4. Using the Built-in Stand

The power bank features a foldable kickstand for hands-free viewing. Simply pull out the stand from the back of the device. You can position your phone vertically or horizontally on the stand while it charges wirelessly.

Built-in Stand Design

Wireless Charging (15W Max)

Foldable Stand



Work



Facetime



Leisure



Vacation



Image: A collage showing the TESSAN power bank's foldable stand in use, supporting a smartphone for work, FaceTime, leisure, and travel.

Your browser does not support the video tag.

Video: Demonstration of the TESSAN WS-T188LP Portable Charger, highlighting its magnetic attachment and built-in stand functionality.

MAINTENANCE

- Keep the power bank away from water, fire, and high temperatures.
- Avoid dropping or subjecting the device to strong impacts.
- Clean the device with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Store the power bank in a cool, dry place when not in use.
- Recharge the power bank at least once every three months to maintain battery health.

TROUBLESHOOTING

- **Device not charging:**
 - Ensure the power bank is sufficiently charged.
 - Verify that your device is properly aligned with the magnetic charging area or securely connected via the USB-C cable.
 - Check if your device is Qi-enabled and compatible with the power bank.
 - Remove any non-MagSafe compatible cases that may interfere with wireless charging.
- **Slow charging:**
 - Ensure your device supports fast charging.
 - Check for proper alignment during wireless charging.
 - Avoid using your device heavily while charging.
- **Power bank overheating:**
 - Charging may temporarily pause if the device or power bank becomes too hot. This is a safety feature. Allow it to cool down before resuming.
 - Ensure adequate ventilation around the device and power bank during charging.

SPECIFICATIONS

Model Number	WS-T188LP
Battery Capacity	10,000mAh
Wireless Charging Output	15W (Qi2 Certified)
Wired Output (USB-C)	35W Max
Wired Input (USB-C)	20W Max
Product Dimensions	4.23 x 2.7 x 0.78 inches
Item Weight	9.6 ounces
Color	Grey

SAFETY INFORMATION

- Do not disassemble, open, or shred the power bank.
- Do not expose the power bank to heat or fire. Avoid storage in direct sunlight.
- Do not short-circuit the power bank. Do not store it haphazardly in a box or drawer where other metal objects might short-circuit it.
- Do not subject the power bank to mechanical shock.
- In the event of a leak, do not allow the liquid to come into contact with the skin or eyes. If contact has been made, wash the

affected area with copious amounts of water and seek medical advice.

- Keep the power bank out of reach of children.
- Only use the power bank for its intended purpose.
- Dispose of the power bank in accordance with local regulations.

WARRANTY AND SUPPORT

TESSAN products come with a standard manufacturer's warranty. For detailed warranty information, product support, or any inquiries, please visit the official TESSAN website or contact our customer service team. Keep your purchase receipt for warranty claims.

Contact Information: Please refer to the product packaging or the official TESSAN website for the most up-to-date contact details.

© 2025 TESSAN. All rights reserved.