chartustriable DJ0870

chartustriable 2 Doors Armoire Wardrobe Closet with LED and Mirror

Model: DJ0870

Important Safety Information

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- Always secure the cabinet to the wall using the provided anti-tip safety feature to prevent tipping. This is crucial for safety, especially in households with children or pets.
- Exercise caution when handling heavy components and the mirror to avoid injury. It is recommended to assemble this unit with at least two people.
- Ensure all screws and fasteners are tightened securely during assembly. Periodically check for loose connections.
- Do not overload shelves or hanging rods. Distribute weight evenly.
- Keep electrical components (LED light, USB charging cable) away from water and moisture.

Product Overview

The chartustriable 2 Doors Armoire Wardrobe Closet with LED and Mirror is a freestanding storage solution designed for bedrooms and other living spaces. It features a durable engineered wood construction, two doors (one with a mirror, one with tempered glass), two storage drawers, and an integrated LED sensor light.



Image: Front view of the wardrobe, highlighting its overall dimensions (31.5"W x 19.7"D x 71"H).

Key Features:

- **Integrated LED Sensor Light:** Equipped with a human body intelligent induction light that turns on when the door is opened and off when closed. The induction range is within 5 meters. The LED light is USB rechargeable and can last 3-5 months on a single charge.
- **Visual High-Definition Tempered Glass Door:** Provides a clear view of stored items, making it easy to locate clothes and accessories.
- **Functional Mirror:** One door features a mirror, offering convenience for checking outfits and visually expanding the room space.
- **Sturdy Construction:** Made from P2 engineered wood and metal, with a stable floor-standing base. Includes an anti-tip safety feature.
- **Flexible Storage:** Divided into a hanging area, stacking area, and top box area, along with two large storage drawers, to accommodate various clothing and item types.



Image: Diagram showing the internal organization of the wardrobe, including hanging space, drawer storage, and top shelf for less frequently used items.

Setup and Assembly

Assembly is required for this product. It is recommended that two adults perform the assembly due to the product's weight (approximately 126 pounds) and size. Instructions for assembly are included with the product packaging.

Before You Begin:

- Unpack all components and verify against the parts list provided in the separate assembly instructions.
- Ensure you have the necessary tools (e.g., screwdriver, hammer).
- Clear a spacious, clean area for assembly to prevent damage to components.

Assembly Video:

Your browser does not support the video tag.

Video: Detailed assembly guide for the 2 Doors Armoire Wardrobe Closet with LED and Mirror. This video demonstrates step-by-step construction, including hardware installation and component assembly, to assist users in setting up their new wardrobe.

Anti-Tipping Device Installation:

After assembly, it is mandatory to install the anti-tipping device. Follow the specific instructions provided in your assembly manual to securely fasten the wardrobe to a wall stud. This prevents accidental tipping and ensures safety.



Image: Detail of the anti-tipping device, along with the hardware clothes rail and visible high gloss door, and large storage drawers.

Operating Instructions

Using the LED Sensor Light:

- The LED light is motion-activated. It will automatically turn on when the wardrobe door is opened and turn off when the door is closed.

- The sensor has an effective range of approximately 5 meters.
- To charge the LED light, use the included USB charging cable. A full charge can provide power for 3-5 months of typical use.



Image: Detail of the LED sensor light mounted inside the wardrobe, demonstrating its illumination when the door is open.

Door and Drawer Operation:

- The wardrobe features two doors with magnetic closures. Gently push the doors to ensure they close completely.
- The two bottom drawers slide smoothly on their tracks. Pull the handles to open and push to close. Avoid forcing the drawers.



Image: Interior view of the wardrobe with doors open, showcasing the hanging area and the two lower drawers filled with folded garments.

Maintenance

- **Cleaning the Surface:** Wipe the engineered wood surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Cleaning Glass and Mirror:** Use a standard glass cleaner and a lint-free cloth for the tempered glass door and mirror. Spray cleaner onto the cloth, not directly onto the surface, to prevent liquid from seeping into edges.
- **LED Light:** Recharge the LED light as needed using the provided USB cable. Do not attempt to disassemble the LED unit.
- **Hardware:** Periodically check all screws and fasteners for tightness. Retighten if necessary to maintain stability.

Troubleshooting

Problem	Possible Cause	Solution
LED light does not turn on.	Battery is low or discharged; sensor is obstructed; light is faulty.	Charge the LED light using the USB cable. Ensure the sensor area is clear. If the issue persists after charging, contact customer support.
Doors do not close properly.	Misalignment during assembly; loose hinges; weak magnets.	Check door alignment and adjust hinges if necessary. Ensure all hinge screws are tight. Verify magnets are properly installed and functional.
Wardrobe feels wobbly or unstable.	Loose fasteners; uneven floor; anti-tip device not installed.	Retighten all assembly screws. Ensure the wardrobe is on a level surface. Install the anti-tip device securely to the wall.
Missing parts or damaged components.	Packaging error; shipping damage.	Do not proceed with assembly. Contact the seller or manufacturer immediately for replacement parts.

Specifications

Feature	Detail
Brand	chartustriable
Model Number	DJ0870
Product Dimensions (D x W x H)	19.7" x 31.5" x 71"
Item Weight	126 Pounds
Material	Engineered Wood
Color	Black
Number of Doors	2
Number of Drawers	2
Number of Shelves	1 (adjustable)
Additional Features	LED Sensor Light, Mirror, Anti-Tipping Device
Installation Type	Freestanding
Required Assembly	Yes

Warranty and Support

Warranty information for this product may vary. Please refer to the documentation included with your purchase or contact the seller directly for details regarding warranty coverage and claims.

For technical assistance, missing parts, or any other inquiries, please contact the seller, FUzanni, through the platform

where the product was purchased. Provide your order number and a detailed description of the issue to ensure prompt support.

© 2026 chartustriable. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question