

[Manuals.plus](#) /

› [XIXIMENG](#) /

› XIXIMENG SF3000 Retro Handheld Game Console User Manual

XIXIMENG SF3000

XIXIMENG SF3000 Retro Handheld Game Console User Manual

Model: SF3000

INTRODUCTION

The XIXIMENG SF3000 is a versatile retro handheld game console designed for entertainment on the go. It features a 4.5-inch IPS screen, a dual-core processor, and comes pre-loaded with over 20,000 classic games across more than 14 mainstream emulators. Beyond gaming, this device supports video playback, e-book reading, music playback, and can even function as an emergency power bank for mobile phones. This manual provides detailed instructions for setting up, operating, and maintaining your SF3000 console.

PACKAGE CONTENTS

Ensure all items are present in the package:

- SF3000 emulator handheld
- USB Cable
- Type-C Adapter
- Instructions (this manual)



Image: The SF3000 console, USB cable, Type-C adapter, and instruction manual are included in the package.

PRODUCT OVERVIEW

Console Layout and Controls

BUTTON FUNCTION



Image: Top and front view of the SF3000 console, highlighting directional keys, function keys (A, B, X, Y), SELECT, START, joysticks, extended keys (L, R), ON/OFF switch, TF socket, DC/OTG port, earphone port, and volume key.

- **Directional Keys:** For movement and menu navigation.
- **Function Keys (A, B, X, Y):** For in-game actions.
- **SELECT Button:** Used for menu selections and in-game functions.
- **START Button:** Used to begin games and confirm selections.
- **Analog Joysticks:** For precise movement control in supported games.
- **Extended Keys (L, R):** Shoulder buttons for additional in-game controls.
- **ON/OFF Switch:** Power button for the console.
- **TF Socket:** Slot for a TF (MicroSD) card to expand storage.
- **DC/OTG Port:** USB Type-C port for charging and OTG functionality.
- **Earphone Port:** 3.5mm jack for audio output.
- **Volume Key:** Adjusts the audio output level.

Display Screen

4.5 INCH HIGH-DEFINITION IPS SCREEN

Screen Resolution:854*480



Image: The SF3000 console showcasing its 4.5-inch IPS high-definition screen with 854*480 resolution.

The console features a 4.5-inch IPS full-viewing angle HD screen with an 854*480 resolution. This display delivers rich colors and clear details. It is protected by ultra-strong fully laminated tempered glass, which is wear-resistant and scratch-resistant, and effectively reduces reflections. Screen brightness can be adjusted to suit different environments.

Integrated Stand



Image: The SF3000 console with its integrated foldable stand extended, providing stable support.

The back of the console includes a foldable stand. This stand can be unfolded to provide stable support, ideal for hands-free viewing of videos or for desktop gaming. It folds back flush with the console for convenient handheld use and storage.

SETUP

1. **Initial Charge:** Before first use, it is recommended to fully charge the console using the provided USB Type-C cable and adapter. Connect the Type-C cable to the DC/OTG port on the console and the other end to the adapter, then plug into a power outlet.
2. **Power On:** Press and hold the **ON/OFF** button located on the top of the console to power it on. The console will boot up and display the main menu.
3. **Language Selection (if applicable):** If prompted, select your preferred language using the directional keys and A button.
4. **Explore Games:** Once powered on, you can navigate the vast game library using the directional keys and analog joysticks.

OPERATING INSTRUCTIONS

Power On/Off

- To turn on: Press and hold the **ON/OFF** button.
- To turn off: Press and hold the **ON/OFF** button until the power-off prompt appears, then confirm.

Gaming

1. **Selecting a Game:** From the main menu, use the directional keys or joysticks to browse through the game categories and titles. Press the **A** button to select a game.
2. **Starting a Game:** After selecting a game, press the **START** button to launch it.
3. **Saving and Loading Game Progress:** To save or load your game progress, press and hold **SELECT + START** simultaneously during gameplay. This will bring up a menu where you can choose to save your current state or load a previously saved state.



Image: The SF3000 console highlighting its core functions: access to over 20,000 games, support for two players, OTG functionality, and video playback.

Media Playback (E-Book, Music, Video)

The SF3000 supports various multimedia functions:

- Navigate to the respective E-Book, Music, or Video sections from the main menu.
- Select your desired file from the storage. The console is compatible with a variety of mainstream formats.
- Use the console's controls for playback (play, pause, skip, volume adjustment).

Two-Player Mode

The console supports a two-player game mode. Connect compatible external controllers (not included) via the OTG function to enjoy multiplayer gaming with friends or family.



Image: The SF3000 console illustrating its dual functionality: game mode for two players and emergency charging mode for a mobile phone.

OTG Functionality

The SF3000 supports On-The-Go (OTG) functionality, allowing you to connect external devices such as USB flash drives for expanded storage or joysticks for alternative control methods. Connect these devices to the DC/OTG port using an appropriate OTG adapter (if required).

Emergency Phone Charging

The console can act as an emergency power bank. Connect your mobile phone to the console's DC/OTG port using a compatible USB cable to charge your phone when its battery is low.

SF3000 - 2025 Dual-Joystick Retro Handheld Game Console

XIXIMENG

64G
TF Card

20000+
Games



4.5-inch IPS
full-view full HD screen

Support double
rocker

854*480
Resolution
854*480

Video playback

E-book reading

Music Playback

Emergency charging
of mobile phone

Image: The SF3000 console demonstrating its emergency charging capability for a mobile phone, powered by its 3000mAh battery.

MAINTENANCE

- **Cleaning:** Keep the console clean by using a soft, dry cloth. Avoid using harsh chemicals, abrasive cleaners, or solvents, as these may damage the screen or the body of the console.
- **Storage:** When not in use, store the console in a cool, dry place away from direct sunlight and extreme temperatures.
- **Charging:** Always use the original USB Type-C cable and adapter or a high-quality compatible cable for charging to ensure safe and efficient power delivery.

TROUBLESHOOTING

- **Console Not Turning On:**
 - Ensure the battery is charged. Connect the console to a power source and allow it to charge for at least 30 minutes before attempting to power on again.
 - Press and hold the ON/OFF button for a few seconds to ensure it registers.
- **Games Not Loading or Lagging:**
 - Ensure the TF card is properly inserted into the TF socket.
 - The console's built-in games do not support user-initiated system changes or updates. Attempting to modify the system may cause issues.
 - If issues persist, contact customer support for assistance.
- **Screen Issues (No Display, Flickering):**
 - Check if the console is powered on.
 - Adjust the screen brightness using the dedicated controls.
 - If the screen remains unresponsive or displays abnormalities, contact customer support.

• **Audio Problems (No Sound, Distorted Sound):**

- Adjust the volume using the volume key.
- Ensure headphones are properly connected if using the earphone port.
- Test with different headphones or without headphones to isolate the issue.

Important Note: The gaming consoles with built-in games do not support users to change or update the system by themselves, nor to refresh the system. If you encounter any problems during use, please contact customer support for assistance.

SPECIFICATIONS

Model Number	SF3000
Screen Size	4.5 Inches
Display Type	IPS LCD
Screen Resolution	854*480 HD
Processor	Dual-core (1.2G main frequency)
Memory	2G DDR3
Storage Capacity	64 GB (via TF card)
Battery Capacity	3000mAh Lithium-Ion
Battery Life	5-7 hours (continuous gameplay)
Charging Port	USB Type-C (DC/OTG)
Emulators	14+ mainstream emulators
Number of Players	1-2 (with external controllers)
Dimensions (L x W x H)	3.43" x 1.5" x 7.87"
Material	Plastic

MULTIPLE GAME MODES TO CHANG FREELY, ENJOY THE JOY OF VIDEOS

PLUG IN A USB FLASH DRIVE AND INSTANTLY TURN IT INTO A VIDEO PLAYER.
OPEN THE STAND AND PLACE IT ON THE TABLE TO PREVENT PROLONGED SWEATING



Image: Visual representation of the SF3000's dual-core high-performance processor, indicating its 1.2G main frequency for smooth operation.

SAFETY INFORMATION

- **Temperature Exposure:** Avoid exposing the console to extreme temperatures, direct sunlight, or high humidity for extended periods. This can affect performance and lifespan.
- **Charging Precautions:** Use only the original USB Type-C cable and adapter or high-quality, compatible alternatives for charging. Improper charging equipment can damage the device or pose safety risks.
- **Cleaning:** Refer to the Maintenance section for proper cleaning instructions. Do not use liquids directly on the console.
- **Disassembly:** Do not attempt to disassemble or repair the console yourself. This will void the warranty and may cause damage or injury.
- **Water Exposure:** Keep the console away from water and other liquids.

WARRANTY AND SUPPORT

Your SF3000 Retro Handheld Game Console comes with a comprehensive warranty and dedicated customer support.

- **Return Service:** We offer a one-month return service. You may request a refund if you are not satisfied with the product within this period.
- **Lifetime Warranty:** Enjoy a lifetime worry-free warranty for your console.
- **Customer Support:** If you encounter any problems during use, please contact our customer support team. We aim to respond and resolve issues within 12 hours.
- **Contact Information:** For support, please refer to the contact details provided on the product packaging or the official XIXIMENG website.

