

## EASYmaxx 16411

# EASYmaxx Insect Protect Telescopic Roof Window Fly Screen

Model: 16411

## 1. INTRODUCTION

This manual provides instructions for the installation, operation, and maintenance of your EASYmaxx Insect Protect Telescopic Roof Window Fly Screen. This product is designed to provide effective protection against insects such as mosquitoes, wasps, and spiders, while allowing fresh air into your home through roof windows.

The fly screen features a pre-assembled, extendable aluminum frame and an integrated net, eliminating the need for cutting or drilling during installation. Its semi-transparent fabric ensures good visibility and air circulation. Designed for indoor use, it is weather-protected and durable.

## 2. SAFETY INSTRUCTIONS

- Read all instructions carefully before installation and use.
- Keep packaging materials away from children to prevent suffocation hazards.
- Ensure the fly screen is securely installed to prevent accidental detachment.
- Do not hang heavy objects on the fly screen frame.
- This product is intended for its specified purpose only. Any other use may result in damage or injury.

## 3. PACKAGE CONTENTS

Please check that all items are present and undamaged:

- 1 x Roof Window Mosquito Net (Telescopic Frame with Integrated Net)
- 4 x Spring-loaded Clamping Elements
- 1 x Brush Seal (long, for closing the gap between frame and wall)

- 6 x Edge Protectors

## 4. SETUP AND INSTALLATION

The EASYmaxx Insect Protect fly screen is designed for easy, tool-free installation without drilling, cutting, screwing, or gluing. The extendable frame adapts flexibly to various roof window sizes.

### 4.1 Key Features for Installation

#### Pre-assembled Frame with Integrated Net

The frame comes pre-assembled with the net already integrated, eliminating the need for cutting or waste. The frame is extendable, allowing the net to adapt to your window dimensions.



Image: A graphic illustrating the pre-assembled, extendable frame with integrated net, highlighting that no cutting or waste is required.

#### Easy Installation & Secure Hold

Simply clamp the screen into place. The spring-loaded brackets ensure a perfect fit and secure hold, even with wind or drafts. The all-around brush seal provides maximum protection at the window frame.

# EASY MONTIERT, PERFEKT GESCHÜTZT



Image: A visual representation of the fly screen's adjustable dimensions (min. 63 cm - max. 100 cm width, min. 93 cm - max. 160 cm height), emphasizing no drilling or cutting, and the inclusion of a brush seal.

## 4.2 Step-by-Step Installation

1. **Assemble Corners:** Connect the corners of the frame if not already fully assembled.
2. **Attach Spring-Loaded Brackets:** Secure the spring-loaded clamping elements to the frame. These will hold the screen in place.
3. **Adjust Frame Size:** Extend or retract the telescopic frame to match the exact dimensions of your roof window opening. The net will adapt accordingly.
4. **Insert into Window Frame:** Carefully insert the adjusted fly screen into your roof window opening. The spring-loaded brackets will hold it firmly.
5. **Apply Brush Seal:** Attach the long brush seal around the perimeter of the frame to close any gaps between the screen and the window frame, ensuring maximum insect protection.
6. **Install Edge Protectors:** Apply the self-adhesive edge protectors to areas where the screen might rub against the window when opening, to prevent net damage.

## MIT PRAKTISCHER REISSVERSCHLUSS-ÖFFNUNG



Fenstergriff  
bequem  
bedienen




Image: A series of four illustrations demonstrating the installation process: connecting frame corners, securing spring-loaded brackets, adjusting the flexible frame to window size, and applying the self-adhesive brush seal for complete protection.

### EASYMAXX INSECT PROTECT



Zuverlässiger Luftdurchlass



### STANDARDGEWEBE



Weniger Frischluft




Image: Detailed views of the protective nubs, which are designed to prevent the net structure from being damaged when the window is opened or closed.

## 5. OPERATION

The EASYmaxx Insect Protect fly screen allows full functionality of your roof window while providing continuous insect protection.

### 5.1 Zipper Opening for Window Handle Access

A practical zipper opening is integrated into the net, allowing you to access the window handle at any time without removing the entire screen. This ensures that opening, tilting, and shock ventilation of your window remain effortlessly possible.



Image: A user reaching through the integrated zipper opening to comfortably operate the window handle, demonstrating the screen's practical design.



Image: A detailed view of the practical zipper opening, allowing easy access to the window handle without removing the insect screen.

## 5.2 Video Demonstration

Watch this video to see the EASYmaxx Insect Protect fly screen in action, demonstrating its functionality and ease of use.

Video: A short demonstration showing the EASYmaxx Insect Protect fly screen installed on a window, highlighting its transparent mesh and how it allows light and air while keeping insects out. The video also shows the window being opened and closed with the screen in place.

## 6. MAINTENANCE

To ensure the longevity and effectiveness of your fly screen, follow these simple maintenance guidelines:

- **Cleaning the Net:** Gently wipe the net with a soft, damp cloth to remove dust and dirt. Avoid using harsh chemicals or abrasive cleaners, as these can damage the fabric.
- **Frame Cleaning:** Clean the aluminum frame with a mild detergent and water. Dry thoroughly.
- **Inspection:** Periodically check the net for any tears or holes. Small damages can often be repaired with a repair kit. Inspect the frame and clamping elements for any signs of wear or damage.
- **Storage:** If removing the screen for seasonal storage, clean it thoroughly and store it in a dry, protected area to prevent damage.

## 7. TROUBLESHOOTING

If you encounter any issues with your EASYmaxx Insect Protect fly screen, please refer to the following common solutions:

Problem	Possible Cause	Solution
Screen does not fit securely in the window.	Frame not properly adjusted or clamping elements not engaged.	Ensure the telescopic frame is extended to the correct dimensions of your window. Check that all spring-loaded clamping elements are correctly positioned and engaged.
Insects are still entering.	Gaps between the screen and the window frame.	Verify that the brush seal is properly installed and covers all gaps. Check for any tears in the net.

Problem	Possible Cause	Solution
Difficulty operating the window handle.	Zipper opening is not aligned or stuck.	Ensure the zipper is fully opened and the net is not obstructing the handle. Gently move the zipper to free it if stuck.

## 8. SPECIFICATIONS

---

- **Model Number:** 16411
- **Product Dimensions (packed):** 86 x 16.6 x 6.3 cm
- **Adjustable Dimensions:** 63 x 93 cm to 100 x 160 cm (Width x Height)
- **Weight:** 1.67 Kilograms
- **Color:** White (Roof Window variant)
- **Material:** Aluminum frame, integrated insect net
- **Special Features:** Telescopic, pre-assembled, no drilling/cutting required, zipper opening, brush seal, protective nubs.

## 9. WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the documentation included with your purchase or contact EASYmaxx customer service directly. Keep your proof of purchase for any warranty claims.

**Manufacturer:** DS Produkte GmbH