

## BOSHIRO 78DH

# BOSHIRO Model 78DH 80-inch Electric Fireplace with Mantel and TV Stand User Manual

Model: 78DH | Brand: BOSHIRO

## 1. INTRODUCTION

---

This manual provides essential instructions for the safe assembly, operation, and maintenance of your BOSHIRO Model 78DH 80-inch Electric Fireplace with Mantel and TV Stand. Please read all instructions carefully before use and retain this manual for future reference.

## 2. SAFETY INFORMATION

---

Observe the following safety precautions to reduce the risk of fire, electric shock, or injury:

- Ensure the power outlet meets the electrical requirements of the fireplace insert.
- Do not route the power cord under carpeting or in high-traffic areas.
- Keep combustible materials at least 3 feet (0.9 meters) away from the front of the fireplace.
- Do not block air vents.
- Always unplug the fireplace before cleaning or maintenance.
- This appliance is for indoor use only.

## 3. PACKAGE CONTENTS

---

Verify that all components are present before beginning assembly. The package typically includes:

- Mantel components (panels, shelves, hardware)
- 30-inch Electric Fireplace Insert
- Remote Control
- Assembly Hardware Kit
- Instruction Manual

*Note: This product may be shipped in two separate parcels, which might arrive 1-2 days apart.*



This illustration indicates that the product may be shipped in two separate packages, which might arrive 1-2 days apart.

## 4. ASSEMBLY INSTRUCTIONS

Assembly requires careful attention to detail. All parts are numbered and pre-drilled for convenience.

1. Refer to the step-by-step instructions provided in the included manual.
2. A detailed assembly video is available to guide you through the process.
3. Ensure all connections are secure before proceeding to the next step.
4. For items placed on shelves requiring power, you may need to create custom openings in the back panels for cable management.



A front view of the BOSHIRO electric fireplace mantel, highlighting the integrated 30-inch fireplace insert and the side storage compartments.

## 5. SETUP


Proper placement and electrical connection are crucial for optimal performance and safety.

### 5.1 Placement

- Place the assembled fireplace mantel on a flat, stable surface.
- Ensure adequate clearance around the unit for air circulation.
- The mantel is designed to accommodate TVs up to 90 inches.

## 5.2 Electrical Connection

- Connect the fireplace insert to a grounded 120V AC outlet.
- Do not use extension cords or power strips.



This diagram illustrates the overall dimensions of the fireplace mantel (80 inches wide, 13.5 inches deep, 35.6 inches high) and indicates compatibility with TVs up to 90 inches.

## 6. OPERATING INSTRUCTIONS

The electric fireplace insert offers various settings for flame effects, heat, and timing.

### 6.1 Control Panel and Remote Control

The fireplace can be operated using the control panel on the unit or the included remote control.

- **Power (On/Off):** Turns the fireplace insert on or off.

- **Flame:** Adjusts the flame color and brightness. There are 3 types of realistic LED flame effects.
- **Heater:** Activates the 750W or 1500W heater.
- **Timer:** Sets an auto-shut off timer for up to 6 hours (0.5-6H).
- **Temperature Control:** Adjusts the heating level from 62°F to 82°F (17°C-27°C) with 22 available levels.



A detailed view of the electric fireplace insert's control panel and remote, explaining functions such as flame brightness, power, heat settings (750W/1500W), timer (0.5-6H), and temperature control (62°F-82°F).

## 6.2 Overheat Protection

A built-in safety cut-off device will automatically power off the heater if it overheats, ensuring safety for you and your family.

**Low-Noise Operation**  
**Keep Room Warm and Quiet**



This image suggests the low-noise operation of the fireplace heater, suitable for maintaining a quiet environment.

## 7. MAINTENANCE

Regular maintenance helps ensure the longevity and proper functioning of your fireplace.

- **Cleaning:** Dust the mantel and wipe the fireplace insert's glass with a soft, damp cloth. Do not use abrasive cleaners.
- **Storage:** If storing the unit, ensure it is unplugged and stored in a dry, cool place.
- **Inspection:** Periodically check the power cord for any damage.

## 8. TROUBLESHOOTING

If you encounter issues, refer to the following common solutions:

- **No Power:** Check if the unit is properly plugged into a working outlet. Verify the circuit breaker.
- **Heater Not Working:** Ensure the heater function is activated and the temperature setting is above the ambient room temperature. Check for overheat protection activation.
- **Remote Control Not Responding:** Replace the remote control batteries. Ensure there are no

obstructions between the remote and the fireplace sensor.

- **Noise from Heater:** Some operational noise is normal. If the noise is excessive, ensure vents are clear and the unit is on a stable surface.

For further assistance, please contact customer support.

## 9. SPECIFICATIONS

Feature	Specification
Brand	BOSHIRO
Model Name	78DH
Product Dimensions	13.5"D x 80"W x 35.6"H
Material	Engineered Wood
Installation Type	Freestanding
Heat Output	1400 Watts (750W/1500W settings)
Special Features	Dimmer, LED Flame, Overheat Protection, Safety Shut Off, TV Stand
Color	Antique White & Brown
Item Weight	108.5 pounds
Included Components	Adjustable Shelves, Remote Control

## 10. WARRANTY AND SUPPORT

This BOSHIRO product comes with a Limited Warranty. For specific details regarding warranty coverage, please refer to the documentation included with your purchase or contact BOSHIRO customer support. For any questions, missing parts, or technical assistance, please contact BOSHIRO customer support through the retailer where the product was purchased.