

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Air Choice](#) /

› [Air Choice 700W Oil Filled Radiator Heater \(Model OH12\) Instruction Manual](#)

Air Choice OH12

Air Choice 700W Oil Filled Radiator Heater (Model OH12) Instruction Manual

Model: OH12

INTRODUCTION

Thank you for choosing the Air Choice 700W Oil Filled Radiator Heater, Model OH12. This compact and efficient heater is designed to provide gentle, consistent warmth for small indoor spaces such as bedrooms, home offices, and under-desk areas. This manual provides essential information for the safe and effective operation and maintenance of your new heater.

IMPORTANT SAFETY INFORMATION

Please read all safety warnings and instructions before using this heater to prevent fire, electric shock, injury, or property damage.

- Always place the heater on a firm, level surface. The unit is equipped with a tip-over safety switch that automatically shuts off the heater if it is not upright.
- Maintain a minimum distance of 3 feet (0.9 meters) between the heater and any flammable materials such as furniture, pillows, bedding, papers, clothes, and curtains.
- Do not cover the heater. Covering the heater can lead to overheating and fire.
- The heater features an automatic shut-off at 105°F (40.6°C) to prevent overheating. If the internal components reach excessive temperatures, the heater will power off.
- Unplug the heater from the power outlet when not in use. Allow at least 20 minutes for the unit to cool down before handling or moving it after use.
- Do not operate the heater with a damaged cord or plug, or after the heater malfunctions or has been dropped or damaged in any manner.
- This heater is for indoor use only. Do not use outdoors.
- Keep out of reach of children and pets.

PRODUCT FEATURES

- **Efficient Heating:** 700W of steady heating power, suitable for areas up to 120 sq. ft.
- **Silent Operation:** Fanless oil-radiator technology ensures quiet operation without producing dry air.
- **Compact & Portable:** Dimensions of 15.1" (D) x 5.4" (W) x 12.4" (H) with a built-in carrying handle for easy relocation.
- **Simple Controls:** Features a rotary thermostat knob and an independent power switch for easy adjustment between high and low heat levels.
- **Consistent Warmth:** Delivers gradual and consistent radiant heat, minimizing energy use.
- **Safety Features:** Includes overheat protection (auto shut-off at 105°F) and a tip-over safety switch.



Figure 1: Front view of the Air Choice 700W Oil Filled Radiator Heater.

Quickly Heats Up The Space

Convective airflow evens out heating, keeping you warm and comfortable all winter long

700W

Powerful Heating

120 ft²

Heat Coverage



Figure 2: The heater efficiently warming a small living space.

Safe & Silent for Peaceful Sleep



Overheating
Protection



Noiseless
Working




Figure 3: Heater positioned for under-desk heating in an office environment.

Compact & Portable for Any Room

Lightweight with easy-carry handle—space-saving design fits anywhere



Figure 4: The heater operating silently in a bedroom for peaceful sleep.

Simple Controls, Powerful Efficiency



Adjust the Temperature



Figure 5: Demonstrating the heater's compact design and portability with its built-in handle.

Meet Various Space Needs

| Living Room



| Bedroom



| Office



Figure 6: The heater's versatility for different small space heating needs.

SETUP

- 1. Unpack:** Carefully remove the heater and all packaging materials from the box. Retain packaging for future storage or transport.
- 2. Attach Feet (if applicable):** Some models may require attaching feet for stability. Locate the two extra feet pieces and slide them into the designated slots at the base of the radiator until they are securely in place. This elevates the heater, preventing direct contact with the floor or carpet.
- 3. Placement:** Place the heater on a stable, level surface, ensuring it is at least 3 feet (0.9 meters) away from walls, furniture, and any flammable objects. Ensure the power cord is not obstructed or placed under the heater.
- 4. Power Connection:** Plug the heater into a standard wall outlet. Ensure the outlet meets the electrical requirements of the heater (120 Volts, 5.9 Amps).

Video 1: Overview of the Air Choice Oil Filled Radiator Heater, demonstrating its compact size and basic setup.

OPERATING INSTRUCTIONS

- Power On:** Press the red 'ON' button located on the front panel. The indicator light will illuminate, signifying the heater is powered on.
- Adjust Heat Level:** Turn the rotary thermostat knob to select your desired heat level. Options typically include 'LOW' and 'HIGH'.
- Set Temperature:** To set a specific temperature, turn the thermostat knob clockwise towards 'HIGH' until you hear a click. The heater will then adapt to and maintain that temperature. If you wish to decrease the temperature, turn the knob counter-clockwise until you hear a click. The heater will readjust accordingly.
- Warm-up Time:** Allow approximately 15 minutes for the radiator to reach its set temperature and begin radiating heat effectively.
- Power Off:** To turn off the heater, press the red 'OFF' button. The indicator light will turn off.



Figure 7: Close-up of the simple controls for adjusting temperature and heat settings.

MAINTENANCE

The Air Choice Oil Filled Radiator Heater is designed for low maintenance. The oil inside the heater is permanently sealed and does not require replacement or refilling.

- **Cleaning:** Always unplug the heater and allow it to cool completely before cleaning. Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the heater in a cool, dry place. You may wrap the power cord around the designated cord storage area if available.

TROUBLESHOOTING

- **Heater does not turn on:**

- Ensure the power cord is securely plugged into a working electrical outlet.
- Check if the 'ON' button is pressed.
- Verify the heater is on a stable, level surface to ensure the tip-over switch is engaged.
- Confirm the thermostat knob is set to a heat level above the current room temperature.

- **Heater turns off unexpectedly:**

- The overheat protection may have activated. Unplug the heater, allow it to cool for at least 20 minutes, and then restart. Ensure there are no obstructions around the heater.
- The tip-over switch may have activated if the heater was bumped or moved. Place it back on a stable, level surface.

SPECIFICATIONS

Feature	Specification
Brand	Air Choice
Model Number	OH12
Heat Output	700 Watts
Heating Coverage	Up to 120 sq. ft.
Product Dimensions	15.1"D x 5.4"W x 12.4"H
Color	Light Black

Voltage	120 Volts
Amperage	5.9 Amps
Min Temperature Setting	40 Degrees Fahrenheit
Max Temperature Setting	105 Degrees Fahrenheit
Special Features	Energy Efficient, Noiseless, Overheat Protection, Portable
Indoor/Outdoor Usage	Indoor
Item Weight	1.44 ounces

WARRANTY AND SUPPORT

Air Choice is committed to providing quality products and customer satisfaction.


- **Replacement:** 12 Months Replacement available.
- **After-Sales Service:** Lifetime after-sales service and technical support.


For any questions, concerns, or support needs, please contact Air Choice customer service through the official channels provided with your purchase or on the Air Choice website.

Video 3: A brief overview of the small oil heater, highlighting its features and suitability for personal use.

© 2025 Air Choice. All rights reserved.

Related Documents - OH12

	<p><u>Air Choice TWH-15Q2 Electric Space Heater User Manual and Safety Guide</u></p> <p>This user manual provides detailed instructions for operating and maintaining the Air Choice TWH-15Q2 Electric Space Heater. Learn about safety features, setup, operating modes, timer functions, troubleshooting, and warranty information.</p>

 <p>Indoor Electric Space Heater Model: KPT-173ND</p>	<p><u>Air Choice KPT-173ND Indoor Electric Space Heater User Manual and Safety Guide</u></p> <p>Comprehensive guide for the Air Choice KPT-173ND Indoor Electric Space Heater, including safety instructions, operating methods, maintenance, and warranty information.</p>
	<p><u>Air Choice Electric Space Heater User Manual and Instructions</u></p> <p>Comprehensive user manual for the Air Choice Electric Space Heater (Model TW-120H), providing detailed instructions on setup, operation, safety precautions, maintenance, troubleshooting, and warranty information.</p>
	<p><u>Air Choice GD9315BCW-4JA Electric Space Heater User Manual</u></p> <p>User manual for the Air Choice GD9315BCW-4JA Electric Space Heater, providing instructions for setup, operation, maintenance, safety features, and troubleshooting.</p>
	<p><u>Air Choice MH-39 Mica Heater Owner's Manual - Safety, Operation, and Maintenance Guide</u></p> <p>Comprehensive owner's manual for the Air Choice MH-39 Mica Heater. Learn about safety precautions, product specifications, operation, humidification features, maintenance, troubleshooting, and warranty information.</p>