

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Bewinner](#) /

› [Bewinner DAB Digital Radio D2 User Manual](#)

Bewinner D2

Bewinner DAB Digital Radio D2 User Manual

Model: D2

INTRODUCTION

This manual provides detailed instructions for the operation and maintenance of your Bewinner DAB Digital Radio D2. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize your listening experience.

PACKAGE CONTENTS

- 1 x Bewinner DAB Digital Radio D2
- 1 x Sound Cable (AUX Cable)
- 1 x Type-C USB Charging Cable
- 1 x User Manual (this document)



Image: The Bewinner DAB Digital Radio D2 shown with its included accessories: a sound cable (AUX cable) and a Type-C USB charging cable.

PRODUCT OVERVIEW

The Bewinner DAB Digital Radio D2 features a 2.4-inch TFT LCD color screen, DAB/DAB+ and FM stereo reception, broadcast recording capabilities, and a built-in 2200mAh lithium battery. It supports Micro SD card playback, Bluetooth connectivity, and AUX input.



Image: Front view of the Bewinner DAB Digital Radio D2, displaying its 2.4-inch LCD screen, speaker grille, and control panel with numbered buttons and function keys.

Key Features:

- DAB/DAB+ and FM Stereo Receiver
- 2.4-inch TFT LCD Color Screen with Backlight
- Broadcast Recording Function (DAB+/FM)
- Bluetooth, Micro SD Card Player, AUX Input
- 2200mAh Built-in Lithium Battery
- Clock, Alarm, Sleep Timer with Time Backup

SETUP

1. Charging the Battery

Before first use, fully charge the radio. Connect the supplied Type-C USB cable to the radio's charging port and the other

end to a USB power adapter (not included) or a computer USB port. The charging indicator will show the charging status.



Image: Side view of the Bewinner DAB Digital Radio D2, highlighting the various ports including the Type-C charging port, AUX input, and Micro SD card slot.

2. Inserting a Micro SD Card (Optional)

To use the recording function or play media from a Micro SD card, insert a Micro SD card (up to 128GB, not included) into the designated slot on the side of the radio. Ensure the card is inserted correctly with the contacts facing down.

3. Extending the Antenna

For optimal reception of DAB/DAB+ and FM signals, fully extend the telescopic antenna located on the top of the radio.

Color LCD Display

2.4 inch color LCD backlit display, no worries about reading difficulties when listening to radio at night, backlit display makes it easy to operate in darkness; with large, easy to read digital display screen for clear view.



Image: The Bewinner DAB Digital Radio D2 with its telescopic antenna fully extended, indicating readiness for radio reception.

OPERATING INSTRUCTIONS

Power On/Off

Press and hold the **Power** button (usually located on the side or top) to turn the radio on or off.

Mode Selection

Press the **Mode** or **Func** button to cycle through available modes: DAB, FM, Bluetooth, Micro SD Card Player, AUX Input.

DAB/DAB+ Radio Operation

1. Switch to DAB mode.
2. Press the **Scan** button to perform a full scan for available DAB/DAB+ stations. The radio will automatically store found stations.
3. Use the **Tuning+** and **Tuning-** buttons or number keys to navigate through the station list.
4. Press **Enter** to select a station.

FM Radio Operation

1. Switch to FM mode.
2. Press the **Scan** button to auto-scan and store FM stations.
3. Alternatively, use **Tuning+** and **Tuning-** buttons for manual tuning.
4. Use number keys to select preset stations.



Image: The Bewinner DAB Digital Radio D2 showing the FM radio interface on its 2.4-inch color LCD screen, indicating active FM reception.

Time Setting

The radio's clock can be set manually or synchronized automatically with DAB+ and FM time signals. Refer to the menu options for time synchronization settings. The device supports clock, alarm, and sleep timer functions with time backup.

Time Setting

The clock of digital tuning radio can be manually adjusted or synchronized with DAB+ and FM time, supporting clock, alarm, sleep timer with time backup.



Image: The Bewinner DAB Digital Radio D2 displaying its time setting interface on the LCD screen, showing options for manual adjustment or synchronization.

Recording Function

The radio supports recording DAB+/FM programs directly to a Micro SD card. While listening to a program, press the **REC** button to start recording. Press **REC** again to stop recording. Ensure a Micro SD card is inserted.

Recording Function

Supports DAB+/FM program recording. Supports BT, micro storage card digital player. Supports AUX input and stereo headphone listening function.



Image: The Bewinner DAB Digital Radio D2 with its antenna extended, emphasizing its recording capability for DAB+/FM programs to a Micro SD card.

Bluetooth Connectivity

1. Switch to Bluetooth mode. The radio will enter pairing mode.
2. On your mobile device, search for Bluetooth devices and select "Bewinner D2" (or similar name) to pair.
3. Once paired, you can play audio from your device through the radio.

Micro SD Card Playback

Insert a Micro SD card with audio files (MP3, WAV, FLAC, etc.). Switch to Micro SD Card Player mode. Use the navigation buttons to browse and play files.

AUX Input

Connect an external audio device to the radio's AUX input port using the supplied sound cable. Switch to AUX Input mode to play audio from the connected device.

Volume Control

Use the **Vol+** and **Vol-** buttons to adjust the volume level.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the radio's surface. Do not use abrasive cleaners or solvents.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the radio regularly, especially if not used for extended periods.
- **Storage:** Store the radio in a cool, dry place away from direct sunlight and extreme temperatures.
- **Antenna:** Handle the telescopic antenna carefully to prevent bending or breakage. Retract it when not in use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Radio does not power on.	Battery is discharged.	Connect the radio to a power source using the Type-C cable and charge it.
Poor radio reception.	Antenna not fully extended; weak signal area.	Fully extend the telescopic antenna. Try moving the radio to a different location.
No sound.	Volume too low; Mute function active; Headphones connected.	Increase volume. Check if Mute is active. Disconnect headphones if sound is desired from speaker.
Bluetooth pairing fails.	Radio not in pairing mode; device too far; interference.	Ensure radio is in Bluetooth pairing mode. Keep devices close. Restart both devices.
Recording not working.	No Micro SD card inserted; Micro SD card full or corrupted.	Insert a compatible Micro SD card. Check card capacity and format if necessary.

SPECIFICATIONS

- **Model:** D2
- **Screen:** 2.4 inch TFT LCD Color Screen
- **Frequency Response:** 20Hz-20KHz
- **FM Frequency Range:** 87.5-108MHz
- **DAB/DAB+ Frequency Range:** 174-240MHz
- **DAB+ Receiver Sensitivity:** -99dbm
- **Expansion Interface:** Micro SD card (supports up to 128GB)
- **Battery:** 2200mAh Lithium Battery (built-in)
- **Dimensions:** Approximately 22 x 14.99 x 6.99 cm
- **Material:** ABS

Versatile Use

With 2.4 inch color display and stunning user menu, the radio is wide applicable for home, office, outdoor travel, sports, leisure, entertainment, learning, and more.



Image: Rear view of the Bewinner DAB Digital Radio D2, displaying the battery compartment, product information, and regulatory markings.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the contact details provided with your purchase or visit the official Bewinner website. Keep your proof of purchase for warranty claims.