



[Manuals.plus](#) /

> [Mia&Coco](#) /

> Mia&Coco Heated Blanket Queen Size (84"x90") Instruction Manual - Model OB27-003

Mia&Coco OB27-003

Mia&Coco Heated Blanket Queen Size (84"x90") Instruction Manual

Brand: Mia&Coco | Model: OB27-003

1. INTRODUCTION

Thank you for choosing the Mia&Coco Heated Blanket. This Queen size electric blanket (84"x90") is designed to provide warmth and comfort with advanced features for a personalized experience. It includes dual controls, 10 heat levels, a 10-hour auto-off timer, and overheat protection, all crafted from soft flannel and fluffy fleece material.



Image: Close-up of the soft, skin-friendly flannel material of the Mia&Coco heated blanket.

2. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using your Mia&Coco Heated Blanket. Failure to follow these instructions may result in fire, electric shock, or injury.

- **Overheat Protection:** The blanket features high-quality PTC and NTC heating wires with built-in overheat protection to prevent excessive temperatures.
- **Automatic Shut-Off:** A 10-hour programmable timer and a 3-hour default auto-off feature provide dual automatic protection, ensuring the blanket turns off after the set time or 3 hours if no timer is selected.
- **Proper Use:** Do not use the blanket folded, bunched, or tucked in. Ensure the blanket lies flat on the bed or surface.
- **Children and Incapacitated Persons:** This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- **Inspection:** Regularly inspect the blanket, power cord, and controllers for any signs of wear or

damage. Discontinue use if any damage is found.

NTC Temperature-Sensitive Heating Wire

SAFE AND DURABLE

Self-recovery of wire overheating damage




Image: Diagram illustrating the NTC temperature-sensitive heating wire with safety wire, main wire, safety coating layer, and PVC insulation layer, highlighting overheat protection, real-time temperature monitoring, fast heating, and abrasion-resistant PVC protective layer.

3. SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove the heated blanket and its components from the packaging.
2. **Position the Blanket:** Lay the blanket flat on your mattress. Ensure it is not folded or wrinkled.
3. **Connect Controllers:** The Queen size blanket comes with two controllers for dual control. Connect each controller cord securely to the corresponding port on the blanket.
4. **Plug In:** Plug the power cords from the controllers into a standard electrical outlet. Ensure the outlet is easily accessible. The sturdy 263cm (approximately 8.6 ft) cable allows for flexible placement.




Image: Visual guide showing how to connect the controller cord to the blanket and then plug the power cord into an electrical socket.

4. OPERATING INSTRUCTIONS

The Mia&Coco Heated Blanket features intuitive controls for personalized comfort.

4.1 Dual Control

Each side of the Queen size blanket has an independent controller, allowing two users to set their preferred heat and timer settings without affecting the other side.

INTUITIVE AND USER-FRIENDLY CONTROLLER



Image: Close-up of the two intuitive and user-friendly controllers with digital displays for heating level and timing indication, power switch, pre-heat, heat timer, and increase/decrease buttons.

4.2 Power On/Off

Press the power button on the controller to turn the blanket on or off. Upon powering on, the heating level and timer will default to the settings you last used.

4.3 Adjusting Heat Levels

The blanket offers 10 adjustable temperature levels, ranging from 1 to 9, and an 'H' setting (77-127°F). Use the '+' and '-' buttons to increase or decrease the heat intensity. The LED display will show the current heat level.

4.4 Pre-Heat Function

Press the 'PRE-HEAT' button to quickly warm the blanket to its highest heating level. After 1 hour, it will automatically return to the original setting level.

4.5 Setting the Timer

The blanket features a programmable timer that can be adjusted from 1 to 10 hours. Use the 'HEAT TIMER' button and the '+' and '-' buttons to set your desired auto-off time. A 3-hour default auto-off feature provides additional safety.

4.6 Official Product Video: Controller Operation

Your browser does not support the video tag.

Video: This video demonstrates the operation of the Mia&Coco heated blanket's controller, showing how to power on/off, adjust heat settings, and set the timer.

5. MAINTENANCE

5.1 Cleaning Instructions

The Mia&Coco Heated Blanket is designed for easy cleaning.

1. **Disconnect Power:** Always unplug the power cord and detach the controllers from the blanket before washing.
2. **Washing:** The blanket can be machine washed or hand washed. Use cold water (below 86°F / 30°C) on a gentle cycle. Do not bleach or dry clean.
3. **Drying:** Air dry the blanket naturally. Do not tumble dry on high heat. Ensure the blanket is completely dry before reconnecting the controllers and using it. The fabric will not fade or deform after washing, maintaining its softness and cleanliness.



EASY TO CLEAN AND MAINTAIN

The wiring structure is durable enough that the electric blanket remains soft and warm even after multiple washings

Image: A woman placing the Mia&Coco heated blanket into a washing machine, with an inset showing how to detach the controller cord. Text highlights that the blanket is machine washable and easy to clean and maintain.

5.2 Official Product Video: Care and Washing

Your browser does not support the video tag.

Video: This video provides detailed instructions on how to care for and wash the heated blanket, emphasizing the detachment of the controller before washing.

5.3 Storage Instructions

For long-term storage, ensure the blanket is clean and completely dry. Fold it neatly and store it in a cool, dry place. Avoid excessive folding or twisting, and do not place heavy objects on top of the blanket to maintain its heating performance and longevity.

5.4 Official Product Video: Long-Term Storage

Your browser does not support the video tag.

Video: This video demonstrates the correct and incorrect ways to store the heated blanket long-term, advising against excessive folding or placing heavy objects on it.

6. TROUBLESHOOTING

- **Blanket Not Heating:** Ensure both controllers are securely connected to the blanket and the power cords are firmly plugged into a working electrical outlet. Check if the power button on the controller is pressed and a heat level is selected.
- **Uneven Heating:** Ensure the blanket is laid flat and not folded or bunched. If the issue persists, contact customer support.
- **Controller Display Not Working:** Verify the power connection. If the display remains off, try plugging into a different outlet. If the problem continues, the controller may need replacement.

7. PRODUCT SPECIFICATIONS

Material	Fleece, Flannel Sherpa
Color	Grey
Brand	Mia&Coco
Special Feature	Corded Electric, Dual Control, 10 Heat Levels, 10-Hour Auto-Off, Overheat Protection
Product Dimensions	90"L x 84"W
Size	Queen (84" x 90")
Item Weight	7.33 pounds
Model Name	OB27-003
Manufacturer	Mia&Coco

Product Care Instructions	Machine Wash, Hand Wash (below 86°F)
--------------------------------------	--------------------------------------

8. WARRANTY AND SUPPORT

For any warranty claims, technical support, or further inquiries regarding your Mia&Coco Heated Blanket, please refer to the contact information provided in your product packaging or visit the official Mia&Coco website. Keep your purchase receipt as proof of purchase.