

[Manuals.plus](#) /

› [GIANTEX](#) /

› GIANTEX Folding Sewing Table with Charging Station, Model GX73607US-WH

GIANTEX GX73607US-WH

GIANTEX Folding Sewing Table with Charging Station

Model: GX73607US-WH

INTRODUCTION

Thank you for choosing the GIANTEX Folding Sewing Table with Charging Station. This versatile and space-saving furniture piece is designed to enhance your crafting and sewing experience. It features a foldable design, integrated storage, and a convenient charging station. This manual provides essential information for safe assembly, operation, and maintenance of your new sewing table.



Figure 1: GIANTEX Folding Sewing Table in expanded configuration.

SAFETY INFORMATION

Please read and understand all safety instructions before assembling or using this product. Failure to follow these instructions may result in injury or damage to the product.

- Always secure the tabletop when in use to prevent accidental folding.
- Exercise caution when folding and unfolding the table to prevent tip-over or pinching.
- Keep small parts and the power strip out of reach of children.
- Always follow the assembly instructions carefully to avoid injury and ensure structural integrity.
- Do not overload the table or shelves beyond the recommended weight capacity of 20.41 kg (45 lbs).

PRODUCT FEATURES

- **Smart Storage & Organization:** Features a spacious tabletop, 3 built-in side storage bins for threads and tools, and a large open shelf for various supplies.

- **Foldable Space-Saving Design:** Easily folds down to save space, making it ideal for small apartments, dorms, or compact studios. Expanded dimensions: 45.5"L x 16"W x 31"H. Folded dimensions: 35"L x 20"W x 31"H.
- **Built-in Power Strip with USB & Type-C:** Includes 2 AC outlets, 1 USB port, and 1 Type-C port for convenient power access without cluttering the workspace.
- **Mobile & Stable Craft Table:** Equipped with 5 smooth-rolling castor wheels for easy repositioning. 3 lockable casters ensure stability during use.
- **Multifunctional Design:** Can be used as a sewing table, craft desk, computer workstation, or side storage cabinet.



Figure 2: Integrated storage trays and open shelf.



Built-in Power Strip on Side

Provide a convenient charging station
without messing up the tabletop



2 AC Outlets
125V/12A



USB + Type-C
5V/2.4A



Power Cord
4.8 FT



Figure 3: Built-in charging station with AC, USB, and Type-C ports.

SETUP AND ASSEMBLY

Your GIANTEX Folding Sewing Table requires assembly. An assembly guide is included in the packaging. Please ensure all components are present before beginning assembly.

Required Tools:

- Screwdriver (not included)

Assembly Steps:

1. Unpack all components and verify against the parts list in the included assembly guide.
2. Follow the step-by-step instructions provided in the assembly guide. Pay close attention to diagrams for correct orientation of parts.
3. Attach the caster wheels to the base of the table, ensuring the lockable casters are placed as indicated for optimal stability.
4. Securely fasten all screws and connectors. Do not overtighten.

5. Once assembled, test the folding mechanism and ensure all parts move smoothly and lock securely.

Dimensions




Figure 4: Product dimensions for assembly planning.

OPERATING INSTRUCTIONS

Folding and Unfolding the Table:

1. To unfold: Release the spring latch (if engaged) on the side panel. Gently extend the tabletop until it is fully open and stable. Ensure the support leg is properly positioned.
2. To fold: Clear the tabletop of all items. Carefully lift the tabletop and fold it inwards. Secure the side panel with the spring latch to keep it in the compact position.

Ample Storage Space



Sewing
Machines



Threads



Scissors



Mini
Iron



Lights

Spacious Tabletop

3 Side
Storage Trays

Open Shelf


Figure 5: Table in folded, compact position.

Using the Charging Station:

1. Plug the table's power cord into a standard wall outlet.
2. Use the 2 AC outlets for sewing machines, lamps, or other electrical devices.
3. Connect your mobile devices to the USB or Type-C ports for charging.
4. Always ensure the power strip is not overloaded.

Mobility and Stability:

1. To move the table: Unlock the 3 lockable caster wheels. Gently push the table to your desired location.
2. To stabilize the table: Once in position, engage the locks on the 3 caster wheels to prevent movement during use.



Spring Latch



Magnetic Door Catch



5 Universal Casters, 3 with Brakes



Anti-Collision Pads

Figure 6: Lockable caster wheel detail.

MAINTENANCE

Regular maintenance will help prolong the life of your sewing table.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.
- **Casters:** Keep caster wheels free of debris to ensure smooth rolling.
- **Electrical Components:** Inspect the power cord and outlets for any signs of damage. Discontinue use and contact support if damage is found.

TROUBLESHOOTING

If you encounter issues with your sewing table, refer to the following common solutions:

- **Table is wobbly:** Ensure all assembly screws are tightened. Verify that the lockable casters are engaged when the table is stationary. Check that the folding mechanism is fully extended and locked into place.
- **Tabletop does not fold/unfold smoothly:** Check for any obstructions. Ensure the spring latch is properly disengaged/engaged. Apply a small amount of silicone lubricant to hinges if movement is stiff.
- **Charging station not working:** Ensure the table's power cord is securely plugged into a functional wall outlet. Check if the wall outlet itself is working by plugging in another device. Inspect the power cord for any visible damage.
- **Casters not rolling:** Check for debris (thread, hair) caught in the wheels. Ensure the caster locks are disengaged.

SPECIFICATIONS

Feature	Detail
Brand	GIANTEX
Model Number	GX73607US-WH
Expanded Dimensions (L x W x H)	45.5"L x 16"W x 31"H (115.6 x 40.6 x 78.7 cm)
Folded Dimensions (L x W x H)	35"L x 20"W x 31"H (approx. 89 x 50.8 x 78.7 cm)
Material	Engineered Wood, Metal
Color	White & Natural
Item Weight	19.5 kg (43 lbs)
Maximum Weight Recommendation	20.41 kg (45 lbs)
Charging Station	2 AC Outlets (125V/12A), 1 USB Port, 1 Type-C Port
Casters	5 Universal Casters (3 with Brakes)
Storage	3 Side Storage Trays, 1 Open Shelf



Figure 7: Table used as a computer workstation.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact GIANTEX customer service directly. Keep your purchase receipt for warranty claims.

Contact information can typically be found on the manufacturer's website or on the product packaging.

© 2023 GIANTEX. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question