#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- > PHILIPS /
- > PHILIPS Android 15 Tablet T7315 User Manual

#### **PHILIPS T7315**

# **PHILIPS Android 15 Tablet T7315 User Manual**

Model: T7315

# 1. Introduction

This manual provides essential information for the safe and efficient use of your PHILIPS Android 15 Tablet T7315. Please read this manual thoroughly before operating the device and keep it for future reference.



Image 1: Front and back view of the PHILIPS Android 15 Tablet T7315.

### 2. PACKAGE CONTENTS

Upon opening the package, ensure all items listed below are present. If any items are missing or damaged, please contact customer support.

- PHILIPS Android 15 Tablet T7315
- · USB Type-C Cable
- Charging Adapter (5V/2A)
- · Memory Card Slot Pin
- Instruction Manual (Japanese)



#### ユーザー補助機能を搭載

文字サイズの拡大、音声アシスト、画面読み 上げ、色の反転など、視覚や聴覚に不安のある 高齢者にも使いやすいシニア向けタブレットです。





Image 2: The PHILIPS T7315 Tablet package contents, including the tablet, charger, Type-C cable, and instruction manual.

# 3. SETUP

# 3.1. Initial Charging

Before first use, fully charge your tablet using the provided Type-C cable and charging adapter. The tablet supports PD18W fast charging, though the included adapter is 5V/2A (10W). For faster charging, a compatible 18W charger (sold separately) can be used.

#### 3.2. Power On/Off

- **To Power On:** Press and hold the power button located on the right side of the tablet until the PHILIPS logo appears.
- **To Power Off:** Press and hold the power button until the power options appear on the screen, then select "Power Off."
- **To Restart:** Press and hold the power button until the power options appear on the screen, then select "Restart."

# 3.3. Inserting a MicroSD Card

Locate the memory card slot on the top edge of the tablet. Use the provided memory card slot pin to open the tray. Insert your MicroSD card (up to 1TB) into the tray and gently push it back into the slot until it clicks into

# 4. KEY FEATURES

## 4.1. Display and Visuals

- 10.1-inch IPS Display: Enjoy vibrant colors and clear images with a 1280x800 resolution and a 16:10 aspect ratio. The 178-degree wide viewing angle and 330-nit brightness ensure visibility even outdoors.
- **90Hz Refresh Rate:** Experience smoother scrolling, gaming, and video playback with the high 90Hz refresh rate.
- Widevine L1 Support: Stream high-definition content from platforms like Disney+, Amazon Prime Video, and Hulu.
- Eye Care Mode: Reduces blue light emission to minimize eye strain during prolonged use, making it comfortable for reading and online learning.

# 広視野角IPSパネル搭載・10.1インチ大画面

解像度1280×800の高精細ディスプレイで、動画や電子書籍もくっきり鮮明。自然で鮮やかな発色、斜めから見てもクリアな視認性、家族や友人と画面を共有するのに最適



10.1インチ

画面サイズ

80%

画面占有率

1670万色

発色

1000:1

コントラスト比

90Hz

リフレッシュレート

1280x800

解像度

149

LCD ppi

Image 3: The 10.1-inch IPS display with 90Hz refresh rate and 1280x800 resolution.

# 迫力あるステレオサウンドで臨場感アップ

左右に配置された2つの高音質スピーカーが、映画や音楽、ゲームをよりリアルに楽しめる。 クリアでバランスの良い音響設計だから、動画視聴もオンライン会議も快適。



# Widevine L1対応

Widevine L1認証を取得しており、Amazon Prime Video、Disney+、Huluなどが高画質で視聴可能。ワイヤレス投影機能で、大画面TVに簡単接続し、家族や友人と一緒に映画や動画を楽しむことができます。









Image 4: Eye Care Mode for reduced blue light and comfortable viewing.

### 4.2. Performance

- Android 15 OS: The latest Android 15 operating system offers improved battery consumption and up to 30% faster app launch speeds through AI optimization. It also includes enhanced security features.
- Unisoc T615 Octa-core CPU: Equipped with a power-efficient Unisoc T615 processor (2x1.8GHz Cortex-A75 + 6x1.6GHz Cortex-A55), ensuring smooth operation for video editing, YouTube, gaming, online learning, web browsing, and office tasks.

# 高性能8コア CPU搭載

高性能オクタコアプロセッサにより、SNS・ネット検索・動画視聴・オンライン 学習など、日常の操作がストレスなく快適。

省電力設計でバッテリー持ちも、在宅ワークにもおすすめ。

# 電力消費制御がより優れる

GPU性能がより高い

**UNISOC T615** 

12nm

UNISOC T615 1.8GHz
















Image 5: The Unisoc T615 Octa-core CPU for efficient performance.

# 4.3. Memory and Storage

- 12GB RAM: Features 4GB physical RAM and 8GB virtual RAM for seamless multitasking, allowing multiple applications and games to run smoothly.
- 128GB Internal Storage + 1TB Expandable: Comes with 128GB of built-in storage, expandable up to 1TB via a MicroSD card. This provides ample space for comics, music libraries, videos, photos, and important work or study files.

# 最大12GB RAM (4GB+8GB拡張)

たっぷりのメモリで複数アプリも軽快に動作。



# 128GB内蔵ストレージ 最大1TBのmicroSDカード対応

写真や動画、大容量アプリもたっぷり保存でき、 ビジネスからエンタメまであらゆる用途に対応します。



Image 6: 12GB RAM and 1TB expandable storage capacity.

## 4.4. Battery and Charging

- 6000mAh Large Capacity Battery: Provides long-lasting power for daily use, outdoor activities, and travel. Enjoy approximately 9-12 hours of video playback, 10-12 hours of web browsing, up to 70 hours of music playback, and about 9 hours of gaming.
- PD18W Fast Charging: Supports 18W fast charging (charger sold separately) for quick power recovery,

ensuring you can use the tablet for extended periods after a short charge.



Image 7: 6000mAh battery and 18W fast charging capabilities.

- 8MP Main Camera & 5MP Front Camera: Capture clear photos and videos. The front camera is ideal for video calls and online meetings.
- Face Recognition: Unlock your tablet quickly and securely with face recognition, eliminating the need for passwords.

# 顔をかざすだけで簡単 スピーディにロック解除

パスワード不要で、誰でもスト レスなく 安全に使える。 忙しい朝や外出時もサッと 操作できて快適です



# 目にやさしい 「アイケアモード」搭載



# 迷わない! いつでも正確な位置情報

複数の衛星から位置情報を取得。 屋外での散歩や旅行、ドライブも 安心サポート。GPS/Beidou/QZSS/





### カメラ8MP/5MP

高品質な写真とビデオを 撮影できます。

リアカメラ: 800万画素 フロントカメラ: 500万画素



Image 8: Face recognition and dual cameras (8MP rear, 5MP front).

## 4.6. Connectivity and Navigation

- **Bluetooth 5.0:** Provides stable and power-efficient connections for accessories like headphones and keyboards.
- **Dual-band Wi-Fi (2.4G & 5G):** Supports 5GHz (up to 433Mbps) and 2.4GHz Wi-Fi for stable, high-speed communication, ideal for online meetings and 4K video streaming.
- GPS/Beidou/QZSS/GLONASS/Galileo Support: Accurate satellite positioning for reliable navigation during travel or in-car use.

### 4.7. User-Friendly Features

- Split Screen Function: Efficiently multitask by displaying two applications simultaneously on the screen.
- Wireless Projection: Easily connect your tablet to a TV or projector for a larger display without cumbersome cables.
- Private Space: Protect confidential files with an additional authentication layer.
- Parental Control: Manage usage time and content filters for children.

# 5. OPERATING INSTRUCTIONS

### 5.1. Basic Navigation

The tablet uses a touch-sensitive screen. Tap to select, swipe to scroll, and pinch to zoom. Familiarize yourself with the Android interface for optimal use.

## 5.2. Using Split Screen

To activate split screen mode, open an application, then swipe up from the bottom of the screen to reveal the recent apps. Drag one app to the top or side of the screen, then select another app to fill the remaining space. You can adjust the division ratio between the two apps.

Your browser does not support the video tag.

Video 1: This video demonstrates various functions of a PHILIPS tablet, including split-screen multitasking with Google Maps and YouTube, smooth web browsing, and camera functionality. While the video mentions model T8015, the features shown are generally applicable to the PHILIPS T7315 tablet.

## 5.3. Wireless Projection

To project your tablet's screen wirelessly to a compatible TV or projector, navigate to Settings > Connected devices > Connection preferences > Cast. Select your desired display device from the list to begin mirroring.

### 5.4. Camera Usage

Open the Camera app from your home screen or app drawer. Tap the shutter button to take a photo. Switch between front and rear cameras using the camera icon. Tap and hold to record a video.

# 5.5. GPS Navigation

Utilize pre-installed map applications or download your preferred navigation app from the Google Play Store. The tablet's multi-satellite GPS support ensures accurate positioning for reliable navigation.

## 6. MAINTENANCE

- **Screen Protection:** The tablet comes with a pre-applied protective film. For enhanced protection, a stronger glass film (e.g., B0FG7Z433J) can be purchased and applied.
- Cleaning: Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid using harsh chemicals or abrasive materials.
- Battery Care: To prolong battery life, avoid exposing the tablet to extreme temperatures.

# 7. TROUBLESHOOTING

### 7.1. Power Does Not Turn On

If the tablet does not power on, try the following steps:

- 1. Ensure the tablet is fully charged. Connect it to the charger for at least 30 minutes.
- 2. If still unresponsive, disconnect the charger, leave the tablet untouched for approximately one week (to allow for full discharge), then reconnect the charger and immediately press and hold the power button.
- 3. If the issue persists, please contact customer support.

### 7.2. Screen Refresh Rate Update

As of October 14, 2025, the tablet's refresh rate has been upgraded from 60Hz to 90Hz via an OTA update. To ensure your tablet has the latest update:

```
Go to "Settings" ( ).
Select "System" ( ).
Select "System Update" ( ).
Execute the update. (New system: Philips_T7315_2539_V10_JP)
```

# 8. SPECIFICATIONS

Feature	Specification
Brand	PHILIPS
Model Name	T7315
Operating System	Android 15
CPU Brand	Unisoc T615 Octa-core (1.8 GHz)
Display Size	10.1 inches
Resolution	1280x800 pixels
Refresh Rate	90Hz

RAM	12GB (4GB physical + 8GB virtual)
Storage	128GB (expandable up to 1TB via MicroSD)
Battery Capacity	6000mAh
Charging	Type-C, PD18W Fast Charging support
Rear Camera	8MP
Front Camera	5MP
Connectivity	Wi-Fi (802.11a/b/g/n/ac, 2.4G & 5G), Bluetooth 5.0
Navigation	GPS/Beidou/QZSS/GLONASS/Galileo
Weight	470g

# 9. WARRANTY AND SUPPORT

Your PHILIPS T7315 Tablet comes with a 1-year product warranty. PHILIPS offers 24-hour customer support in Japanese to assist with any inquiries or issues.

# 9.1. Contacting Customer Support

If you encounter any problems or have questions regarding your product, please contact us through Amazon:

- 1. Go to your Amazon account.
- 2. Navigate to "Order History."
- 3. Select the relevant order for this product.
- 4. Click on "Contact Seller" ( ).

We are committed to ensuring customer satisfaction.

© 2025 PHILIPS. All rights reserved.

**Related Documents - T7315** 

