

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [UGREEN](#) /

› [UGREEN FineTrack G \(65543P\) Android Air Tracker Tags User Manual](#)

UGREEN FineTrack G (65543P)

UGREEN FineTrack G (65543P) Android Air Tracker Tags User Manual

Model: FineTrack G (65543P) | Brand: UGREEN

1. INTRODUCTION

Welcome to the UGREEN FineTrack G Android Air Tracker Tags user manual. This document provides detailed instructions for setting up, operating, and maintaining your new item trackers. The UGREEN FineTrack G is designed to help you locate your valuables using the Google Find Hub app on compatible Android devices.

2. SAFETY INFORMATION

- Keep the device away from water and extreme temperatures.
- Do not attempt to disassemble or modify the device.
- Use only the specified USB-C charging cable.
- This device is designed for tracking personal items and should not be used for unauthorized tracking of individuals.
- Ensure the device is kept out of reach of small children to prevent accidental ingestion of small parts.

3. PACKAGE CONTENTS

The UGREEN FineTrack G package includes the following items:

- UGREEN FineTrack G Air Tracker Tags (4 units)
- USB-C Charging Cable (1 unit)
- Protective Dust Covers (8 units)
- Sticker Sheet for Customization (1 unit)

Package Contents



Figure 3.1: UGREEN FineTrack G package contents, showing four trackers, a USB-C cable, dust covers, and a sticker sheet.

4. SETUP

4.1 Initial Charging

Your UGREEN FineTrack G tags come with a built-in rechargeable battery. Before first use, it is recommended to fully charge the device. A full charge provides up to 1 year of continuous use.

- Locate the USB-C charging port on the side of the tracker.
- Connect the provided USB-C cable to the tracker and a compatible USB power adapter (not included).
- The indicator light will show charging status. Once fully charged, the light will change or turn off.
- After charging, ensure the protective dust plug is securely inserted into the USB-C port to prevent dirt and moisture

entry.




Figure 4.1: The UGREEN FineTrack G tracker connected to a USB-C charging cable, illustrating its rechargeable battery feature.

4.2 Pairing with Google Find Hub App (Android Only)

The UGREEN FineTrack G is compatible with Android phones running Android 9.0 and above. It is not compatible with iOS devices.

1. **Download the App:** Ensure you have the latest version of the Google Find Hub app installed on your Android phone. You can download it from the Google Play Store.
2. **Enable Bluetooth and Location:** Make sure Bluetooth and Location services are enabled on your Android phone.
3. **Power On the Tracker:** Shortly press the power button on the FineTrack G tracker to turn it on.
4. **Initiate Pairing:** Hold the tracker near your phone and open the Google Find Hub app. A pop-up window should automatically appear on your phone prompting you to connect.
5. **Follow On-Screen Prompts:** Tap "Connect," then "Agree and continue," and finally "Open app" to allow access to nearby devices.
6. **Name Your Tracker:** Once connected, you can assign a name to your tracker (e.g., "Keys," "Wallet," "Luggage") and select an icon for easy identification.



Figure 4.2: Step 1 - Power on the tracker by pressing the button.




Figure 4.3: Step 2 - Hold the tracker near your phone and open the Find Hub app.




Figure 4.4: Step 3 - Follow the on-screen prompts to complete pairing.

Your browser does not support the video tag.

Video 4.1: A seller-provided video demonstrating how to set up an Android Air Tag with the Google Find Hub app, including initial pairing steps.

Your browser does not support the video tag.

Video 4.2: A seller-provided video illustrating the connection process of a Bluetooth tracker to both Android and iOS phones, highlighting the initial setup.

5. OPERATING INSTRUCTIONS

5.1 Finding Your Items

The Google Find Hub app offers two primary ways to locate your items:

- **Close Range (Play Sound):** When your tracker is within Bluetooth range, open the Find Hub app, select your tracker, and tap "Play Sound." The tracker will emit an audible alert, helping you pinpoint its exact location.
- **Long Range (Navigate):** If your tracker is out of Bluetooth range, the Find Hub app will display its last known location on a map, utilizing the vast network of Android devices. You can then use the app's navigation feature to get directions to the item's location.





Figure 5.1: The Find Hub app showing the "Play Sound" option for locating a nearby UGREEN FineTrack G tracker.



Worldwide Tracking

No matter where the product is lost, it can be tracked, as long as an Android device is nearby.

Figure 5.2: The Find Hub app displaying navigation to a UGREEN FineTrack G tracker's last known location when out of Bluetooth range.

5.2 Lost Item Alerts & Lost Mode

To enhance the security of your items, the FineTrack G offers Lost Item Alerts and a dedicated Lost Mode:

- **Lost Item Alerts:** If your tracker moves out of range from your phone, the Google Find Hub app will send an alert with the last known location of the tracker.
- **Lost Mode:** If an item is confirmed lost, activate Lost Mode in the Find Hub app. You can leave your contact information (message and phone number). Any nearby Android device that detects your lost tracker can then access this information, facilitating its return.

5.3 Family Sharing

You can share the location of your UGREEN FineTrack G trackers with family members or trusted contacts through the Google Find Hub app. This allows multiple people to help keep track of important items.

- In the Find Hub app, select the tracker you wish to share.
- Tap the "Share device" option and follow the on-screen instructions to share access with others.



Figure 5.3: The Find Hub app interface demonstrating the family sharing feature for UGREEN FineTrack G trackers.

6. MAINTENANCE

6.1 Charging the Device

The UGREEN FineTrack G features a long-lasting rechargeable battery that provides up to 1 year of use on a single charge. To charge your device:

- Gently remove the protective dust plug from the USB-C port.
- Insert the provided USB-C cable into the port and connect the other end to a USB power source.
- The LED indicator will illuminate to show charging status.
- Once charging is complete, remove the cable and securely reinsert the dust plug to maintain water and dust resistance.



Figure 6.1: A close-up view of the UGREEN FineTrack G tracker being charged via its USB-C port.

6.2 Cleaning

To clean your UGREEN FineTrack G, use a soft, dry cloth. Avoid using harsh chemicals or abrasive materials that could damage the device.

7. TROUBLESHOOTING

Problem	Possible Solution
Tracker not pairing	Ensure Bluetooth and Location are enabled on your Android phone. Make sure the Google Find Hub app is updated. Press the power button on the tracker to ensure it's on. Try restarting your phone and the tracker.
Cannot hear the tracker's sound	Ensure the tracker is within Bluetooth range of your phone. Check the volume settings within the Find Hub app. The tracker's speaker may be obstructed.
Location not updating	Ensure your phone has an active internet connection. The tracker relies on nearby Android devices to update its location when out of your phone's range. Ensure location services are active on your phone.
Battery draining quickly	Ensure the USB-C dust plug is properly sealed. Frequent use of the "Play Sound" feature can consume more battery. Ensure the tracker is not constantly searching for a connection in areas with poor Bluetooth coverage.

8. SPECIFICATIONS

- **Model:** FineTrack G (65543P)
- **Brand:** UGREEN
- **Compatibility:** Android 9.0 and above (Google Find Hub App required)
- **Connectivity:** Bluetooth
- **Battery:** Rechargeable Lithium Polymer (up to 1-year continuous use per charge)
- **Charging Port:** USB-C
- **Dimensions:** 1.42 x 0.29 x 1.42 inches
- **Item Weight:** 4.9 ounces
- **Material:** Plastic
- **Color:** Black

9. WARRANTY AND SUPPORT

UGREEN products come with a standard manufacturer's warranty. For specific warranty details, technical support, or customer service inquiries, please refer to the warranty card included in your package or visit the official UGREEN website. You may also contact your retailer for assistance.

Related Documents - FineTrack G (65543P)

	<p>UGREEN FineTrack Slim Q & A - Troubleshooting and Usage Guide</p> <p>Frequently asked questions and answers regarding the UGREEN FineTrack Slim tracker, covering setup, pairing, device compatibility, battery life, and location tracking features.</p>
	<p>UGREEN FineTrack CM816: Item Finder and Locator Specifications and FAQ</p> <p>Detailed specifications and frequently asked questions for the UGREEN FineTrack CM816 item finder and locator, compatible with Apple's Find My app.</p>
	<p>UGREEN FineTrack CM816: User Guide and FAQs</p> <p>Comprehensive guide to the UGREEN FineTrack CM816 item finder and locator, including setup, compatibility, and troubleshooting.</p>
	<p>UGREEN FineTrack Q & A - Troubleshooting and Usage Guide</p> <p>Answers common questions about the UGREEN FineTrack, including setup with Apple's Find My app, device compatibility, sound issues, and location updates. Learn how to use and troubleshoot your UGREEN FineTrack.</p>
	<p>UGREEN Smart Bluetooth Finder User Manual</p> <p>The UGREEN Smart Bluetooth Finder (Model CM520) is a compact item tracker designed to help you locate your personal belongings using Apple's Find My app. It allows users to track items on a map, trigger sound alerts, enable 'Lost Mode' with contact information, and receive notifications when items are left behind or found. This device is compatible with iOS 14.5 or later.</p>
	<p>UGREEN FineTrack Slim CM817 45298: Frequently Asked Questions</p> <p>Answers to common questions about the UGREEN FineTrack Slim CM817 45298, including compatibility, setup, troubleshooting, and functionality with Apple's Find My app.</p>

