

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [DinoFire](#) /
- › [DinoFire Wireless Presentation Remote with Air Mouse User Manual](#)

## DinoFire WP102

# DinoFire Wireless Presentation Remote with Air Mouse User Manual

MODEL: WP102

### Introduction

This manual provides comprehensive instructions for the DinoFire Wireless Presentation Remote with Air Mouse (Model WP102). This device combines the functionality of a traditional presentation clicker with a wireless air mouse, offering enhanced control during presentations. It features a 2.4GHz RF connection, a built-in rechargeable battery, and a bright red light pointer. The remote is designed for ease of use, supporting various operating systems and presentation software.



Figure 1: DinoFire Wireless Presentation Remote (Model WP102) with its dual USB receiver.

## Setup Guide

1. **Charge the Remote:** Before first use, ensure the presentation remote is fully charged. Connect the included USB-C

cable to the remote's charging port and the other end to a USB power source (e.g., computer USB port, wall adapter). The LED indicator will show charging status. A full charge typically takes 3 hours and provides weeks of use.

2. **Locate the USB Receiver:** The 2-in-1 USB receiver is conveniently stored inside the remote's body. Gently slide open the magnetic storage compartment at the bottom of the remote to retrieve it.



Figure 2: Location of the USB receiver within the remote.

3. **Connect the Receiver:** Insert the USB receiver into an available USB-A or USB-C port on your computer or laptop. The receiver is designed to be compatible with both port types.



Figure 3: The versatile 2-in-1 USB receiver for USB-A and USB-C ports.

4. **Power On the Remote:** Slide the ON/OFF switch on the side of the remote to the "ON" position. The remote is plug-and-play, requiring no additional software installation. Your computer should automatically recognize the device.

## Operating Instructions

The DinoFire Wireless Presentation Remote offers multiple functions to enhance your presentation experience. Familiarize yourself with the button layout and their corresponding actions.

# PLUG & PLAY AIR MOUSE PRESENTER



## Left/right Mouse Keys

Control your computer like a real mouse



## Page Up/Down

Simple & smooth control presntaion



## Full/Bck Screen

Freely switch your window screen



## Play Videos

Can play video or open liks/  
hyperlinks eyc



## Volume Control

Press the "+" "-" buttons to control volume

Figure 4: Key functions of the DinoFire Air Mouse Presenter.

### Button Functions:

- **Light Control (Red Laser Pointer):** Press the button with the red light icon to activate the red laser pointer. This is useful for highlighting specific points on your presentation screen.
- **Page Up (Single Press):** Press the **^** button to move to the previous slide or page.
- **Full Screen / Black Screen (Press and Hold):** Press and hold the **^** button to toggle between full-screen mode and a black screen during a presentation.
- **Page Down (Single Press):** Press the **v** button to advance to the next slide or page.
- **Black Screen (Press and Hold):** Press and hold the **v** button to activate a black screen.
- **Left Mouse Button:** The button with the mouse icon acts as the left mouse click.

- **Volume Up (+):** Press the '+' button on the side to increase the system volume.
- **Volume Down (-):** Press the '-' button on the side to decrease the system volume.
- **ON/OFF Mouse (Single Press):** The button with the mouse icon and a circle (below the left mouse button) toggles the air mouse functionality on and off. This allows you to pause cursor movement when not needed.

### Air Mouse Functionality:

The integrated air mouse allows you to control your computer's cursor by moving the remote in the air. This is particularly useful for interacting with hyperlinks, playing videos, or navigating web pages directly from your presentation. Ensure the "ON/OFF Mouse" button is activated for air mouse control.



Figure 5: Air Mouse functionality for interactive presentations.

### Compatibility:

The DinoFire WP102 is widely compatible with various operating systems and presentation software:

- **Systems:** Windows 2003/XP/Vista/7/8/10 or above, Mac OS, Linux, Android.
- **Software:** PowerPoint, Excel, Prezi, iWork (Keynote & Numbers & Pages), Web browsers, and more.

The 2.4GHz RF technology provides a long control range, allowing you freedom of movement up to 100 feet (30 meters) from your computer.

## Maintenance

- **Charging:** Recharge the built-in 300mAh battery when the LED indicator shows low power. Use the provided USB-C cable. Avoid overcharging for extended battery life.
- **Storage:** When not in use, store the USB receiver inside the remote's magnetic compartment to prevent loss. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cleaning:** Wipe the remote with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Care:** If the device will not be used for an extended period, charge it periodically (e.g., every 3 months) to maintain battery health.

## Troubleshooting

Problem	Possible Cause	Solution
Remote not responding / No cursor movement.	<ul style="list-style-type: none"> <li>• Remote is off.</li> <li>• Low battery.</li> <li>• USB receiver not properly connected.</li> <li>• Receiver not recognized by computer.</li> <li>• Air mouse function is off.</li> <li>• Out of range.</li> </ul>	<ul style="list-style-type: none"> <li>• Slide the ON/OFF switch to "ON".</li> <li>• Charge the remote.</li> <li>• Ensure the USB receiver is fully inserted into a working USB port. Try a different port.</li> <li>• Remove and re-insert the USB receiver. Restart your computer if necessary.</li> <li>• Press the "ON/OFF Mouse" button to activate air mouse.</li> <li>• Move closer to the computer (within 100 feet / 30 meters).</li> </ul>
Red laser pointer not working.	<ul style="list-style-type: none"> <li>• Remote is off.</li> <li>• Low battery.</li> </ul>	<ul style="list-style-type: none"> <li>• Slide the ON/OFF switch to "ON".</li> <li>• Charge the remote.</li> </ul>
Buttons not performing expected actions (e.g., page up/down).	<ul style="list-style-type: none"> <li>• Software incompatibility.</li> <li>• Temporary software glitch.</li> </ul>	<ul style="list-style-type: none"> <li>• Ensure your presentation software is active and in focus.</li> <li>• Try restarting the presentation software or your computer.</li> <li>• Verify compatibility with your specific software version.</li> </ul>

## Specifications

**Model Number:** WP102

**Connectivity:** RF 2.4GHz Wireless

**Receiver Type:** 2-in-1 USB-A / USB-C

**Battery:** Built-in 300mAh Rechargeable Battery

**Charging Port:** USB-C

**Control Range:** Up to 100 feet (30 meters)

**Laser Type:** Red Light

**Dimensions:** Approximately 6.3 x 1.61 x 1.18 inches (16 x 4.1 x 3 cm)

**Weight:** Approximately 1.76 ounces (50 grams)

**Compatibility:** Windows 2003/XP/Vista/7/8/10+, Mac OS, Linux, Android; PowerPoint, Excel, Prezi, Keynote, etc.

**Manufacturer:** Shenzhen Qixun Space Technology Co., Ltd

## Warranty Information

Specific warranty details for the DinoFire Wireless Presentation Remote (Model WP102) are typically provided at the point of purchase or within the product packaging. Please refer to the documentation included with your product or contact the seller/manufacturer directly for information regarding warranty coverage, terms, and conditions.

## Customer Support


For technical assistance, troubleshooting beyond this manual, or inquiries regarding your DinoFire Wireless Presentation Remote, please contact the seller through the platform where you purchased the product. You may also visit the official DinoFire brand store for additional resources and contact information.

Visit DinoFire  
Store

© 2025 DinoFire. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

## Related Documents - WP102

	<p><a href="#">DinoFire Q94/Q80 Wireless Presenter User Manual</a></p> <p>Comprehensive user manual for the DinoFire Q94/Q80 wireless presenter, covering setup, features, function descriptions, troubleshooting, and FCC compliance.</p>
	<p><a href="#">DinoFire Wireless Game Controller Quick Start Guide - Connect &amp; Features</a></p> <p>Comprehensive quick start guide for DinoFire wireless game controllers (models Q215, Q216, Q217, Q218). Learn how to connect to Nintendo Switch, Android, iOS, and Windows PC, and master features like Turbo, Vibration, Programming, and Lighting effects.</p>
	<p><a href="#">Intermatic Product Catalog Index and Model Guide</a></p> <p>Comprehensive index of Intermatic product models, listing part numbers and corresponding page references for electrical controls, lighting, pool &amp; spa equipment, and surge protection.</p>