

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [FoodSaver](#) /

> [FoodSaver Mini Handheld Vacuum Sealer Machine with Marinate Setting & Charging Dock | Model 2217129 User Manual](#)

FoodSaver 2217129

FoodSaver Mini Handheld Vacuum Sealer Machine

Model: 2217129 | Brand: FoodSaver

INTRODUCTION

The FoodSaver Mini Handheld Vacuum Sealer is designed to extend the freshness of your food, reduce waste, and simplify meal preparation. This compact, rechargeable device offers powerful vacuum sealing for various food storage needs, including freezer, refrigerator, pantry, and sous vide applications. It also features a dedicated Marinate mode to infuse flavors quickly.

This manual provides essential information on setting up, operating, and maintaining your FoodSaver Mini Handheld Vacuum Sealer to ensure optimal performance and longevity.

WHAT'S INCLUDED

Your FoodSaver Mini Handheld Vacuum Sealer kit includes the following components:

- Mini Vacuum Sealer
- Charging Dock
- 2 Quart Zipper Bags
- 2 Reusable Quart Zipper Bags
- 3-Cup Container



AUTO OFF

The vacuum sealer stops automatically when sealing or marinating is done.

Image: Contents of the FoodSaver Mini Handheld Vacuum Sealer Starter Kit.

SETUP

Charging the Device

1. Place the Mini Vacuum Sealer onto the Charging Dock.
2. Connect the Charging Dock to a power outlet using the provided adapter.
3. The battery indicator light on the sealer will illuminate to show charging status. A full charge typically takes approximately 2.5 hours.
4. Ensure the device is fully charged before its first use for optimal battery life.

Starter Kit Includes:



1 Cordless Handheld Vacuum Sealer & Charging Dock



1 3-Cup Container



2 Reusable Quart Zipper Bags



2 Quart Zipper Bags

Image: FoodSaver Mini Handheld Vacuum Sealer on its charging dock.

OPERATING INSTRUCTIONS

Using with Zipper Bags

1. **Fill & Zip Bag:** Place food items into a FoodSaver zipper bag. Ensure the zipper is securely closed, leaving a small gap near the vacuum valve.
2. **Place Mini Over Valve:** Position the nozzle of the Mini Vacuum Sealer directly over the circular vacuum valve on the bag. Ensure a tight seal between the sealer and the valve.
3. **Press Vacuum to Seal:** Press the 'Vacuum' button on the sealer. The device will automatically remove air from the bag. The vacuum process stops automatically when a sufficient vacuum is achieved.



Image: Three-step guide for vacuum sealing with zipper bags.

Using with Containers (Marinate Mode)

1. **Prepare Container:** Place food and marinade into a FoodSaver container. Securely close the container lid.
2. **Position Sealer:** Place the nozzle of the Mini Vacuum Sealer over the vacuum port on the container lid.
3. **Activate Marinate Mode:** Press the 'Marinate' button. The sealer will initiate an automated 3-cycle process (vacuum, release, repeat) to infuse flavor into your food in minutes. The cycle stops automatically when complete.

Keeps Food Fresh Longer*

Compact, Portable Design




*FoodSaver® mini vacuum sealer and zipper bags vs. ordinary fridge storage methods

Image: Using the Marinate mode with a FoodSaver container.

Using with Accessories

The FoodSaver Mini Handheld Vacuum Sealer is compatible with various FoodSaver accessories, including bottle stoppers and jar sealers. Simply attach the appropriate accessory to the item you wish to seal, then use the Mini Sealer over the accessory's vacuum port as described above.



VERSATILE USE

Fridge, freezer, pantry,
or sous vide — perfect
for home or on the go.

Image: Sealing a wine bottle with the FoodSaver Mini Handheld Vacuum Sealer and a bottle stopper.

Official Product Videos

Your browser does not support the video tag.

Video: An official demonstration of the FoodSaver Mini Handheld Vacuum Sealer Machine in use.

Your browser does not support the video tag.

Video: An official demonstration of FoodSaver Reusable Gallon Vacuum Zipper Bags being used with the sealer.

MAINTENANCE

Cleaning

- Wipe the exterior of the Mini Vacuum Sealer with a damp cloth. Do not immerse the device in water.
- The FoodSaver containers and reusable zipper bags are generally dishwasher-safe (top rack recommended) or can be hand-washed with warm, soapy water. Ensure they are completely dry before reuse.
- Regularly check the vacuum nozzle for any food debris and clean as necessary to maintain optimal suction.

Battery Care

- Charge the device fully before long periods of storage.
- For best performance, avoid completely draining the battery frequently.
- Store the device in a cool, dry place.

TROUBLESHOOTING

If you encounter issues with your FoodSaver Mini Handheld Vacuum Sealer, consider the following:

- **No Suction:** Ensure the device is fully charged. Check that the vacuum valve on the bag or container is clean and free of debris. Make sure the sealer's nozzle is firmly pressed against the valve, creating a complete seal.
- **Bag Not Sealing Properly:** Verify that the zipper on the bag is completely closed. Ensure there are no wrinkles or food particles along the zipper or around the vacuum valve.
- **Container Not Sealing:** Check that the container lid is properly aligned and securely latched. Inspect the gasket around the lid and the vacuum port for any damage or debris.
- **Device Not Turning On:** Confirm the device is charged. If the issue persists after charging, contact customer support.

SPECIFICATIONS

| Feature | Specification |
|----------------|------------------------------|
| Brand | FoodSaver |
| Model Number | 2217129 |
| Material | Plastic |
| Color | Blue |
| Item Weight | 2.94 pounds (1.34 Kilograms) |
| Power Source | Battery Powered |
| Operation Mode | Semi-Automatic |

| | |
|--------------------|-----------------------------|
| UPC | 033413005195 |
| Manufacturer | Newell Brands |
| Package Dimensions | 12.32 x 11.42 x 4.49 inches |

WARRANTY & SUPPORT

The FoodSaver Mini Handheld Vacuum Sealer comes with a Limited 5-Year Warranty. For detailed terms and conditions, please refer to the warranty card included in your product packaging or visit the official FoodSaver website.



Image: Limited 5 Year Warranty badge.

For further assistance, product registration, or to purchase additional accessories, please visit the [FoodSaver Store](#) or contact FoodSaver customer support.