KOPIDOE X7

KOPIDOE X7 Bone Conduction Swimming Headphones User Manual

Model: X7

1. Introduction

Thank you for choosing the KOPIDOE X7 Bone Conduction Swimming Headphones. These headphones are designed to provide a unique audio experience for various activities, including swimming, running, and cycling, by transmitting sound through your cheekbones, leaving your ears open to ambient sounds. Featuring IPX8 waterproofing, a built-in 32GB MP3 player, and Bluetooth 5.4 connectivity, the X7 offers versatility and durability for your active lifestyle.

2. Product Overview

The KOPIDOE X7 headphones combine advanced bone conduction technology with robust features for sports and daily use.

- **IPX8 Waterproof:** Designed for immersion up to 3 meters, suitable for swimming and water sports.
- **32GB MP3 Player:** Built-in storage for up to 9,000 songs, allowing music playback without a phone, especially useful underwater.
- **Bluetooth 5.4:** Provides stable and fast wireless connection for audio streaming and calls.
- **Open-Ear Design:** Ensures comfort and situational awareness by not covering your ear canals.
- **8 Hours Battery Life:** Extended playback and talk time on a single charge.
- **Magnetic Charging:** Secure and waterproof charging port.



Image: The KOPIDOE X7 headphones shown with the magnetic charging cable and earplugs.

3. Package Contents

Please check the package for the following items:

- KOPIDOE X7 Bone Conduction Swimming Headphones
- Magnetic Charging Cable
- Earplugs
- User Manual

4. Setup

4.1 Charging the Headphones

Before first use, fully charge your headphones. A full charge takes approximately 2 hours.

1. Connect the magnetic charging cable to the charging port on the headphones. Ensure the magnetic pins align correctly.
2. Plug the USB end of the charging cable into a standard USB power adapter (not included) or a computer's USB port.
3. The indicator light will show charging status (refer to LED indicator section for details).

4. Once fully charged, disconnect the cable.




Image: Close-up of the magnetic charging port on the headphones, illustrating the charging connection.

4.2 Transferring Music to MP3 Mode (32GB Internal Storage)

The headphones have a built-in 32GB storage for MP3 files, allowing you to listen to music without a Bluetooth connection, which is essential for underwater use.

1. Use the original magnetic charging cable to connect your headphones to a computer's USB port.
2. The headphones will appear as a removable USB drive on your computer.
3. Open the headphone's folder.
4. Drag and drop your music files (MP3, WMA, WAV, APE, FLAC formats supported) from your computer into the headphone's folder.
5. Safely eject the device from your computer once transfer is complete.



Image: Instructions for connecting the headphones to a computer and transferring music files to the internal 32GB storage.

4.3 Bluetooth Pairing

To connect your headphones to a Bluetooth-enabled device:

1. Ensure the headphones are powered off.
2. Press and hold the Power button for 3-5 seconds until the LED indicator flashes red and blue, indicating pairing mode.

3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "X7" from the list of devices.
5. Once connected, the LED indicator will flash blue slowly.

The headphones support simultaneous connection to two devices, allowing seamless switching.



Image: Illustration of the headphones connecting via Bluetooth to a laptop and a smartphone.

5. Operation

5.1 Basic Controls




Image: Detailed diagram showing the location and function of each button on the headphones.

- **Power On/Off:** Press and hold the Power button for 3-5 seconds.
- **Play/Pause Music:** Click the Power button once.
- **Volume Up:** Click the '+' button once.
- **Volume Down:** Click the '-' button once.
- **Next Track:** Press and hold the '+' button for 2 seconds.
- **Previous Track:** Press and hold the '-' button for 2 seconds.
- **Answer/Hang Up Call:** Click the Power button once during an incoming call.

- **Reject Call:** Press and hold the Power button for 2 seconds during an incoming call.

5.2 Switching Between Bluetooth and MP3 Mode

The headphones power on automatically in Bluetooth mode. To switch between modes:

- **Switch Mode:** Double-click the Power button to toggle between Bluetooth mode and MP3 (internal storage) mode.

Important Note for Swimming: Bluetooth signals cannot transmit underwater. When swimming, you **must** switch the headphones to MP3 mode to listen to music stored on the device.




Image: Diagram illustrating how to switch between Bluetooth and MP3 modes using the power button.

5.3 Wearing the Headphones

Place the headphones over your ears with the bone conduction transducers resting on your cheekbones, just in front of your ears. The band should wrap around the back of your head. Adjust for a comfortable and secure fit.



Image: A man wearing the KOPIDOE X7 headphones during a run, demonstrating the open-ear design and comfortable fit.

6. Maintenance

Proper care will extend the life of your KOPIDOE X7 headphones.

- **Cleaning:** After use, especially after swimming or heavy sweating, rinse the headphones with clean fresh water. Wipe them dry with a soft cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Charging Port:** Ensure the magnetic charging port is clean and dry before charging to prevent corrosion.
- **Avoid Impact:** Do not drop or subject the headphones to strong impacts.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No power	Low battery	Charge the headphones fully.
Cannot pair via Bluetooth	Headphones not in pairing mode; Device Bluetooth off; Too far from device	Ensure headphones are in pairing mode (red/blue flashing LED). Turn on device Bluetooth. Move closer to device (within 10 meters).
No sound in water	Still in Bluetooth mode; No music files on device	Double-click Power button to switch to MP3 mode. Ensure music files are transferred to the 32GB internal storage.
Cannot transfer music files	Improper connection; Unsupported file format	Ensure magnetic cable is securely connected. Try a different USB port. Check if music files are MP3, WMA, WAV, APE, or FLAC.
Sound quality issues	Improper fit; Earplugs not used (for swimming)	Adjust headphones for optimal placement on cheekbones. Use earplugs when swimming for improved sound clarity.

8. Specifications

Feature	Specification
Model Name	X7
Brand	KOPIDOE
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth 5.4
Water Resistance Level	IPX8 (up to 3 meters)
Internal Storage	32GB (for MP3 mode)
Battery Life	Up to 8 Hours
Charging Time	Approximately 2 Hours
Audio Driver Type	Bone Conduction Driver
Bluetooth Range	Up to 10.06 Meters (33 feet)
Frequency Range	20Hz - 20,000Hz
Item Weight	4.8 ounces
Earpiece Shape	Open-ear with hook
Control Method	Push Button
Compatible Devices	Smartphone
UPC	768365687235

9. Warranty and Support

KOPIDOE products are manufactured to high quality standards. For warranty information, technical support, or customer service inquiries, please refer to the contact information provided on the product packaging or visit the official KOPIDOE website. Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question