

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VEVOR](#) /

› [VEVOR 22.8-inch Freestanding Electric Fireplace Stove Heater Instruction Manual](#)

VEVOR TPL-A1-5

VEVOR 22.8-inch Freestanding Electric Fireplace Stove Heater

MODEL: TPL-A1-5

Introduction

Thank you for choosing the VEVOR 22.8-inch Freestanding Electric Fireplace Stove Heater. This compact and portable unit is designed to provide efficient infrared heating and a realistic flame effect, creating a warm and comfortable atmosphere in your home. With easy installation and robust safety features, it's an ideal addition to any living space.



Figure 1: The VEVOR electric fireplace, ideal for adding warmth and ambiance to various rooms like living rooms, bedrooms, studies, and dining areas.

Safety Information

Please read all safety instructions carefully before using this electric fireplace. Keep this manual for future reference.

- Ensure the unit is placed on a firm, level surface.
- Do not cover the heater or block any air vents.
- Keep flammable materials at least 3 feet (0.9 meters) away from the front of the heater.
- Do not use outdoors or in wet locations.
- Always plug the heater directly into a wall outlet. Never use with an extension cord or relocatable power tap.
- This appliance is equipped with an overheating protection system that automatically shuts off power at critical temperatures to prevent hazards. If this occurs, unplug the unit, allow it to cool, and then plug it back in.
- Keep children and pets away from the heater.

Sleep Soundly All Night

Secure Design for Reliable Rest



Figure 2: The electric fireplace features an overheating auto shutoff for enhanced safety and peace of mind, especially in bedrooms.

Package Contents

Verify that all items are present and in good condition upon unpacking.

- Electric Fireplace Unit x 1
- Mounting Legs x 4
- Phillips Screws x 12
- User Manual x 1

5120 BTU - Quickly Heats Up Your Bedroom




Figure 3: Unpacked components of the VEVOR electric fireplace, showing the main unit and the separate legs that require assembly.

Setup and Assembly

Assembly of your VEVOR electric fireplace is quick and straightforward, requiring only a few minutes.

- 1. Attach the Legs:** Carefully place the main fireplace unit upside down on a soft, non-abrasive surface to prevent scratches. Align each of the four mounting legs with the designated screw holes on the bottom of the fireplace.
- 2. Secure with Screws:** Use the provided Phillips screws to firmly attach each leg to the fireplace unit. Ensure all screws are tightened securely.

3. Position and Plug In: Once all legs are attached, carefully turn the fireplace upright and place it in your desired location. Ensure it is on a stable, level surface and away from any flammable materials. Plug the power cord into a standard electrical outlet.

Just 3 Steps to Enjoy the Heat

Step 1

Attach 4 legs to the base



Step 2

Secure with screws



Step 3

Plug in and start heating



Figure 4: A visual guide illustrating the simple three-step assembly process: attaching the legs, securing them with screws, and plugging in the unit.

Video 1: This video demonstrates the unboxing, quick assembly of the legs, and basic operation of the electric fireplace, including turning on the flame effect and adjusting heat settings.

Operating Instructions

Your electric fireplace offers both realistic flame effects and efficient heating modes.

Control Panel Overview

The control panel, typically located on the unit, allows you to manage all functions:

- **Power Switch:** Turns the unit on/off.
- **Flame Effect Switch:** Activates the realistic 3D rolling flame effect independently.
- **Heat Mode Switches:** Select between 900W (low heat) and 1500W (high heat) settings.
- **Thermostat Dial:** Adjusts the desired room temperature. The heater will cycle on and off to maintain this setting.



Figure 5: The intuitive control panel allows users to independently control the flame effect and select between 900W (low) and 1500W (high) heating modes.

Using the Flame Effect

To enjoy the visual ambiance without heat, simply turn on the flame effect switch. The realistic 3D flames and glowing logs will provide a cozy atmosphere.



Figure 6: The realistic 3D rolling flame effect with glowing logs provides a comfortable visual experience, enhancing your decor.

Activating Heating Modes

Select either the 900W or 1500W switch to activate the heating function. Adjust the thermostat dial to your preferred temperature. The unit will automatically regulate heat output to maintain the set temperature.

Maintenance

Regular maintenance ensures optimal performance and longevity of your electric fireplace.

- **Cleaning:** Always unplug the unit before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the fireplace in a cool, dry place, preferably in its original packaging.
- **Ventilation:** Ensure the air intake and exhaust vents are free from dust and debris to maintain proper airflow.


Troubleshooting

If you encounter any issues with your electric fireplace, refer to the following common solutions:

- **No Power:** Check if the power cord is securely plugged into a working outlet. Verify that the outlet is receiving power by testing it with another appliance.
- **No Heat:** Ensure the heat setting (900W or 1500W) is selected and the thermostat dial is set to a temperature higher than the current room temperature. Check if the overheating protection has activated (unplug and cool down).
- **No Flame Effect:** Ensure the flame effect switch is turned on.
- **Unusual Noise:** If you hear unusual noises, immediately unplug the unit and contact customer support.

Specifications

Feature	Specification
Brand	VEVOR
Model Name	Freestanding Fireplaces
Item Model Number	TPL-A1-5
Size	22.8 Inch
Product Dimensions	15.75"D x 9.84"W x 22.83"H
Item Weight	8.2 Pounds
Power Source	Corded Electric
Heat Output	1500 Watts (5120 BTU)
Material	Plastic
Finish Type	Powder Coated
Installation Type	Freestanding
Color	Black
UPC	197988155638



Item Model Number: **TPL-A1-5**

Installation Type: **Freestanding**

Heat Output: **5120 BTU**

Color: **Black**

Item Dimensions: **15.75 x 9.84 x 22.83 in / 400 x 250 x 580 mm**

Power Supply: **Wired**

Power: **1500W**

Material: **PP**

Net Weight: **8.2 lbs / 3.72 kg**

Accessories:

User Manual **x 1**

Mounting Legs **x 4**

Phillips Screws **x 12**

Figure 7: This diagram provides key product specifications including dimensions, power, heat output, material, color, weight, and a list of included accessories for easy reference.

Warranty and Support

For warranty information or technical support, please refer to the contact details provided in the separate warranty card included with your product or visit the official VEVOR website. Keep your purchase receipt as proof of purchase.