

YFDSPSM Streaming Stick PRO

YFDSPSM Streaming Stick PRO Smart TV Box User Manual

Model: Streaming Stick PRO

1. INTRODUCTION

Thank you for choosing the YFDSPSM Streaming Stick PRO Smart TV Box. This device transforms any television into a smart entertainment hub, offering seamless streaming with advanced features. Powered by a quad-core processor and the Android GTV operating system, it delivers crystal-clear visuals up to 8K resolution and stable connectivity via dual WiFi and Bluetooth 5.0. This manual provides essential information for setup, operation, and maintenance to ensure you get the most out of your device.

2. SAFETY INFORMATION

- Read all instructions carefully before use.
- Keep the device away from water, moisture, and extreme temperatures.
- Do not attempt to disassemble or repair the device yourself. Refer to qualified service personnel.
- Use only the provided power adapter to prevent damage.
- Ensure proper ventilation around the device to prevent overheating.
- Keep out of reach of children.

3. PACKAGE CONTENTS

Please check the box for the following items:

- YFDSPSM Streaming Stick PRO Smart TV Box
- Bluetooth Voice Remote Control
- Power Adapter
- HDMI Cable
- User Manual

0.32inch



HDMI



adapter



remote control

Image: Package contents of the YFDSPSM Streaming Stick PRO, showing the TV box, remote control, HDMI cable, and power adapter.



Image: Additional view of package contents, highlighting the user manual alongside the TV box, HDMI cable, and power adapter.

4. PRODUCT OVERVIEW

4.1. Device Layout



Image: The YFDSPSM Streaming Stick PRO Smart TV Box shown with its accompanying remote control.

The YFDSPSM Streaming Stick PRO is a compact TV box designed to deliver high-performance streaming. It features a powerful quad-core processor, 2GB of RAM, and 16GB of ROM for smooth operation and ample storage for applications and media. The device supports up to 8K resolution for stunning visual clarity.

High performance and large capacity storage space

2GB of running space+16GB of storage



Image: Visual representation of the TV box's high performance, highlighting 2GB of running space (RAM) and 16GB of storage (ROM).

Full format HD King Dolby World

True 4K picture quality bid farewell to blur

4K

2k



Image: A visual comparison showcasing the difference between 4K and 2K picture quality, emphasizing the enhanced detail provided by 4K resolution, supported by the TV box.

4.2. Ports and Connections

The device is equipped with various ports for versatile connectivity:

- **Power Port (DC):** For connecting the power adapter.
- **HDMI:** For connecting to your TV or display.
- **USB (x2):** For connecting external storage devices or peripherals.
- **Memory Card Slot:** For expanding storage with a memory card.
- **Ethernet (LAN):** For wired network connection.
- **AV Port:** For connecting to older TVs or audio systems.
- **SPDIF:** For digital audio output.

We are adaptable to connecting HDMI, USB, and Ethernet to many ports



Image: Detailed view of the YFDSPSM Streaming Stick PRO TV box, highlighting its various input/output ports including Power, HDMI, USB, Memory Card, Ethernet, and AV.

4.3. Remote Control

The included Bluetooth 5.0 voice remote control allows for easy navigation and voice commands, enhancing your user experience.

5. SETUP

5.1. Physical Installation

1. Connect one end of the HDMI cable to the HDMI port on the TV Box and the other end to an available HDMI input on your television.
2. Connect the power adapter to the DC power port on the TV Box, then plug the adapter into a power outlet.
3. Turn on your television and select the correct HDMI input source using your TV remote.

Video: This video demonstrates the unboxing, physical installation, and initial network connection process for a similar Android TV Box. It shows how

to connect the device to a TV via HDMI and power, and how to set up the network.

Video: This video provides an unboxing and installation guide for a similar Android TV Stick. It illustrates the connection steps to a TV and the initial setup of the user interface.

5.2. Initial Configuration

1. Once powered on, the device will boot up and display the Android TV logo.
2. Follow the on-screen prompts to select your preferred language and region.

5.3. Remote Control Pairing

The Bluetooth voice remote needs to be paired with the TV Box for full functionality:

1. Ensure the remote has batteries installed.
2. Hold the remote close to the TV Box (within 20cm).
3. Press and hold the 'Home' and 'Back' buttons on the remote simultaneously for approximately 10 seconds until the remote's indicator light flashes, then release.
4. The TV Box will detect and connect to the remote. A confirmation message will appear on the screen.

5.4. Network Connection

Connect your TV Box to the internet for streaming content:

1. From the home screen, navigate to **Settings**.
2. Select **Network & Internet**.
3. Choose your desired Wi-Fi network from the list of available networks.
4. Enter the Wi-Fi password using the on-screen keyboard and select **Connect**.
5. Alternatively, connect an Ethernet cable to the LAN port on the TV Box for a wired connection.

6. OPERATING INSTRUCTIONS

6.1. Navigation

Use the directional pad (D-pad) and the 'OK' button on your remote control to navigate through the Android GTV interface. The 'Home' button returns you to the main screen, and the 'Back' button allows you to go back to the previous screen.

6.2. App Usage

The TV Box comes with pre-installed apps like YouTube and Prime Video. You can install additional applications from the Google Play Store:

1. From the home screen, navigate to the 'Apps' section or select the '+' icon to add a new app to your favorites.
2. Select the **Google Play Store** icon.
3. Browse or search for your desired applications.
4. Select an app and choose **Install** to download and install it on your device.

6.3. Voice Control

The Bluetooth voice remote allows you to use voice commands for searching content, controlling playback, and more:

1. Press the dedicated Voice Assistant button (usually a microphone icon) on your remote.
2. Speak your command clearly into the remote. For example, "Open Netflix" or "Search for action movies."

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the device. Do not use liquid cleaners or aerosols.
- **Software Updates:** The device may receive periodic software updates. Ensure your device is connected to the internet to receive these updates, which improve performance and add new features. You can check for updates in the Settings menu.
- **Storage Management:** Regularly clear cache and uninstall unused apps to maintain optimal performance.

8. TROUBLESHOOTING

Issue	Possible Cause	Solution
No power/Device not turning on	Power adapter not connected, faulty outlet.	Ensure power adapter is securely connected to the device and a working power outlet. Try a different outlet.
No signal on TV	Incorrect HDMI input selected, loose HDMI cable.	Verify the TV is on the correct HDMI input. Check HDMI cable connections at both ends. Try a different HDMI port or cable.
Remote control not responding	Batteries low/dead, remote not paired.	Replace remote batteries. Re-pair the remote control following the instructions in Section 5.3.
Wi-Fi connection issues	Incorrect password, router issues, device too far from router.	Double-check Wi-Fi password. Restart your router. Move the TV Box closer to the router or use a wired Ethernet connection.
Apps crashing or slow performance	Insufficient memory, app issues, outdated software.	Clear app cache (Settings > Apps > [App Name] > Clear Cache). Restart the device. Check for system and app updates.

9. SPECIFICATIONS

Feature	Detail
Brand	YFDSPSM
Model Number	SF20250914B0FGCPZYNL
Operating System	Android GTV
Processor	Quad-core
RAM	2 GB
ROM (Storage)	16 GB
Resolution Support	Up to 8K (Video Output Resolution: 3840 Pixels, commonly known as 4K)
Connectivity	Dual Wi-Fi (2.4G & 5G), Bluetooth 5.0, Ethernet
Supported Internet Services	Netflix, Hulu, Amazon Prime Video, YouTube, etc.
Form Factor	TV Box
Item Weight	12 ounces (0.34 Kilograms)
Product Dimensions	3.5 x 1 x 3.5 inches
Compatible Devices	Television

10. WARRANTY & SUPPORT

Your YFDSPSM Streaming Stick PRO Smart TV Box comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.

For technical support, troubleshooting assistance, or warranty claims, please contact YFDSPSM customer service through the retailer where you purchased the product or visit the official YFDSPSM website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question